


Welcome Guide

Upster

What's Included



x 2

7" Tablet




Stand x 2



x 2

Adapter



Micro USB cable x 2





Spring wire x 2




iBeacon



Rubber pad x 4

 <p>Adhesive tape      x 4</p>	 <p>Welcome Guide</p>	
---	--	--

## At a Glance



1. Front camera
2. Microphone
3. Touch screen
4. Volume up button
5. Volume down button
6. Power button



- 7. Micro USB port
- 8. 3.5 mm headphone jack
- 9. Speaker

---


## Installing the Stand

### 1. Fix the stand

g g



## 2. Attach the iBeacon



## 3. Connect the spring cable



1



2



3



4

---


## Operating Your Tablet

### 1. Power on/off


1. Press and hold the Power button until the startup screen appears



2. Slide the Unlock icon to activate screen



3. Press and hold the Power button until “Power Off” options appear




4. Select “OK” to confirm




3

## 2. WiFi connection


1. Select "Setting"




2. Touch Wi-Fi to "ON"



3. Select your Wi-Fi connection



#### 4. Enter password




#### 5. Once connected, Wi-Fi connectivity icon will be shown at the right up corner




### 3. APP menus




#### 1. Touch APP menu






2. Select the application you'd like to open



 <b>Home</b>	Go directly to the Home screen
 <b>Back</b>	Go to the previous page
 <b>Recent APPs</b>	See recently opened applications

---

## Charging Your Tablet



---




## Customizing Your Tablet



1. App setting

2. Member club

---

## Specifications

Input	AC 100 - 240 V
Output	5 V / 2 A
Display	7 inches (diagonal)
Resolution 	1280 × 800
CPU 	Dual Core 1.3 - 1.8 GHz
Memory 	8 G

Battery 	2500 mAh
Pixels 	2 MP
Size	185 × 104 × 6 mm / 7.3 × 4.1 × 0.2 in
Weight	234 g / 8.3 oz

---

### Attention

Use original or certified cables  
 Don't expose to liquids  
 Don't disassemble  
 Avoid dropping  
 Avoid extreme temperatures

---

### FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the

receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio / TV technician for help.

**RF Warning Statement**

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

---