

## RC Plush Animal User Manual

### Battery installation

#### For Animal Car

Remove the screw and open the batteries cover.

Insert 3\*AAA batteries (1.5V) and close the batteries cover.

Put the screw back and lock the batteries cover.

#### For Remote Controller:

Remove the screw and open the batteries cover.

Insert 2\*AAA batteries (1.5V) and close the batteries cover.

Put the screw back and lock the batteries cover.

#### **⚠ WARNING: TO AVOID BATTERY LEAKAGE**

- 1) The batteries used with this product are small parts and should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone American Association of Poison Control Centers (1-800-222-1222).
- 2) Always purchase the correct size and grade of battery most suitable for intended use.
- 3) Do not mix old and new batteries, alkaline, standard (Carbon - Zinc) or rechargeable (Nickel-cadmium) batteries.
- 4) Clean the battery contacts and those of the device prior to battery installation.
- 5) Ensure the batteries are installed correctly with the regard to polarity (+ and -).
- 6) Always remove batteries if consumed or if product is to be left unused for a long time.

### Operation procedure

Put the Animal car on the floor and make sure the frequency docking successfully when the car and the controller are turned on.

Use the remote controller to control the Animal Car.

The animal car will move forward when you press the forward button in left side.

The animal car will rotate backward when you press the backward button in right side.

### Notes:

Please make sure the car and remote controller within 5 meter range.

Age Recommendation: 10+ years and adult supervision required.

If you do not play the car, you must remove the batteries from both of the remote controller and the car.

### Packaging includes:

Animal car unit 1pc

Remote controller unit 1pc

### Product dimension:

Animal car unit: 4.6"W\*3"D\*6"H

Remote controller unit: 2.55"W\*2.65"D\*0.85"H

### Description:

Remote controller batteries: 2\*AAA (1.5V) batteries are not included.

Animal car batteries: 3\*AAA (1.5V) batteries are not included.

Range: 5 meters

Duration: about 15mins

Suitable for children of 10 years old or above

## User Manual

This device complies with Part 15 of FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changers or modifications to this unit not expressly approved by the party responsible for the compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part, 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Warning statement:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

Conforms to ASTM F963-17