

Circuit Description

The car will receive the RF signals by antenna. The received signals are selected and amplified by Q1 and peripheral components. The encoding signals will be decoded by U1, and drive the motors, then the car will be moving