



Rechargeable Remote Training Collar

operating and training guide



1 Dog Model Number
PTS-018



2 Dog Model Number
PTS-018B

PLEASE READ THIS ENTIRE GUIDE BEFORE BEGINNING

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Reference Size for Different Dogs

Size	Neck (in)	Chest Measurement (in)	Back Length (in)	Type
Mini	7.8-8.6	9.8-11.8	7.5	Chihuahua, Yorkshire Terrier
Small	7.8-9.5	11.4-14.2	9	Chihuahua, Yorkshire Terrier, Poodle, Pomeranian
Medium	9-11	13.7-16.5	11	Maltese Dog, Shih Tzu
Large	10.6-12.2	16.2-18.5	12.2	Miniature Schnauzer, Pekingese
Large	11.8-13.4	18.1-20.8	13.8	Schnauzer, English Cocker Spaniel
Large	13-14.5	20.5-23.2	15.7	Beagle
Huge	17-18.9	30-33	23.6	Husky
	18.5-20.5	34.6-38.2	25.6	Labrador Retriever
	21.6-24.4	36.2-39.3	27.5	Golden Retriever, Old English Sheepdog

Reference Weight for Dogs

Large Dog (Body height above 24 inch, Weight above 88 lbs)

Medium Dog (Height 16-24 inch, Weight 24.2-66 lbs)

Small Dog (Height 10-16 inch, Weight 8.8-22 lbs)

Mini Dog (Height under 10 inch, Weight under 8.8 lbs)

Troubleshooting

<p>My pet does not respond when I press a button.</p>	<ul style="list-style-type: none"> • Make sure the Receiver Collar has been turned on. • If your range has reduced from the first time you used the Rechargeable Remote Training Collar, the battery(s) may be low in either the Remote Transmitter or Receiver Collar. • Many factors can impact the amount of range you have with the Rechargeable Remote Training Collar. See “How the System Works”. • Test the Receiver Collar. See “Test Light Instructions” for details. • Increase the Stimulation/Vibration Level. Refer to “Find the Best Stimulation/Vibration Level For Your Pet” for more information. • Make sure the Receiver Collar’s Contact Points are placed snugly against your pet’s skin. Refer to “Fit the Receiver Collar” for more information.
<p>The Receiver Collar will not turn on.</p>	<ul style="list-style-type: none"> • Make sure the Receiver Collar has been charged. For the initial charge, be sure to charge it for 4 hours. Subsequent charges only take 2-3 hrs.
<p>The Receiver Collar is not responding to the Remote Transmitter.</p>	<ul style="list-style-type: none"> • Verify the Receiver Collar is on. • If the Indicator Light does not come on when any button is pressed on the Transmitter, ensure that the Receiver has been charged. • If the first two solutions did not resolve your problem, see “To Pair the Remote Transmitter and the Receiver Collar.”

Test Light Instructions



1. Turn the Receiver Collar on.
2. Hold the Test Light Contacts to the Contact Points.
3. Press the Stimulation Button on the Remote Transmitter.
4. The Test Light will flash. Note: At higher Stimulation Levels, the Test Light will flash brighter.
5. Turn the Receiver Collar off.

Save the Test Light for future testing. Note: If the Test Light does not flash, replace the batteries and re-test. If Test Light still does not flash, contact us for Customer Service.

Important Safety Information

Explanation of Attention Words and Symbols used in this guide



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

CAUTION, used with the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

CAUTION

CAUTION, used without the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in harm to your pet.

WARNING

Not for use with aggressive dogs. Do not use this Product if your dog is aggressive, or if your dog is prone to aggressive behavior. Aggressive dogs can cause severe injury and even death to their owner and others. If you are unsure whether this product is appropriate for your dog, please consult your veterinarian or certified trainer.

CAUTION

Safety during on-leash training. It is vitally important that you and your dog remain safe while learning during on-leash training. Your dog should be on a strong leash, long enough for him to attempt to chase an object, but short enough for him not to reach a road or other unsafe area. You must also be physically strong enough to restrain your dog when he tries to chase.

CAUTION

Risk of skin damage. Please read and follow the instructions in this manual. Proper fit of the collar is important. A collar worn for too long or made too tight on the pet’s neck may cause skin damage. Ranging from redness to pressure ulcers; this condition is commonly known as bed sores.

- Avoid leaving the collar on the dog for more than 12 hours per day.
- When possible reposition the collar on the pet’s neck every 1 to 2 hours.
- Check the fit to prevent excessive pressure; follow the instructions in this manual.
- Never connect a lead to the electronic collar; it will cause excessive pressure on the contacts.
- When using a separate collar for a lead, don’t put pressure on the electronic collar.
- Wash the dog’s neck area and the contacts of the collar weekly with a damp cloth.
- Examine the contact area daily for signs of a rash or a sore.

- If a rash or sore is found, discontinue use of the collar until the skin has healed.
- If the condition persists beyond 48 hours, see your veterinarian.

These steps will help keep your pet safe and comfortable. Millions of pets are comfortable while they wear stainless steel contacts. Some pets are sensitive to contact pressure. You may find after some time that your pet is very tolerant of the collar. If so, you may relax some of these precautions. It is important to continue daily checks of the contact area. If redness or sores are found, discontinue use until the skin has fully healed.

The Rechargeable Remote Training Collar must be used only on healthy dogs. We recommend that you take your dog to a veterinarian before using the collar if he is not in good health.


Frequently Asked Questions

Is the Stimulation/Vibration safe for my pet?	<ul style="list-style-type: none"> • While the Stimulation/Vibration is unpleasant, it is harmless to your pet. Electronic training devices require interaction and training from the owner to achieve desired results.
How old does my pet have to be before using the Rechargeable Remote Training Collar?	<ul style="list-style-type: none"> • Your pet should be able to recognize basic obedience commands such as "Sit" or "Stay". Pets should be at least 6 months old before using the Training Collar.
Once my pet is trained and has been obeying my commands, will he have to continue to wear the Receiver Collar?	<ul style="list-style-type: none"> • Probably not. You may need to reinforce training with the Receiver Collar from time to time.
Is the Receiver Collar waterproof?	<ul style="list-style-type: none"> • Yes.
Will I get exactly 450 yards of range with the Rechargeable Remote Training Collar?	<ul style="list-style-type: none"> • The range of the Rechargeable Remote Training Collar will vary according to terrain, weather, vegetation, as well as transmission from other radio devices. See "How the System Works" for tips on maximizing your range.
How long can I continuously deliver stimulation/vibration to my pet?	<ul style="list-style-type: none"> • The maximum amount of time you can press the Stimulation or Vibration Button and deliver stimulation/vibration to your pet continuously is 10 seconds. After this, there's a time-out and stimulation/vibration cannot be delivered for 5 seconds. After the 5 second time-out period, Button can be pressed and stimulation/vibration can be delivered again.

Trash Raiding

The easiest way to prevent trash raiding is to remove garbage and tempting food from your pet's environment. You can use the Remote Training Collar to teach your pet to stay away from these items; however, you must be prepared to correct your pet every time he approaches them.

1. Choose the Intensity Level 1 higher than your pet's Recognition Level.
2. Pick a temptation for your pet and position yourself where he cannot see you.
3. While your pet's mouth is touching the temptation, press and hold the Stimulation/Vibration Button. Immediately, release the button when your pet leaves the temptation .
4. Do not say anything, as you want your pet to associate the stimulation/vibration with his behavior, not you.
5. If your pet does not respond to the stimulation, increase the Intensity Level by 1 and repeat the process.
6. Repeat this process in several different locations with different temptations.



Thank you for choosing PTS-018. Our mission is to offer the best electronic training solutions. We want to ensure your pet's safety by providing you with the tools and techniques to successfully train your pet. You and your pet deserve a companion that includes memorable moments and a shared understanding together. If you have any questions, please contact us for Customer Service.

Table of Contents

Components	5
Other Items You May Need	5
How the System Works	6
Features	6
Key Definitions	7
Operating Guide	9
Prepare the Remote Transmitter	9
Prepare the Receiver Collar	11
Fit the Receiver Collar.....	12
To Pair the Remote Transmitter and Receiver Collar.....	15
Two Dog System.....	15
Training Guide	16
General Tips.....	16
Teaching Your Pet the Positive Tone	16
Find the Best Stimulation Level for Your Pet	17
Teaching Basic Obedience	18
The "Sit" Command.....	18
The "Come" Command.....	18
The "Stay" Command	19
Eliminating Unwanted Behavior	20
Jumping Up	20
Digging	21
Chasing	22
Trash Raiding	23
Frequently Asked Questions	24
Troubleshooting	25
Test Light Instructions	25

Reference Size for Different Dogs26
 Reference Weight for Dogs26

Components



Other Items You May Need


- Scissors
- Lighter
- Non-metallic collar and 10-foot leash

Chasing

Chasing is an instinctive behavior stimulated by moving objects. Some dogs have a particularly strong desire to chase that can put them in harm's way and leave you helpless. Never allow your dog off the leash or out of a contained area until he has learned the "Come" command, regardless of the distraction. Be consistent and correct your dog every time he chases something.

CAUTION It is vitally important that you and your dog remain safe while learning during on-leash training. Your dog should be on a strong leash, long enough for him to attempt to chase an object, but short enough for him not to reach a road or other unsafe area. You must also be physically strong enough to restrain your dog when he tries to chase.


1. If your dog has not learned the "Come" command, keep a leash on him so you can physically stop him before he reaches the object he is chasing.
2. Choose the Intensity Level 1 higher than your dog's Recognition Level.
3. Set up a scenario where your dog is enticed to chase an object. Common items could be cars, motorcycles, bicycles, etc. (do not use toys).
4. When the object passes in front of your dog, make sure to hold the leash with a firm grip. As soon as your dog begins to chase the object, press and hold the Stimulation/Vibration Button until he stop.
5. When your dog stops chasing the object, immediately release the button, walk backwards and give the command "Come." Praise your dog as he comes to you.
6. Repeat the process until your dog stops chasing the object.



Digging

It is important to first understand why your pet is digging. Many dogs, such as terriers, were bred to flush out prey, and digging is very innate to them. Other dogs may be digging to find a cool spot to lie down, or simply out of boredom. Your pet may no longer have the desire to dig if he is provided with the following:

- A cool, shaded area in which to lie down, and plenty of water.
 - An alternate activity, such as a favorite toy.
 - Plenty of play, exercise, and attention.
 - A yard free from rodents or prey that he may be trying to flush out.
1. Choose the Intensity Level 1 higher than your pet's Recognition Level.
 2. Place the Receiver Collar on your pet and wait at least 10 minutes before placing him in the yard. No other people or pets should be in the yard, as you do not want your pet to associate the stimulation/vibration with anything other than his digging. Your pet must be securely fenced in or contained during training.
 3. From a window or area where your pet cannot see you, wait until your pet begins to dig.
 4. While your pet digs, press the Stimulation/Vibration Button and release it when he stops digging. Only press the button while your pet is in the act of digging, and do not say anything to him .
 5. If your pet ignores the stimulation/vibration, increase the Intensity Level by 1.
 6. Continue to watch your pet, as he may choose another area to dig.
 7. Do not allow your pet in the yard unsupervised until he has completely stopped digging.



How the System Works

Now you can experience the difference a Rechargeable Remote Training Collar can make. Spend less time training and more time enjoying your dog. The Rechargeable Remote Training Collar is easy to use with an advanced digital display that tells you exactly what level of stimulation/vibration you are using.

The Rechargeable Remote Training Collar assists you in controlling your pet without a leash in a range of up to 450 yards. When you push a button, a signal sending from your remote activates your dog's Receiver Collar. He receives a safe but annoying stimulation. He'll quickly learn the association between his behavior and your correction; in no time, you'll have a better-behaved pet. The Rechargeable Remote Training Collar have been proven safe, comfortable, and effective for both small and large dog breeds.

Using the Rechargeable Remote Training Collar consistently and correctly, any basic obedience commands can be taught and many misbehaviors that your pet exhibits can be corrected.

Important: The Rechargeable Remote Training Collar has a range up to 450 yards. Hold the Remote Transmitter in a horizontal position away from your body to achieve optimum range. Terrain, weather, vegetation, transmission from other radio devices, and other factors will affect the maximum range.



Features

- Range up to 450 yards
- 16 levels of stimulation (1-16 levels)
- 16 levels of vibration (1-16 levels)
- Individual Stimulation only button
- Individual Vibration only button
- Individual Tone only button
- Train up to 2 dogs
- Big Blue Backlight LCD
- Easy to read Digital Display on Transmitter displays current Stimulation/Vibration Level and battery status
- Rechargeable Batteries in both the Remote Transmitter and Receiver Collar
- Waterproof Receiver Collar