





1. Photographs of Conducted Emissions Test Configuration

Test Mode: Mode 1, Mode 3, Mode 4 and Mode 5



FRONT VIEW





Test Mode: Mode 2 and Mode 6



FRONT VIEW









2. Photographs of Radiated Emissions Test Configuration

Test Mode: Mode 1 and Mode 4




FRONT VIEW





Test Mode: Mode 2 and Mode 3



FRONT VIEW






Test Mode: Mode 5



FRONT VIEW



Test Mode: Mode 6



FRONT VIEW





_