LIMITED PRODUCT WARRANTY

LIMITED PHODUCS WARRANTY

What Markey Inventors the Products are conversed by a familiar product or surrorly planted thermyly for the year peed tilluling the Yound Markey Inventors and Products are conversed to the Product of the Young Transport of the Markey Transport of

This Limited Warranty does not cover any Merkury Innovations Product purchased through non-authorized dealers and/or online auction This Limited Warmity does not cover any Meeting Venoculous Product purchased Product Ministrational Counties and and of or the authors. This Limited Warmity algorithm of the Counties of the

Sole and Exclusive Remedy
Your sole and exclusive remedy for any breach by Merkury Innovations of this Limited Warranty, and Merkury Innovations' sole and Your sole and exclusive emorby for any breach by Membry Increasors and the Lintest Warment, and Membry Increators design the size for siles before the Section 1, as all feeting Proceeds or, of the search glain is advantable during the facility (30 calandar days of the Warmen Proceds or Membry Proceds or, of the search glain is advantable during the facility (30 calandar days of the Warmen Proced, when the purchase price of the Membry Increasors and the Section 1, a

Obtaining Warranty Service
To make a warranty claim please contact customer support: support@merkuryinnovations.com Warranty Disclaimers

EXCEPT AS EXPRESSLY SET FORTH ABOVE IN THIS LIMITED PRODUCT WARRANTY SECTION, EACH MERKURY INNOVATIONS

YOU MAY ASO INVECTOR RIGHTS WHICH WARF FROM JURISDICTION TO JURISDICTION.

LIMITEDISON OF LIMING TO CLUSE OF ACTION OF FEMORY OF JURISDICTION, SHALL MERGINARY INDIVIDUATION TO DESTRUCTION.

OF SIPPLIES IRE JURISDICTION OF STATE OF THE STATE OF ST THE POSSIBILITY OF SUCH DAMAGES, WITHOUT LIMITING THE FOREGOING, YOU UNDERSTAND AND AGREE THAT MERKURY INNOVATIONS HAS NO LIABILITY FOR ANY DAMAGE OR DESTRUCTION TO CONSUMER ELECTRONICS DEVICES OR OTHER PERSONAL PROPERTY THAT ARE CONTAINED INSIDE OR OUTSIDE THE MERKURY INNOVATIONS PRODUCTS, INCLUDING PERSONAL PROFESTY THAT ARE CONTAINED BASED OR DUTILES THE MERSOURY INNOVATIONS PROCUSTS, INCLUDING, WITHOUT UNDITED, WITHOUT CHARGE TO PROMISE, OR CHARGE TO SERVE, OR CHARGE TO SERVE, OR CONTRIBUTION OF THE NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate

radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not

occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Regrient or relocate the receiving antenna

- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is
- -Consult the dealer or an experienced radio/TV technician for help.


This device complies with part 15 of the FCC rules. Operation is subject to the following two

- (2) this device must accept any interference received, including interference that may cause

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

IMPORTANT

PLEASE READ BEFORE USING THIS PRODUCT





User's manual for H3W

Inside Box:

- 1 Bluetooth Speaker 1 Micro LISB Cable

Features:

- Durable, shock and weather-resistant
 On-board playback and volume controls
- . 3.5mm audio jack to provide a wired audio input

Charge It

- Plug the charging cable into the charging port on the back of the speaker, and connect the other end of the cable to either a computer USB port or a USB-compatible charger.
- The LED light will slowly flash blue to indicate when the M-RIG speaker is charging, ever
- while speaker is turned off.

 When charging is complete, the blue LED light will turn off.
- . Charging time is approximately 3 hours.

Turn It On & Off

- Switch the power button on the back of the speaker from the "OFF" position to the "ON"
- Position to play audio via Bluetooth® or via the AUX cable.

 The M-RIG will emit a tone & the Power Indicator Light on the front of the speaker will turn.
- on to notify the speaker has powered on. To power off, switch the power button from the "ON" position to the "OFF".

Pair & Connect

- . Power on the M-RIG speaker (refer to the "Turn It On" section).
- The Power Indicator Light will begin to quickly flash blue to indicate that it is ready to be paired.
 On your Bluetooth enabled smartphone, tablet or media player, navigate to the Bluetooth settings menu, turn on the Bluetooth feature, and search for new devices.
- . After a few seconds you will see "MERKURY SPB71" listed.
- Tap this model to select it. The speaker will beep, and the LED will remain blue. You are now paired, connected and ready to play?

 If using ALV, connect the included ALV cable to the port on the back of the M-RIG. Then connect the 3.5mm auxillary lack at the other end of the cable to your device's audio lack.

- Play Connect your device to the M-RIG speaker via Bluetooth (see "Pair & Connect with a New Device") or via the AUX input on the back of the speaker.
- Open your favorite music app and press play.
 Ontrol the music, track and volume from your mobile device or the speaker.
 Press the PlayPause button once to answer/end calls. Press either of the volume buttons to
- adjust the volume on the speaker.
- adjust the volume on the speaker.

 Note: Volume on on your device and on the speaker are controlled seperately.

 All audio, including music, games, videos, and notifications will be routed through the speaker.

 NOTE: On-speaker controls only work over fluetooth?, and will not work when your device is connected via an AUX cable.

Reconnect to Bluetooth

- . You only need to pair your Bluetooth device with the M-RIG speaker once,
- With your previously paired device's Bluetooth turned on and in range, power on the speaker.
 The speaker will automatically reconnect to the last Bluetooth device it was connected to,
 If you have a previously paired device that does not auto-reconnect, navigate to
- the Bluetooth settings menu on your device, turn on the Bluetooth feature, and select "MERKURY SPB71" from your list of paired Bluetooth devices.

Important Waterproof/Safety Information


IMPORTANT: DO NOT submerge the M-RIG peaker in water. This device is not intended to function properly after being under water.

- Before using the M-RIG in a wet environment, make sure the silicone cover over the AUX and micro USB input ports on the back of the speaker is fully closed.
- and secured, If water gets into either port, the speaker may not function properly.

 M-RIG is rated IPX4, which means the speaker can be splashed with
 water or left in the rain (but not submerged in water) for approximately 5 minutes.

 If the M-RIG gets wet, it is recommended that you dry the speaker completely before using it again.
 While the M-RIG has a silicone shell for protection, it does NOT mean that the M-RIG is
- while a meaning has a silicone site in protection, it does not in mean that use which is
 drop-proof or indestructible. Speaker may be damaged when dropped from any height.
 All actions done with the M-RIG speaker are done at your own risk. While the speaker is
 weather-proof and has a protective case, it is not a guarantee for complete damage protection.

Speaker Diagram



Troubleshooting

Music is not playing over Bluetooth

Recharge your M-RIG using the included micro USB cable. Make sure your Bluetooth® device has A2DP profile. Check if both devices are paired and connected over

Bluetooth, Restart the M-RIG to reconnect your Bluetooth device

Bluetooth device will not reconnect with the speaker

Navigate to your Bluetooth® settings menu on your Bluetooth device, tap "MERKURY SPB71", and select "Forget". Now follow the steps to pair your device again.

Speaker Specifications: Output Power: 3W (1 channel)

Frequency Response: 150Hz to 15KHz Dimensions (WxHxD): 4.57in x 1.57in x 2.28in

Bluetooth® Information: Bluetooth® Specification: V2.1+EDR Operating Distance: 10 Meters (Class II) System Requirements: Bluetooth-capable device

Battery Information: Built-in Battery: Lithium Input: DC 5V/500mA

Music playing time: Up to 5 Hours* Music playing time: Op to 5 hours

Charging time: 4 hours

*Approximate playback time. Battery life depends on individual use and may be slightly more or less than the time specified.

Additional Connection Sources Additional Connection Sources: Power Source: Built-in rechargeable battery via Micro USB to USB cable AUX Input: 3.5mm









Technical Support:

If you are experiencing problems, do not attempt to fix the product yourself or return it to the store you purchased it from. Please refer to the user's manual or just contact our helpful tech support team

Merkury Innovation 39 Broadway, 15th FI New York NY 10006 support@merkuryinnovations.com

©2016 Merkury Innovations, LLC. • To explore our full selection of products, please visit www.merkuryinnovations.com. The illustrated product and specifications may differ slightly from those supplied. All other trademarks and trade names are those of their respective owners.