MAGNAVOX

Foldable Stereo Headphone with Bluetooth Wireless Technology

FCC ID: 2AHM7-MBH542

OWNER'S MANUAL

PLEASE READ BEFORE OPERATING THIS EQUIPMENT.

MODEL: MBH542

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.


FCC RF Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

LOCATION OF CONTROLS



- 1. ♦►II Button
- 2. ← Micro USB Port (For Charging Only)
- 3. Indicators
- 4. AUX (In) Jack
- 5. Microphone
- 6. +V₩ Button
- 7. ₩v- Button



POWER SOURCE

The unit has a built-in Li-ion rechargeable battery, charge it before first time use or when it is drained as follows:

- Connect the small plug from the supplied USB Connection Cable to the
 Micro USB Port
 on the unit.
- Connect the full size USB Plug from the supplied USB Connection Cable to the USB Port on the Personal Computer or USB Charger (Computer and USB Charger not included).
- When charging, the Red Charging Indicator on the unit will illuminate. When charging is complete, the indicator will turn off.

NOTES:

Your battery will last longer if you following these simple guidelines for caring and storing:

- A. Before first time use, recharge the unit approximately 4 hours until the unit is fully charged.
- B. Charge and store the unit within the temperature range of 5°C 35°C (40°F 95°F).
- C. Do not overcharge (longer than 24 hours). Excessive charging or running the unit until battery fully drains will damage battery. Battery life will be extended if you keep the battery fully charged.
- D. Battery life naturally shortens slowly over time.
- E. The rechargeable battery incorporated in this product is not user replaceable.

OPERATION

For first time use or re-pairing the unit to a new BT Device, pairing it as below:

- Press and holding the Ů►II Button approximately 3 seconds until the Blue & Red indicators is illuminate & blink to power on the unit and enter to pairing mode.
- Power on the external BT Device and enter to BT searching mode. Start pairing following the on screen instructions from the external BT Device. When paired, the Blue LED Indicator will stop blinking and Red LED Indicator will turn off.
- If pairing is complete you may now play music and answer the phone with your external BT Device.

- 4. During playback:
 - The Blue LED Indicator will start blinking.
 - Press the ♥▶II button to pause; press again to resume normal playback.
 - Press and release the +V ★ or ➤ V- buttons to adjust volume level as desired.
 - Press and hold the +V or ➤ V- buttons repeatedly to skip tracks.
- 5. If the unit is paired to a Cell Phone:
 - When a call is incoming during an active music session:
 - ▶ Press the �►II button then speak into the Microphone to answer the call. When your call is complete, press the �►II button to disconnect or end the phone call and resume to music playback.
 - ▶ Or, press and hold the Ů▶II button approximately 1second to decline the incoming phone call then resume to music playback.
 - Quick press the ♥►II button twice to redial the last telephone number your cell phone called.
- When finish listening, press and holding the ♥►II button approximately 3 seconds until
 the Blue Indicator not light to shut off the unit.

Notes:

- When the external BT Device searched the unit, our model number "MBH542" will
- Appear on the display of external BT Device.
- . If while pairing you are asked for a code please try "0000" or "1234".

Normal operation after paired:

- 1. Power on the external BT Device and enter to BT playback mode.
- Press and holding the ♥►II Button approximately 3 seconds to power on the unit. The Blue & Red Indicators will illuminate & blink.
- Wait a few seconds until the unit automatically pair to the external BT Device. When paired, the Blue LED Indicator will stop blinking and Red LED Indicator will turn off.
- If pairing is complete you may now play music and answer the phone with your external BT Device.

AUX (In):

Listen music through the Aux Out; Line Out or Phone Jack from external audio player:

- In power off mode, connect one end of the supplied Audio Connection Cable to the Aux Out; Line Out or Phone Jack on external audio player.
- 2. Connect the other end to AUX (In) Jack on the unit.
- 3. Play the music on the external audio player as usual.
- 4. Use the Volume controls on the external audio player to adjust volume level as desired.

Note: If the Audio Connection Cable is inserted into the AUX (In) Jack, BT will be automatically shut off. Unplug the cable from the jack before use BT.

TROUBLESHOOTING

Check the following before requesting service:

SYMPTOM	POSSIBLE CAUSE	POSSIBLE SOLUTION
Can't power on	Built -in battery drained	Recharge the battery as page 3
No sound or sound weak	Volume of the unit was set to minimum position	Increase the volume by press and release the +V 🕶 Button on the unit
	Volume level of paired /connected device is in low level	Rise the volume level of the paired /connected device
Sound distortion	Volume level too high	Reduce the volume level by press and release the ₩ v- Button on the unit
	Volume level of the paired/ connect eddevice too high	Reduce the volume level of the paired /connected device
BT not functioning	The external BT device had NOT paired to the unit	Pair the external BT device to the unit as page 3-4
	The external BT device too far from the unit	Place the external BT device close to the unit
	Audio Connection Cable was inserted into the AUX (In) Jack	Unplug the Audio Connection Cable from the AUX (In) Jack before use BT

GENERAL SPECIFICATIONS:

Power source: Built-in DC==-3.7V, 450 mAh (1.665WH) rechargeable Li-ion

Battery, recharge by DC === 5V through the Micro USB Port

Impedance of the Earbuds:32Ω per Channel

Audio power: _____15 mW per Channel (Total 30mW)

BT Version: 5.0

BT Operation Distance: Up to 32 feet in open area

PACKAGE INCLUDES:

1 x Owner's Manual

1 x USB Connection Cable (For Charging only)

1 x Audio Connection Cable with 3.5 mm plugs

SPECIFICATIONS AND ACCESSORIES ARE SUBJECT TO CHANGE WITHOUT NOTICE