


BOTTOM VIEW



TOP VIEW



USE LASER ETCHING OR PANTONE® 877 PAT PRINTING. USE THIS DESIGN EXACTLY AS SHOWN, DO NOT MODIFY!



USB-C
Reset
Micro SD Card

Brookstone