


# DT-B660

Waterproof Bluetooth speaker



### Dear customer,

Thank you very much for your choosing the DT-B660 Bluetooth speaker. Please read this manual carefully before use, so that you can proper operation and better use of superior performance products.

### Packaging included:

- 1. DT-B660 Speaker ----- 1pc
- 2. USB line ----- 1pc
- 3. hook ----- 1pc
- 4. User manual ----- 1pc


### Function

- 1. Supported outdoor play, crash resistant and dustproof
- 2. Supported play music in the water
- 3. Adapted to any Bluetooth device
- 4. Supported Hands free

### Specifications

Product Size: 42mm\*42mm\*42mm  
 Weight: 74g  
 Chipset: WS9623  
 Output Power: 3W  
 Bluetooth: 3.0+EDR  
 Protocol: A2DP 1.2+AVRCP 1.3+HFP 1.5+HSP 1.2  
 Charging Current: 200ma  
 Charging Time: 2H  
 Music Play Time: >2.5h  
 Talk Time: >5h  
 Standby Time: 100H

### Function Keys



- 1.ON/OFF
- 2.Play/Pause/Phone
- 3.LED Indicator light
- 4.Vol-/Previous song
- 5.Vol+/Next song

### 1.ON/OFF

Long press "ON/OFF" button 3s, bluetooth speaker boot, LED lights flashing in red and blue, voice prompt "POWER ON" ;Long press "ON/OFF" button 5s, LED lights in red, voice prompt "POWER OFF" , bluetooth speaker shutdown.

### 2.Bluetooth Connection

Boot the Bluetooth speaker and use mobile phones or computers and other equipment search DT-B660 and then connect it. After the connection is successful, the blue light will be brighten and when play music, blue light flashing. The Speaker at the same time can connect two mobile phones which connected before and play music from one of the connected phone. After the speaker starting up it will automatically connect last phone it connected.

### 3.Play Music

When you play music:

- 1. Short press "Play/Pause/Phone" key to pause music, short press second times will play again;
- 2. Short press "Vol-/Previous song" ,the speaker will play the previous song;
- 3. Short press "Vol+/Next song" , the speaker will play the next song;
- 4. Playing music long press "Vol-/Previous song" ,the volume down;
- 5. Playing music long press "Vol+/Next song" ,the volume up and when you hear the prompt "dong" is arriving to the Maximum Volume.

### 4.Hands Free

- 1. When there comes a call, short press "Play/Pause/Phone" key to answer, double press the "Play/Pause/Phone" key to refuse answer.

2. When answering call, short press "Play/Pause/Phone" to hang up .

When the Speaker is working and not in answering call situation, double click the "Play/Pause/Phone" key to redial the last call.

### 5.Battery Charging

Insert the Micro 5P charging cable to the speaker' s USB port and insert another end to the USB port of 5V charger to Charge for the speaker. When the red light lighting it means charging for the speaker and when the blue light lighting, it means finish charging.

### Warm Tips

- 1. To help prolong the speakers use life and your health, please don't listen to music in the long time, high volume environment, in order to avoid damage to your hearing.
- 2. When a fault occurs, please immediately turn off the power switch, unplug the USB plug, prevent speaker and other components damaged.
- 3. The electricity shortage will affect the Bluetooth distance or Bluetooth is easily broken, please charge in time.

### **§ 15.19 Labelling requirements.**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **§ 15.21 Information to user.**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **§ 15.105 Information to the user.**

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **\* RF warning for Portable device:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.