
#### QUICK START GUIDE



# ELITE Bluetooth Headset User Guide

- Volume adjustment button
- Power/ Pairing, pressing 5 seconds to enter pairing model

#### Pair Mobile Phone or Pad

- Put the headset on and push the power button G for 3 seconds until you hear the voice prompt "power on".
- Long-press the call button G until you hear the voice prompt "pairing" as confirmation. The headset enters the pairing mode.
- Then switch on the "Bluetooth" function on your mobile phone or pad and search for Bluetooth headset devices
- Select "ADDASOUND ELITE"
- Once the devices have been paired successfully, there will be the voice prompt "Connected"

Note: If you turn off or exit the "Bluetooth" mode of your mobile phone or pad, the headset will be in "Standby" mode, there will be the voice prompt "Disconnected".

#### Can pair two devices

- If you have paired your headset to a mobile phone or a Pad, directly activate the "Bluetooth" function of a second device and search for headset devices.
- Press the call button G for 2 seconds to turn the headset off
- Long-press the call button G for 5 seconds until you hear "pairing"
- Select "ADDASOUND ELITE".
- After both devices are connected, you can choose alternative use of any one device to receive a call or listen to music.

### Call Control

#### Answer a call

To answer the call please short-press the call button  $\bigcirc$  .

#### End a call

While a call in progress Short-press the call button C to end the current

Press the call button C for 3 seconds to reject the incoming call.

#### Redial the last calling number

To redial the last calling number, double-click the call button G. You will hear "Last number redial" as confirmation. The last calling number will then be automatically called.

#### Adjust the volume

During a call, turn up/down the volume adjustment button by pressing

#### Connect Phone by using voice input method

version) & install. software.

softwares.

#### Audio Play Control

Your headset supports playing audio files on A2DP activated mobile devices.



- 1. Please visit http://addasound.com please download bluesound (phone
- 2. While headset is in connection mode, please start the Bluesound
- \*For the voice input function on Mobile voice-recognition software. required users to use the 3rd party voice recognition assistant

Connect PC by using Voice input method

#### Please visit http://addasound.com please download bluesound (PC version) & install

- Plug the Bluetooth adapter into the computer USB port and run the BlueSound software.
- Put the headset on, enter pairing mode and the "Bluesound software" will search and pair the connection.
- as the default audio device.

#### \*For the voice input function on PC voice-recognition software, required users to use the 3rd party voice recognition assistant softwares. \*Can be used as VOIP for internet phone devices, such as Skype, Lync and others.

- Please Open computer's "Control Panel." and add ADDASOUND ELITE

#### Charge

We recommend use USB cable to charge your headset.

# ////

USB cable to PC or USB wall charger

#### WARNING!

Permanent hearing loss may result from long-term exposure to sound at high volumes .Use as low a volume as possible and avoid prolonged used of the headset at excessive sound pressure levels .Please read the Safety Guidelines below prior to using the headset .

# You Can Reduce the Risk of Hearing Damage by Following These Safety Guidelines During the Use of the Product:

- Turn the volume control to its lowest level, when connecting the headset and then slowly adjust the volume control to a comfortable level.
- Keep the volume at the lowest level possible.
- If increased volume is necessary, adjust the volume control slowly
- 4. If you experience discomfort or ringing in your ears, immediately discontinue using the headset .


Note: With continued use at a high volume, your ears may become accustomed to the sound level ,which may result in permanent damage to your hearing without any noticeable discomfort.

#### SAFETY INFORMATION !

- If you have a pacemaker or other electrical medical devices, you should consult your physician before using the product.
- This package contains small parts that may be hazardous to children Always store the product out of reach of children. The bags themselves or the many small parts they contain may cause choking if ingested.
- Never try to dismantle the product youself ,or push objects of any kind into the product, as this may causes short circuits which could result in a fire or electric shock.
- 4. None of the components can be replaced or repaired by users.Only authorized dealers or serives centers may open the product. If any parts of your product require replacement for any reason, including normal wear and tear or breakage, contact your dealer.
- Avoid exposing your product to rain, mositure or other liquids.
- If the product overheats, has been dropped or damaged or has been dropped in a liquid, discontinue use.
- Never mount or store the product over any airbag deployment area, as serious injury may result when an airbag deploys.
- Dispose of the product according to local standards and regulations.

#### Remember: Always drive safely avoid distractions and follow local laws!

Use of the headset while operating a motor vehicle may be regulated by local laws. Check with your local authorities. Use caution while using your headset when you are engaging in any activity that requires your full attention.





#### BUILT-IN BATTERY CARE:

- Your product is powered by a rechargeable battery. The full performance of a new battery is achieved only after two or three complete charge and discharge cycles.Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime.
- If left unused, a fully charged battery will lose its charge over time.
- Leaving the product in hot or cold places, such as in a closed car in the summer and winter conditions.will reduce the capacity and lifetime of the battery.
- Always try to keep the battery between 0 C and 45 C. A product with a hot or cold battery may not work temporarily, even when the battery is fully charged.

#### BATTERY WARNING!

- "Caution"-The battery used in the product may present a risk of fire or chemical burn if mistreated.Batteries may explode if damaged.
- Only recharge your battery with the provided approved chargers designated for the product.
- 3. Dispose of batteries according to local regulations. Please recycle when possible.
- Do not dispose the battery as household waste or in a fire as it may explode.
- ·Unless otherwise specified in the user manual or quick start quide the battery in your product can not be removed or replaced by the user. Any attempt to do so risky and may result in damage of the product.

For information on batteries please go to www.addasound.com/batteries.

#### CAUTION:

- Do not attempt to charge your product with anything other than the cable. The use of any other types may damage or destroy the product and could be dangerous. Use of other chargers may invalidate any approval or warrant. For availability of approved enhancements, please check with your dealer.
- 2. Charge the product according to the instructions supplied with the product.

#### CERTIFICATION AND SAFETY APPROVALS:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

measures:

-Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that

to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

\*Model:ADDASOUND BTXXXX.(XXXX can be any alphanumeric character or blank for trading purpose, Not involved safety, where XXXX is P100) \*FCC ID: 2AHSP-BTP100

HOW TO CHARGE YOUR ELITE: Simply charge your Elite with ADDASOUND data cable where you

- can find in accessories Recharge the battery only with the data cable designated for the product. Use of another data cable or charger may damage or destroy
- the product and will invalidate the warranty. Charging time: 1.5h

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following.

> DK-9240 Nibe Denmark Email: info@addasound.dk Web: www.addasound.com



## ADDAZOUND

ADDASOUND DENMARK A/S



3 ADDASOUND DENMARK A/S All rights reserved. and Engineered in Denmark

