

addasound-s300-说明书
 折叠尺寸: 100x75mm
 展开尺寸: 800x75mm
 材质: 157g双铜双面印刷-风琴页

Quick Start Guide

addasound.com

Table of Contents

Using the ADDASOUND S300 1

Getting Started - USB Connection 2

Getting Started - Bluetooth Connection - Step 1 3

Getting Started - Bluetooth Connection - Step 2 4

Lights 5

Controls 6

Using the ADDASOUND S300

Best for Use In:

Home • Office • Traveling

Bluetooth / USB

Getting Started - USB Connection

The ADDASOUND S300 can be used with a USB connection to your device or PC. To get started, please follow the steps below:

1. Plug the USB Type C to A Cable into the ADDASOUND S300.

2. Plug the other end of the cable into the USB port of your device or PC.

3. The ADDASOUND S300 will be powered on and ready to use.

Getting Started - Bluetooth Connection - Step 1

When you turn on the ADDASOUND S300, it will enter pairing mode. To get started, please follow the steps below:

1. Turn on the Bluetooth function on your device or PC.

2. Search for the ADDASOUND S300 in the list of available devices.

3. Tap on the ADDASOUND S300 to connect.

Getting Started - Bluetooth Connection - Step 2

Once you have successfully connected to the ADDASOUND S300, you can start using it. To get started, please follow the steps below:

1. Press the Play/Pause button to start playing music.

2. Press the Volume Up/Down buttons to adjust the volume.

3. Press the Power button to turn off the device.

Lights

The ADDASOUND S300 has three different light modes:

- Blue Light:** Default mode when the device is powered on.
- Red Light:** Activated when the device is in pairing mode.
- White Light:** Activated when the device is in charging mode.

Controls

The ADDASOUND S300 has several control buttons:

- Play/Pause:** Starts or pauses music playback.
- Volume Up/Down:** Adjusts the volume level.
- Power:** Turns the device on or off.
- Bluetooth/USB:** Toggles between Bluetooth and USB connection.

Controls

The ADDASOUND S300 has several control buttons:

- Play/Pause:** Starts or pauses music playback.
- Volume Up/Down:** Adjusts the volume level.
- Power:** Turns the device on or off.
- Bluetooth/USB:** Toggles between Bluetooth and USB connection.

Technical Specifications

Model	ADDASOUND S300
Color	Black
Material	ABS Plastic
Weight	157g
Dimensions (Folded)	100x75mm
Dimensions (Expanded)	800x75mm
Power Source	Rechargeable Battery
Charging Time	~2 hours
Usage Time	~4 hours

Frequently Asked Questions

Q: How do I connect the ADDASOUND S300 to my PC?
A: Plug the USB Type C to A Cable into the ADDASOUND S300 and the other end into the USB port of your PC.

Q: How do I connect the ADDASOUND S300 to my smartphone?
A: Turn on Bluetooth on your smartphone and search for the ADDASOUND S300 in the list of available devices.

Frequently Asked Questions

Q: How do I charge the ADDASOUND S300?
A: Plug the USB Type C to A Cable into the ADDASOUND S300 and the other end into the USB port of your device or PC.

Q: How do I turn off the ADDASOUND S300?
A: Press the Power button for 5 seconds.

Customer Support

If you have a question about your ADDASOUND S300, our Customer Service Team will be glad to help.

Contact us at www.addasound.com

Safety and Precautions

• Do not use the device in wet or damp environments.

• Do not use the device near open flames or heat sources.

• Do not use the device with damaged cables or connectors.

• Do not use the device with incompatible accessories.

WARRANTY CARD

Name	
Address	
City	
State	
Zip	
Phone	
Signature	