

## IMPORTANT SAFETY STEPS

When using your equipment, basic safety precautions should always be followed to reduce risk of fire, electric shock, and injury to persons, including the following:

- Read all of the instructions listed here and in the Quick Start Guide before you operate the device. Give particular attention to all safety precautions. Retain the instructions for further reference.
- This device must be installed and use in strict accordance with the Quick Start Guide.
- Comply with all warning and caution statements in the instructions.
- This device should not be used in an environment that is below 14° F (-10° C) and above 104° F (40° C), humidity above 80%.
- Clean Alfie with a soft, dry cloth. Do not use solvents or aggressive cleaning agents. NEVER use detergents, gasoline, glass cleaner, furniture polish, paint thinner, or other household solvents to clean any part of Alfie.
- This device is designed for household usage only, not suitable for commercial and industrial use.
- If there are any malfunctions appeared during the operation of Alfie, switch off the mains and unplug Alfie in safety situations.
- DO NOT use outdoors.
- DO NOT attempt to repair or adjust any electronic or mechanical functions on Alfie. Doing so will void your warranty. The inside of the unit contains no user serviceable parts.
- Charge battery with only enclosed power adaptor.
- Battery must be charged in ambient temp range of 0° to 40° C.

## WARRANTY

The service and device are subject to the terms and conditions found at [www.alfiefetch.com](http://www.alfiefetch.com).

### KENMORE LIMITED WARRANTY

FOR ONE YEAR from the date of sale this product is warranted against defects in material or workmanship when it is correctly connected, operated and maintained according to all supplied instructions.

WITH PROOF OF SALE, return a defective product to the retailer from which it was purchased for free replacement.

This warranty does not cover the batteries, which are expendable parts that can wear out from normal use within the warranty period.

This warranty is void if this product is ever used for other than private household purposes.

**This warranty covers ONLY defects in material and workmanship, and will NOT pay for:**

- Damage to or failure of this product if it is not correctly connected, operated or maintained according to all supplied instructions.
- Damage to or failure of this product resulting from accident, alteration, abuse, misuse or use for other than its intended purpose.
- Damage to or failure of parts or systems resulting from unauthorized modifications made to this product.

### Disclaimer of implied warranties; limitation of remedies

Customer's sole and exclusive remedy under this limited warranty is product replacement as provided herein. Implied warranties, including warranties of merchantability or fitness for a particular purpose, are limited to one year or the shortest period allowed by law. Seller shall not be liable for incidental or consequential damages. Some states and provinces do not allow the exclusion or limitation of incidental or consequential damages, or limitation on the duration of implied warranties of merchantability or fitness, so these exclusions or limitations may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Sears Brands Management Corporation, Hoffman Estates, IL 60179

## FCC STATEMENTS

### FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by tuning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the equipment into an outlet other than the one used for the receiver.
- Consult the dealer or an experienced radio/TV technician for assistance.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

**FCC CAUTION:** Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.