


01

Install ODK Box

- Connect the ODK box to the TV with an HDMI cable.
 See figure for connectors.
- If the router is close to the box, connect it directly using the Ethernet cable you have at home.

 If the Ethernet cable is difficult to connect to, please connect to Wi-Fi /Wireless Internet.
 (See Step 4.)
- 3 Connec power adapter.



02

Change the TV input Source

- Use the TV manufacturer's remote control to change to the corresponding HDMI with the box connected.
- Press the Input or Source button on the TV manufacturer's remote control for adjustment.

<SAMSUNG, LG, VIZIO, etc.>



The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and



03

System Set up

- Language: Please select a language.
- Resolution: Please select the desired resolution. If you don't know, press the OK button at the automatically selected resolution to move on.
- Network Connection: Please select the available network type. For wireless connections, see Step 4. If you are wired, select 'Ethernet' to connect automatically. recommend a wired connection for smooth viewing.







04

Connecting to a Wireless Network (Wi-Fi)

- **Select Wi-Fi**: Please select the network name you use at home.
- Enter password: Please enter a network password. after that press the Skip button. ■
- Wi-Fi name and password
 If you look carefully at your Internet device
 (Modem/Rudder), you can find it as SSID or Wi-Fi
 Name, which is the Wi-Fi Name. The underlined
 part, Web-Key or Password, is the password.
- Installation completed



