


JS-188 Bracelet Bluetooth Speaker



Button Function

“” “Next song”button

short press to get next song, long press to decrease volume ,

“” “Previous song”button

short press to get previous song , long press to increase volume

“” “Multifunction”button

In Bluetooth mode , short press to play/pause music, answer/end/cancel a call. Long press for 2 seconds to reject a call, and to transfer audio between speaker and phone when talking.

Twice press the button to redial the last number.


“ M”Power on/ off button

In Bluetooth mode:

Long press for 2 seconds to turn off the speaker;

Long press for 4 seconds to turn on the speaker(it will acquiescently get into bluetooth mode when the speaker is on).

Buttons and interface description



A.VOL-/Backward button

B.VOL+/Forward button

C.Charging port

D.Power on /off/Mode

E.Multifunction button

LED Indication

Blue/Red LED flashing: Bluetooth searching status, and it will be automatically powered off if not connected in 5 minutes; Bluetooth connected status, and it will be automatically powered off if you do not play music or call in 10 minutes;

Blue LED long light: Bluetooth connected status, if you do not play music or call, the speaker will be in the working status.

Blue LED flashes once every second :Bluetooth talking mode or music mode

Every 30s warning tone: Lower voltage warning

Red LED keep lighting (in power-off mode and charging):In charging

Red LED off(in power off mode and charging):Fully charged

Function description

Definition

A. Bluetooth pairing: the Bluetooth enabled mobile phone, computer, tablet and other devices(Support HSP, A2DP, AVRCP, etc. profile)pair with Bluetooth speaker . The pass code is no

Need when pairing with device with V2.0 version or above.

B. Manually back into connection: when the Bluetooth function of a mobile phone or computer is on(this mobile phone or computer had already connected with the master speaker and still have connection records),power on “JS-188” and click the pairing connection records of the mobile phone or computer to connect the master speaker .

C. Automatically back into connection :when the Bluetooth function of a mobile phone or computer is on (this mobile phone or computer had already connected will the master speaker and still have connection records) power on “JS-188”, it will connect with the last mobile phone or computer automatically .

How to pair one Bluetooth speaker first time .

- A. Long press “ M” for 4 seconds , when blue/red LED flashing and hearing a prompt tone “power on” the Bluetooth speaker will automatically entering pairing mode.
- B. Turn on the Bluetooth function of your mobile phone , searching for “JS-188” and click it to pair, after several seconds ,a prompt tone will inform you connection is success ,your mobile phone will also show “JS-188” is connected.
- C. Turn on the music player software of your mobile phone , press “”button to play music through the speaker.

Tips: You could use “”,“”,“”those buttons to control music play/pause/next song/previous song.

Note: if the music player software is downloaded from other sources which means it's not your original mobile phone software , maybe you can not control the music play/ pause /next song/previous song through the speaker.

- D. Twice press the “”button to redial the last call . Short press “”button to answer or end a call . Hold the “”button to transfer audio between speaker and your phone when talking.

- E. In connected mode , if the speaker is no voice when playing music or could not dial when twice press the“” button , Please turn off the mobile phone

Bluetooth function and re-turn it on ,then find the connection records of “JS-188” manually connect the speaker and mobile phone again , when connection successful ,please play music or dial again.

How to pair with one speaker again

A. Turn on the mobile phone Bluetooth function firstly, and then long press the speaker button “” for 4 seconds , “JS-188” will automatically connected to the last mobile phone after 10 seconds. (this is based on the connection records of your mobile is not deleted)

B. Turn on the music player software of your mobile phone , press “”button to play music through the speaker.

Tips: You could use “”, “”, “”those buttons to control music play/pause/next song/previous song.

Notes: if the music player software is downloaded form other sources which means it's not your original mobile phone software ,maybe you can not control the music play /pause /next song / previous song through the speaker .

C. Quick twice press the “”button to redial the last number . Short press“” between speaker and your phone when talking.Hold the “”button to transfer audio between speaker and your phone when talking.

D. In connected mode , if the speaker is no voice when playing music or could not dial when twice press the “”button, Please turn off the mobile phone Bluetooth function and return it on , then find the connection records of “JS-188”,manually connect the speaker and mobile phone again , when connection is successful ,please play music or dial again .

E . If your mobile phone connection record of “JS-188”has deleted ,then operate again according to 3.2.

Specifications:

Bluetooth Version: 3.0	Dimension:83.59*63.64*28.37 mm
Built-in battery Voltage:3.7V	Battery Capacity:350MAH
Distortion :≤0.5%	Loud Speaker dimension:32mm2W
Net Weight: about 85g (include the watchband)	SNR:≥70Db
Charging Voltage:5V	Charging Time: about 1.5hour Working Time: about 4hours

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.