



**GIEC Y1015  
User Manual**

Thank you for purchasing and using this product!  
For your better experience, please kindly read the instructions.

**Playing music**

1. Play/pause: Touch any earbuds once.
2. Last and Next song : Double-click L earbud is last song,double-click R earbud is next song.
3. Volume: Long press L earbud to decrease volume, long press R earbud to increase volume.
4. Voice assistant: Touch L earbuds 3 times.
- 5.Game mode: Touch R earbuds 3 times.

**Dual calling**

1. Touch once to answer an incoming call.
2. Touch two times reject an incoming call.
3. Touch once to end an active call.

**Low battery warning**

1. When low battery the blue indicator lights on the earbuds will flash and there is a voice prompt;
- 2.The earbuds will automatically power off when they are out of power.

**Warm Tips**

When two earbuds can not play music at the same time or in other unknown states, just click the left and right earphones three times in the pairing state,it will shut down and connect automaticly, or put them into the charging case to reactivate.

( Note: When reconnecting Bluetooth, you need to clear the Bluetooth connection record before reconnecting to the mobile phone. )

**FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.




**Products Specifications**

Model/Bluetooth Name	GIEC Y1015
Material	ABS+PC
Bluetooth Transmission Range	≥ 10 m
Bluetooth Vision	V 5.0
Net Weight	92g
Power Bank Capacity	2000 mAh
Earbuds Battery Capacity	50 mA x 2
Input	5V/1A
Transmission Frequency	( 2402 - 2480 ) MHz

**Product Overview**



**Accessories List**



**HOW TO USE**

The earbuds will be paired automatically once they are turned on. Tap Bluetooth name "GIEC Y1015", on your cellphone, they will be connected.

**\* Warning**

- 1.Please don't use corrosive detergent to clean the product.
- 2.Please keep the product far away from hot.
- 3.Please don't make the product be exposed by the sunlight for a long time.
- 4.Please don't through it in the fire to avoid explosion.
- 5.Please don't attempt to disassemble the product,because it don't including any repair kits.
- 6.Please don't use the product in the rain.
- 7.If you don't use it for a long time,please put it in a dry environment and charge it at least once a month to prolong its service life.
- 8.The dirty surface of the charging contacts may lead to poor contact, please clean it in time.

**Maintenance instructions**

This card is only valid for use in products by the warranty, as detailed below:

- 1.Purchasing the products through legal and formal channels;
- 2.Non-human damage products,including but not limited to private disassembly,improper use,In case of natural disasters,etc.,it is not covered by the warranty;
- 3.Not exceeding product warranty period,It includes and is not limited to the above,The company reserves the right of final interpretation.

**Warranty Card**

Customer Name: \_\_\_\_\_

Contact Number: \_\_\_\_\_

Contact Address: \_\_\_\_\_

Product Model: \_\_\_\_\_

Brief Description of The Problem: \_\_\_\_\_

**Product Certification**

Inspectors: \_\_\_\_\_

Production and Inspection Date: \_\_\_\_\_