


Sectoral Antenna, Continued

Elevation axis
(in mm)

HANT2690V-MB or HANT2690H-MB





Continued on next page

Sectoral Antenna, Continued

Azimuth axis
(in mm)

HANT2690V-MB or **HANT2690H-MB**




Continued on next page

Sectoral Antenna, Continued

Elevation axis
(in mm)

HANT28180V or **HANT28180H** with **MTK-DMA-BX** mounting kit




Continued on next page

Sectoral Antenna, Continued

Azimuth axis
(in mm)

HANT28180V or **HANT28180H** with **MTK-DMA-BX** mounting kit





Continued on next page

Sectoral Antenna, Continued

Elevation axis
(in mm)

HANT28180V-MB or HANT28180H-MB





Continued on next page

Sectoral Antenna, Continued

Azimuth axis
(in mm)


HANT28180V-MB or HANT28180H-MB



Omnidirectional Antenna

Elevation axis
(in mm)

HANT2628360V with **OSDR-360-ANT-MNT-KIT** mounting kit





Continued on next page

Omnidirectional Antenna, Continued

Elevation axis
(in mm)

HANT2628360V with **MTK-DMA-BX** mounting kit




Continued on next page

Omnidirectional Antenna, Continued

Azimuth axis
(in mm)

HANT2628360V with **MTK-DMA-BX** mounting kit





HEADQUARTERS

19.7 km. Markopoulou Ave.
19002 Peania, Athens
Greece
t: +30 2106671000
f: +30 2106671001
sales@intracom-telecom.com



To locate your nearest Intracom
Telecom representative, please visit
www.intracom-telecom.com/worldwide