





front side  
正面

back side  
反面

 <p style="text-align: center;"><b>HAVIT</b></p> <p style="text-align: center;">FREEGO PRO AIR CONDUCTION HEADPHONES <b>USER MANUAL</b></p>	<p><b>Packing list:</b></p>  <p>Headphones*1      Type-C Charging Cable*1</p>  <p>User Manual*1      Certificate of quality*1</p> <p style="text-align: right;">1</p>	<p><b>Production structure</b></p> <ol style="list-style-type: none"> <li>1. Multi-function button(MFB)</li> <li>2. Volume -/Next track</li> <li>3. Volume+/Previous track</li> <li>4. LED indicator</li> <li>5. Charging port</li> <li>6. Speaker</li> </ol>  <p style="text-align: right;">2</p>	<p><b>Power on/Bluetooth connection</b> Follow the steps (Please make sure that your phone is built-in Bluetooth function)</p> <ol style="list-style-type: none"> <li>1. Power on: Long press the MFB for 3 seconds to turn on.The LED indicator flashes alternately with blue and red, the headphones enters the pairing status.</li> <li>2. Activate the Bluetooth function and search for "HAVIT Freego Pro" referring to your phone instructions.Click "HAVIT Freego Pro" to connect.</li> <li>3. The headphones can automatically reconnect with the last device that you had paired. "HAVIT Freego Pro" will disconnect when leave the working range of Bluetooth. The headphones will reconnect automatically if you come back to the range in 3 minutes.</li> </ol> <p><b>Power off</b> Long press the MFB for 5 seconds to turn off.</p> <p><b>Answer the incoming call</b> Press the MFB once to answer incoming call. Tips: Since some mobile phones default to answer calls via their own receiver, please refer to the instructions of your phone and set on your phone.</p> <p style="text-align: right;">3</p>
<p><b>Hang up the current call</b> Press the MFB once to hang up the current call.</p> <p><b>Decline the call</b> Long press the MFB for 2 seconds to reject the incoming call.</p> <p><b>Music control</b></p> <ol style="list-style-type: none"> <li>1. Play/Pause: Press the MFB once</li> <li>2. NEXT: Long press the - for 2 seconds to select the next track</li> <li>3. PREV: Long press the + for 2 seconds to select the previous track</li> <li>4. Volume "-": Press the - once</li> <li>5. Volume "+": Press the + once</li> </ol> <p><b>Activate the voice assistant</b> Triple press the MFB to activate the voice assistant.</p> <p><b>Restore factory settings</b> If the headphones can't pair frequently, please restore the factory settings.Long press the Volume "-" and Volume "+" buttons for 4 seconds at the same time until the indicator flashes blue for 3 times.The headphones will</p> <p style="text-align: right;">4</p>	<p>enter the pairing mode again, search the "HAVIT Freego Pro" bluetooth pairing name with the mobile phone and connect again.</p> <p><b>Charging</b></p> <ol style="list-style-type: none"> <li>1. As product is built-in non-removable and rechargeable battery, please use the provided charging cable to charge. When charging, the headphones will automatically power off.</li> <li>2. Fully charge the product before the first use. It takes about 2H to charge for the subsequent use.</li> <li>3. The LED indicator is solid red when charging.The indicator turns solid blue when the battery is fully charged.</li> </ol> <p><b>Notes:</b></p> <ol style="list-style-type: none"> <li>a. Please choose the charger that is certified by the regular manufacturer.</li> <li>b. The battery performance may decrease as repeating charging and using the product. It's a normal phenomenon for all rechargeable batteries.</li> </ol> <p><b>Specifications:</b> Wireless Version: V5.3 Wireless Working Range: 10M (without</p> <p style="text-align: right;">5</p>	<p>obstacles) Battery: 110mAh Play Time: 9h Charging Time: about 2h Speaker Size: Φ15mm Speaker Frequency: 20hz~20khz Input Voltage/Current: 5V/110mA</p> <p><b>Note:</b> Up to 9 hours playtime depends on playback device,contents and usage.</p> <p><b>Warnings:</b></p> <ol style="list-style-type: none"> <li>1. Please follow the instruction to operate.</li> <li>2. Please keep the headphones from heat source, such as radiators, hot air regulators, stoves, or other heat generating instruments. As it is not anti-high temperature.</li> <li>3. Don't jam the ports of the headset, such as charger port, LED port and microphone etc..</li> <li>4. In order to protect your hearing and extend the product speaker service life, it is not recommended to adjust the volume to the maximum level for a long time.</li> <li>5. Whatever reasons damage the headset, please feel free to contact our after-sales staff in time rather than repair by yourself.</li> </ol> <p style="text-align: right;">6</p>	<p>Otherwise, you will accept without after-sales service.</p> <p><b>FCC Requirement</b> Any changes or modifications not expressly approved by the party responsible for compliance could void the user 's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help.</p> <p style="text-align: right;">7</p>

材质: 128g双铜纸 双面印刷, 风琴折

印刷色号(Printing color number): C:0 M:0 Y:0 K:70

尺寸(Size): 55 X 77 mm