







front side
正面

back side
反面

| | | | | | |
|---|---|--|--|---|---|
| <p style="text-align: center;">HAVIT</p>  <p style="text-align: center;">TW955 TRUE WIRELESS STEREO EARBUDS</p> <p style="text-align: center;">PRODUCT MANUAL</p> | <p>Product and accessories</p>  <p>Earbuds *2 Charging case *1</p> <p>2 pairs of ear cap (L/S size, M equipped) Charging cable *1</p>  <p>User manual *1 Certificate of quality *1</p> <p style="text-align: right;">1</p> | <p>Description of product structure</p>  <p>1.Power LED indicators 2.Multi-function button (MFB) 3.LED indicator 4.Charging port</p> <p>Wearing method</p> <p>Gently insert the earbuds into the ear then adjust the appropriate comfort.</p>  <p style="text-align: right;">2</p> | <p>Basic function</p> <p>01 Power on,Bluetooth connection ---Follow the steps (Please confirm that your phone is built-in Bluetooth function) 1. Power on a)Method 1: Remove earbuds from the charging case. Method 2: If earbuds are power off outside the case, long press the MFB button for 3 seconds on both sides to turn them on. When one earbud indicator starts flashing alternately with orange and white and the other earbud indicator is turn off.And the product is ready for use. 2. Turn on Bluetooth on your device and select "TW955" referring to your phone instructions. 3. Pairing mode can just last 180 seconds, if you miss the pairing time, you need to restart the device and operate follow the procedural steps mentioned above.</p> <p>*Note: a). TW955 remembers previously connected devices. When turned on, earbuds attempts</p> <p style="text-align: right;">3</p> | <p>to reconnect to previously connected devices. b). TW955 will lose the connection when deviate the working range of Bluetooth. The earbuds will reconnect automatically if you come back to the range in 3 minutes.</p> <p>02 Power off Method 1: Put the earbuds into the charging case, they will automatically shut off. Method 2: Long press left/right MFB for 5 seconds to turn them off.</p> <p>03 Answering incoming calls Short press left or right MFB to answer incoming calls.</p> <p>04 End the call Long press left or right MFB for 2s to end the current call.</p> <p>05 Decline incoming calls Long press left or right MFB for 2s to reject a call.</p> <p>06 One key for voice assistant Double press the left or right MFB to activate</p> <p style="text-align: right;">4</p> | <p>voice assistant.</p> <p>07 Music playing 1. Play/Pause: short press the left or right MFB once; 2. Long press the left MFB for 2s to switch to the previous song 3. Long press the right MFB for 2s to switch to the next song</p> <p>08 Mono mode (take out any earbuds as a unilateral bluetooth earbud) (note: single channel mode only needs to remove one of earbuds from the charging box; If two earbuds are removed before connection, the earbud will be used in TWS mode by default, and the TWS connection will be automatically realized.) 1.Take out a earbud from charging case,the earbud automatically turn on and reconnect to previously connected devices. 2.Switch from one earbud to the other when playing music, taking out the other earbud from the charging case and these two earbuds will connected automatically. Both earbuds will play music automatically and then put the earbud which do not need</p> <p style="text-align: right;">5</p> |
| <p>anymore into the charging case and the switching process completes. (note:Call mode is applicable) 3.Please refer to the TWS mode for more functions.</p> <p>09 Restore factory settings If the earbuds cannot pair or disconnect frequently, please restore the factory settings. Take out the left earbud from the charging case and click the MFB button 7 times quickly, then put into the charging case. Repeat the same operation for the right earbud. Then take out both earbuds when one earbud indicator starts flashing alternately with white and orange and the other earbud indicator is turn off, the reset completed.</p> <p>10 Charging -Case Charge the case using the USB cable connected to a computer or wall charger. The indicator in the charging case flashes orange when charging and turns to be steady orange when fully charged. Charging</p> <p style="text-align: right;">6</p> | <p>time is approximately 2 hours.</p> <p>-Earbuds Put the earbuds back into the charging case for charging. While charging, the earbuds white light flash slowly. After full charge, the white light turn off.</p> <p>Specification Bluetooth Version : V5.1 Earbud Battery: 40mAh*2 Charging case battery: 300mAh Play time: 6-7H (in medium vol.) Talk time: 5H (in medium vol.) Charging time: about 2H Battery display indicator Type-C port</p> <p style="text-align: right;">7</p> | <p>Warnings</p> <ol style="list-style-type: none"> Please charge the earbuds with input power below 5V/1A, in order to protect the battery. Please store or use the earbuds in a normal temperature environment. Please do not use this product near the water. Do not immerse this product in any liquid or splash any liquid on this product. Please keep the earbuds from heat source, such as radiators, hot air regulators, stoves, or other heat generating instruments. As it is not anti high temperature. Don't jam the ports of the earbuds, such as charger port, LED port and microphone etc.. In order to protect your hearing and extend the speaker service life, it is not recommended to adjust the volume to the maximum level for a long time. Whatever reasons damage the earbuds, please feel free to contact our after-sales staff in time rather than repair by yourself. Otherwise, you will accept without after-sales service. <p style="text-align: right;">8</p> | <p>FCC Caution: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning</p> | <p>the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p>  <p style="text-align: right;">www.havit.hk</p> | |

材质 : 128g双铜纸过哑胶双面印刷, 风琴折
 Material : 128g double copper paper Matt finish + 2 sides printing Accordion fold
 印刷色号(Printing color number): C:0 M:0 Y:0 K:70
 尺寸(Size): 55 X 77 mm