

V8S说明书

size: 105\*140mm

材质:128g铜版纸,正反印刷





Micro USB Slot

Volume Down/Next

## For cell phone pairing: 1. Fully charge ANC Bluetooth headphone before pairing. means low battery. It takes about two hours to fully charge. release it untill Red & Blue LED blink alternately. Sattings Bluetooth Novi elseoverable as "Like (Diagram 2) Use headphone Use your Headphone: Play/pause music In play list press www for previous music, press value for next music. Volume+/-control ong press ₩v+ to increase volume, long press v→ to decrease volume. Clean Headphone Answer/disconnect phone call When call income phone ring will be heard from headphone, press power on/off button to answer. After phone call finished press again to disconnect; if you don't want to answer the incoming call, long

power on/off button to disconnect.

# Charge headphone: Connect charger plug to Micro USB port, button font change to red color means charging and change to invisible means fully charged. Red color flash per 5 seconds and alert sound rings per 30 seconds 3. Power on headphone: long press power on button for 5 seconds, button font flash between blue and red color, 4.Keep bluetooth headphone and cell phone in one meter range, turn on Bluetooth mode on cell phone and start 5. Pairing the headphone with bluetooth devices: enter pairing mode, press and hold button for 6 seconds and

## Check guide and parameter Malfunction and solution Cannot search device: Check if headphone is in pairing mode. **Audio discontinued**: Check if device is in valid range, check if there is obstacle between headphone and device. Check if battery low. Cannot power on: Check if battery low, or battery installed properly. Technical indicators

Туре	wireless ANC bluetooth headphone	
Channels	two channel stereo	
Impedance	32 Ω	
Battery	400mA Li-polymer	
Sensitivity	110±3dB	
BT version	V4.1	
Frequency range	2.4GHz-2.480GHZ	
Working time	Approximately 12hours	
Connect interface	Micro USB,3.5mm audio jack	
Drive diameter	40mm	
Weight	205g	
Accessories	Manual, Micro USB cable, 3.5mm audio cable	

### Precaution

Keep dry headphone under rain or wet air, don't use hair dryer or micro oven to dry headphone.

Battery safe Due to built-in battery don't heat, pierce and damage headphone, or put into fire Don't expose headphone under direct sunshine for long time, otherwise battery will be melted or damaged. Battery is replaceable if needed please contact headphone provider.

Cable safe at where cable and device connected.

on't tied cable, don't pull cable toughly. Keep away from children and pet to avoid bite or swallow. Don't put cable near hot source, when disconnect cable hold plug and pull out, don't hold cable and pull out. Listen safe

Discard battery and electronics

Don't cast aside battery along with your life garbage, meanwhile you have duty to collect discard battery and take to proper collect station. Due to harmful material in battery, separate collection and recycle is helpful to protect nature resources to benefit human health and environment.

# Headphone size

## **FCC** Statement


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates. uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception , which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio / TV technician for help.





引言






## 检查指引与参数 故障与解决方案 搜索不到设备检查耳机是否进入配对模式。 断音 连接距离是否超出有效距离,设备与耳机之间是否有障碍物,电池电量是否充足。 不开机 检查电池是否有电。 技术指标

类型	主动降噪蓝牙头戴式耳机
功能	主动降噪&蓝牙
阻抗	32 欧姆
电池	400mHA聚合物锂电池
灵敏度	110±3dB
蓝牙版本	V4.1
频率范围	2.4GHz-2.480GHz
使用时间	约20小时
连接端口	Micro USB 充电口, 3.5mm连接线输入口
驱动单元直径	40MM
重量	约205克
附属品	耳机使用说明书,Micro USB充电线,3.5mm音频线

## 不要将耳机暴露在雨中或潮湿的空气中,请勿用吹风机或微波炉来干燥设备。 将音量设置为在可清晰听到即可,不要再提高音量。您的耳朵具有在一定时间后适应的能力,这样高音量听起来就像正常音量一样,但高音量仍可能损坏您的听力。 本设备包含内置电池,对该电池使用不要加热、刺破、毁坏该产品或将该产品投入火中。不要将耳机长时间置于阳光直射下,否则可能导致熔化或电池损坏。本设备电池可更换,更换电池请联系产品提供商。

避免损坏电源线和3.5MM连接线,防止人员踩踏或被挤压、严重弯曲,尤其是电源线与设备的链接处。 不要将电源线打结,也不要猛拉和粗暴使用。电源线远离儿童和宠物,不要让他们啃咬或咀嚼电源线。 不要将电源线暴露在热源处,在断开电源线时,请握住插头拔出,不要通过拉扯电源线拔出。 ● 废旧电池和电子电气设备的处理 产品或其电池废旧后不能随生活垃圾一起丢弃。同时,您有义务将其送交适当的收集点,以便回收利用电池和电气设备。由于电池和电气设备中可能存在有害物质,因而分类收集和回收利用有助于保护自然资源,防止由于处理不当而对人类健康和环境造成潜在的负面后果。

• 线材安全



耳机尺寸