

TE card/USB Mode

- Safety Precautions
- or serious injury if swallowed.

- manufacturer's warranty.

1. Power on the speaker to AUX mode. 2 Insert the TE card or USB disk into the slot property music files will automatically start to play. 3. Use function button on the speaker for PLAY/PAUSE/

 Keep your device and all accessories out of the reach of children or animals. Small parts may cause choking

 Avoid exposing your device to very cold or very hot temperatures (below 0 °C or above 45 °C).

· Extreme temperatures can cause the deformation of the device and reduce the charging capacity and life of

· Do not allow your device to get wet-liquids can cause serious damage. Do not handle your device with wet hands. Water damage to your device can void your

FCC Caution

This device complies with part 15 of the ECC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference: (2) this device must accept any interference received. including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful

interference to radio or television recention which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected -Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



Made in china