

Lovehoney®
the sexual happiness people™

Discover a happier you

We are the sexual happiness people and we're proud to make a fun, fulfilling sex life available to everyone.

Enjoying a fresh, vibrant, playful sex life is a great way to discover greater personal happiness in both mind and body. It's more fun than going to the gym, less fattening than chocolate and more exciting than skydiving.

With Lovehoney you can play more, explore more, enjoy more... and discover a happier you.

Find out more online at www.lovehoney.co.uk

- FR Mini vibromasseur télécommandé - 10 modes
- DE Mini-Vibrator mit Fernbedienung - 10 Funktionen
- ES Mini vibrador con mando a distancia - 10 funciones

Lovehoney®
the sexual happiness people™

Get a buzz on

Explore a fresh approach to foreplay with the Secret Surprise bullet, whose remote operated multispeed let your lover tease you from afar. Take pleasure to its apex as the spectacular vibrations super-charge sensations and send arousal soaring.



6 speeds



10 patterns



waterproof



3 x LR44 batteries
1 x CR2032 battery

Lovehoney®




secret surprise
remote control bullet vibrator

Lovehoney®
the sexual happiness people™

How to use your remote control bullet vibrator

- Slide off the back of the remote and remove the paper disc. Replace the remote cover.
- Twist off the base of the bullet and remove the paper disc. Push and twist the base to reattach.
- Press and hold the button on the bullet for 2 seconds to put it into standby mode.
- When the bullet is on standby, it can be controlled by the remote. Press the power button on the remote to begin the vibrations. Continue pressing to cycle through the 10 patterns. To increase speed press the "+" button, to decrease press the "-" button.
- To turn off, press and hold the power button for 2 seconds.
- To use the bullet without the remote, press the button on the base for 2 seconds to begin vibrations. Continue to press to cycle through the vibration patterns. Hold the button for 2 seconds to turn off.
- This toy has a hibernation function. If there is no activity for 30 minutes the bullet will shut down and switch itself off to save battery power. You will need to press the button on the bullet again to turn it back on.
- Use with water-based lubricant to enjoy your toy at its best.
- Clean after use with sex toy cleaner and leave to dry until next time.
- If you're not going to use your toy for a few days, remove the batteries.



V11708

Remote Control Bullet LH-70464



5 060493 008568 >



RoHS



Requires: 3 x LR44 batteries, 6 included, and 1 x CR2032 battery, included.

Remote and bullet made from PU coated ABS plastic. Does not contain latex or phthalates. Bullet is waterproof. Remote is splashproof. Water-based lubricant is recommended. Sold as an adult novelty. Discontinue use if irritation or discomfort occurs. To avoid injury or aggravation of pre-existing conditions, do not use on swollen or inflamed areas or skin lacerations. No medical claims are warranted or implied by the use of this product. The shape and appearance of the product inside this package are a trademark and trade dress of Lovehoney Group Ltd. Copyright © 2018.

Lovehoney® is a registered trademark of Lovehoney Group Ltd. Made in China for Lovehoney Group Ltd, Bath, BA1 3EN, UK.

FCC Compliance Statement: This device complies with Part 15 of the FCC rules. Operation is subjected to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.