WIRELESS CHARGING PAD



HKWP1010-10QFC USER MANUAL

before using this product.

on right for proper placement.

and turn Green when full charging.

The LED light will turn Blue when charging

If the Charger Pad needs cleaning, wipe it using a soft, dry cloth. Never use any abrasive cleaning agents. Periodically, wipe off any accumulated dust.

SPECIFICATIONS

Wireless Charging Pad: Input: 5V-2A/9V-1.67A **Output:** 5V-1A/9V-1.1A Transmission Distance: ≤8mm **Conversion Rate:** ≥73% Product Dimensions: 98 x 98 x 6.5mm

CHARGING PAD: No Scratching or Slipping

CHARGE MULTIPLE DEVICES: Works with All Qi-Enabled Devices

IMPORTANT SAFETY INSTRUCTIONS

Failure to follow the safety instructions can lead to fire, electrical shock, personal injury or property damage or damage to this product. Make sure to read the entire manual.

- Do not use this unit for anything other than its intended use.
- Keep the unit away from heat source and direct sunlight.
- Do not expose the unit to extremely high or low temperatures.
- Use the product in a location with a temperature of $32^{\circ}F(0^{\circ}C) 95^{\circ}F(35^{\circ}C)$.
- Do not let the unit come in contact with water or any other liquid. If the unit becomes wet, immediately unplug it from the power source.
- Do not handle the unit, USB cord or wall charger with wet hands.
- Do not let the dust or other things accumulate on the product and the wall charger. • Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- If you have an electrical device, such as a pacemaker, consult a physician Charging time will depend on the • Do not place magnetic cards or similar items near this product. type of device. Your device will • Use the specified power source and voltage. display the charging progress. • Do not use a voltage converter/travel adapter. You may remove your device • Make sure the wall charger is inserted all the way into the electrical outlet. from the Charger Pad at any When not in use, unplug the wall charger. time during the charging process. • Place the unit on a sturdy and flat surface during charging. • Keep the unit out of reach of children. CHARGING YOUR DEVICE 4 When charging is complete, Make sure your device is Qi-compatible. remove the device from the Charging Pad. If the case is metal, remove prior to charging. If you are having issues charging, remove your case. ECC NOTICE (for USA) This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference Plug one end of the charging cable (2) This device must accept any interference received, including interference that may cause undesired into the wall charger and the other end operation into the Charger Pad. Place it on a sturdy The manufacturer is not responsible for any radio or tv interference caused by unauthorized modifica-tions or change to this equipment. Such modifications or change could void the user's authority to and flat surface, such as desk or table. operate the equipment This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause 2 Place the Qi-compatible device directly harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to onto the Charger Pad. Refer to diagrams
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.

correct the interference by one or more of the following measures:

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.