


# FOLD INWARD



# (Back Cover)



# (Front Cover)



## Compliance Information

### FCC Information

This device complies with Part 15 of the FCC Rules.

**Caution:** Any changes or modifications not expressly approved by the party responsible for compliance approved could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Radiation Exposure Information

This device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

### WARNING Li-ion Battery Inside

This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).



### Rating Label Definitions

--- Direct current symbol.



This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.



This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.



This symbol signifies that this is a wireless device powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and used under license.

## Warranty Information

90-day Limited Warranty  
Territory: United States/Canada

### LIMITED WARRANTY TO ORIGINAL CONSUMER

This product (including any accessories included in the original packaging) as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

### To obtain warranty service:

- Visit our website at [www.southern telecom.com](http://www.southern telecom.com)
- Click on **Product Support**
- Select the **Brand** of your device
- Select **Service Request** and fill out the form to begin your inquiry

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

### Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTEE GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT, EXCEPT AS STATED HEREIN. NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

2019 Sharper Image® name and logo are registered trademarks. Manufactured, marketed, and distributed under license by Southern Telecom, Inc. Brooklyn, NY 11220. © Sharper Image. All Rights Reserved.

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

TOMORROW'S. MORROW.™

SHARPER IMAGE®



Bluetooth speaker



Instruction Manual

SBT1049

Printed in China  
Designed in USA  
v1.08-2019

## Before You Begin...

### CAUTION

To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, adapters, accessories, and supplies.


- **READ THIS MANUAL AND SAVE FOR FUTURE REFERENCE**
- **THIS DEVICE IS NOT A TOY**, do NOT allow children or pets to use or play with this device.
- Do not disassemble, modify, or repair the device.
- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- Do not submerge in water.
- Low power may cause poor Bluetooth connection or sound distortion.
- Do not overcharge battery.
- Do not allow the power port or the connectors of the supplied power adapter to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.

### Questions & Customer Support



For any issues concerning this product, please visit our website at [SouthernTelecom.com](http://SouthernTelecom.com) and click on **Product Support**.

### What You Get

- SBT1049 - Wireless Speaker (x1)
- Charging Cable (x1)
- Instruction Manual (x1)



## Location of Controls



## Getting Started

### Charging the Speaker

Insert the small connector of the supplied USB charging cable into the USB charging port on the back of the speaker's control panel. Insert the large connector into the USB port on a computer, a USB charging device, or a **5V/1A USB adapter** (not included) and plug into an electrical outlet.

The  LED indicator will **turn RED** while charging and turn off when fully charged.

### Powering ON/OFF

- Flip the **[Power]** switch to the ON position to power the speaker on. A tone will be heard, the lights will turn on, and the speaker will enter Bluetooth pairing mode.
- Flip the **[Power]** switch to the OFF position to power the speaker off.

### Adjusting Volume

- Use the volume knob to adjust speaker volume.

### Changing Input Modes

- Press the **[M]** button to switch between Bluetooth and AUX mode.
- The speaker will automatically switch to AUX mode when a 3.5 mm cable is inserted into the 3.5 mm AUX input.
- An AUX cable must be plugged in to switch to AUX mode.

### Using the Lights

- Press the  button on the speaker to cycle through light modes.

### Bluetooth Pairing

1. Power the speaker ON. A tone will be heard and the BT/AUX LED indicator will **quickly flash BLUE**.
2. Set your mobile device to search for Bluetooth devices. When it appears, select **SBT1049** from the list of found devices.
3. After a successful pairing, a tone will be heard and the BT/AUX LED indicator will **slowly flash BLUE**.

- Press the  button to disable Bluetooth. When disconnected, the speaker will enter Bluetooth pairing mode.

### Playing Music

Once paired with Bluetooth, audio playback and volume can be adjusted via the controls below or on your paired media-playing device.

- Press the  button to pause/resume music playback.
- Press the  and  buttons to skip tracks.

### Using with a Wired Device

Insert one connector of a 3.5 mm audio cable (not included) into the 3.5 mm input jack. Insert the other connector into the headphone jack or audio output jack of your media playback device.

The BT/AUX LED indicator will **turn solid RED** while in use.

While connected via the 3.5 mm input jack, playback and volume can be adjusted with the controls on your connected device.

### Using the Microphones

Plug the 1/4" connector of a wired microphone (not included) into one of the MIC input ports on the back of the speaker. Switch the mic ON.

- Microphone volume is controlled with the volume knob.

**Note:** In order to avoid loud feedback, keep the microphones behind the speaker and pointed away from the speaker, and switch them off when not in use.