

Packing List

Driving videos Please confirm that the camera is intact ar after opening the package.

1) Camera x1 2) USB power cord x1 3) Anti-static film x1 4) User manual x1 5) Installation tool x1 6) Car power adapter x1

Functions Description This part introduces all functions exhaustively. Please read it carefully ar check it when problem happens.

1) Download APP

Way 1: Scan QR code below by your cellphone to download. Way 2: Search "360 Dash Cam" in App stores or Google player and



2)Connect camera

3 Open 360 Dash Camera APP and click "add.

You can see your videos and photos in the APP.

D Click "Setting" on the panel and open "WiFi Info".



eft side of the device to turn it on. fter start-up, the system will begin recording videos automatically. different display interfaces: Video, Time and Settings. device through the Wi-Fi Hot Spot. After establishing a connection, the

4) Emergency videos



emergency video recording mode. Each emergency video takes one minute. After completion, the photo album can be opened through Settings to view the emergency videos.

5) Parking monitoring



①Press "Setting" button and select "Parking Mode". Dash cam will enter

loop recording mode.

automatically. If there is a video taken while parking, the camera will notify you to check new video and see if there is any damage of your car  $\ensuremath{\textcircled{4}}$  If a car is equipped with an uninterruptible power supply, the recorder will automatically enter parking monitoring mode after the car is stationary the continuous vibration and will automatically revert back to the video

Note: Constant power supply function will consume the power of your vehicle's battery. Use it wisely to avoid dead battery issue.

parking mode after engine is turned off.
② When a car is externally hit, the device will automatically start the vide

6) Display interface

①Default display interface: recorder display or clock display can be chosen for the default open interface. ②Video recording: sound can be turned on or off when playing the recorded ③Emergency recording sensitivity:change the sensitivity of triggering emergency recording.

Tap the "Settings" button to set the recorder.

®Format: Format Micro SD Card. Multiple copies of the documents on the

Precautions For Use Of The Recorder

• This product is a safe driving assistant (vehicle driving recorder) product. Ou

 Parking Monitoring: parking monitoring can be set to turn on or off.
 Download App: Scan QR code and fast-set dash cam. 6 Date/time: set system time manually. TWi-Fi: Wi-Fi hotspot won't be established when Wi-Fi is turned off.

(9) Factory reset: factory reset won't delete videos saved on the Micro SD @About dash cam: Present firmware version, Wi-Fi name and SN number will be shown under this item.

icro SD Card are highly recommended before formatting.

8) Diagram of sticking position and power line

installation for anti-static film

company is not liable for data destruction due to long-term use.

• Do not install or operate this product while the vehicle is running.

• Do not connect the uninterruptible power supply by yourself, otherwise it may cause automobile or product failure. Please consult with the professionals for

his product is directly connected to the vehicle power supply system, do not use product for a long time when the engine is not started, otherwise it will lead to loss of the vehicle battery.

is device may interfere with the function of the medical device that is not

vice can shield external radio frequency energy, please consult the doctor or the anufacturer of the medical device. Do not subject this product to strong shock or vibration, so as not to damage the product, and result in malfunction or unusable conditions.

Please use it to the extent permitted by law.

s not guarantee that all the accident images can be recorded. A minor crash

nnot activate the crash sensor, so the image may not be recorded in the

Please stop using this product before cleaning and maintenance.

Do not use chemical solvents or cleaning agents to clean this product.

Do not disassemble or modify this product by yourself.

The ambient temperature range for normal use of this device is -20°C to 65°C, beyond which the product may malfunction, ignite or explode.

 When the product is charging, the power outlet should be installed near the When the charging completes or the product is not charging, please disconr
the charger from this product and unplug the charger from the power outlet.

Precautions For Use Of The Charger

If the charger plug or power line is damaged, do not continue to use it in case of

Precautions For Use Of The Battery

oo not use any damaged charger or battery.

If the battery is too high, deformed, discolored, bulged, leaked and has other normal phenomena in the processof use, charging or storage, please stop using

Trouble Shooting

• Do not dismantle or modify the built-in battery by yourself, so as not to damage Do not throw the battery into the fire or place it in

Oo not use the battery for other purposes.

— 09 —

Note: A small patch of electronic components for special purposes is marked with ""X"" in the table (such as high voltage resistors, ceramic resistors, diodes) . Their quantity of Pb may exceed 0.1% due to high-per mance consideration. As the core in the screws and in the data cabl made of high-quality alloy, Pb may also exceed 0.1%.All of these items Attentions And After-Sales Service I. Introduction and declaration of after-sales service

• Thanks for choosing 360 dash cam. Please use accessories provide

— 11 —

II. Service policies within the warranty period of

the after-sales service center for product returning, replacing or

Contact Us Website: www.360smartai.com

che.360.cn/en **Email:** support@360smartai.com **Facebook:** @360smartAl

6. damages arising from force majeure.

Name Performance fault

Charger & Abnormal status or operation, or failure in normal charger cable charging of designated charger

III. Policies for paid repair of 360 dash cam

warranty. 360 Company or its authorized service center will provide repair at reasonable prices;

1. the period of "three guarantees" expires.

Substances

Warranty Card 1) User Information

2) Product Information

3) Repair Record

Name \_\_\_\_\_ Tel \_\_\_\_

E-mail \_\_\_\_\_ Post Code \_\_\_\_

Service Fault Service Signature Record infomaiton date Signature

— 15 —

This device complies with Part 15 of the FCC Rules. Operation subject to the following two conditions: (1) This device may nuharmful interference, and (2) this device must accept any interference.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter. For product available in the USA/Canada market, only channel 1~ can be operated. Selection of other channels is not possible.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator &

**÷**360

G300英文版说明书 尺寸:88x140mm