

MAGNAVOX

STEREO HEADPHONE with Bluetooth® Wireless Technology

OWNER'S MANUAL

PLEASE READ BEFORE OPERATING THIS EQUIPMENT.

MODEL: MBH531

FCC INFORMATION:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide residential protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on the circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC NOTICE:

To assure continued compliance, follow the attached installation instructions and use only shielded cables when connecting to other devices. Modifications not authorized by the manufacturer may void user's authority to operate this device.



This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2)

this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Location of Controls



1. ON/OFF (Power On-Off/Back On-Off) Button
2. - (Skip Backward/Volume Down) Button
3. M (Play/Pause) Button
4. + (Skip Forward/Volume Up) Button
5. M (Mode Selection) Button
6. Indicators
7. Micro SD Card Slot
8. Micro USB Port (For Charging only)
9. AUX (In) Jack
10. Microphone

POWER SOURCE

Battery Recharging:

The unit has a built-in Li-ion rechargeable battery. recharge it before first time use or when it is drained as below:

1. Connect the small plug from the supplied USB Connection Cable to the Micro USB Port on the left of unit.
2. Connect the full size USB plug from the supplied USB Connection Cable to the USB Port on the Personal Computer or USB Charger (computer and USB Charger not included).
3. During charging, the Red LED Indicator on the left of unit will illuminate. When finished charging, it will turned off.

NOTES:

- Your battery will last longer if you following these simple guidelines for caring and storing.
- A. Before first time use, recharge the unit approximately 3 hours until the unit was fully recharged.
- B. Recharging and store unit within the temperature range of 5°C-35°C (40°F-95°F).
- C. Do not overcharge (longer than 24 hours). Excessive charging or running the unit until battery goes empty will damage batter. Battery life will be extended if you keep the battery fully charge.
- D. Battery life naturally shortens slowly over time.
- E. The rechargeable battery incorporated in this product is not user replaceable.

OPERATION

BT(Bluetooth) Playback Mode:

BT Pairing:

1. Press and hold the ON/OFF Button on the unit approximately 2 seconds to power on the unit. You will hear an audible prompt say "Bluetooth Mode" and the Red & Blue LED Indicators on the unit will illuminate and blink.
2. Power on the external BT Device and enter to BT searching mode. Start pairing following the on screen instructions from the external BT Device. When paired, you will hear an audible prompt say "Connected" and the Blue LED Indicator will stop blinking and Red LED Indicator will turn off.
3. Plays the music in the paired BT Device as usual. The Blue LED Indicator will start blinking.
4. During playback:
 - Press the M Button to pause;press again to resume normal playback.
 - Press and hold the + or - Buttons to adjust volume level as desire.
 - Press and release the + or - Buttons repeatedly to skip tracks.

Note:

If Micro SD (TF) Card is inserted into the Micro SD (TF) Card slot.Press the M Button to switch to Micro USB (TF) Card playback mode; press again resume to BT playback mode.

5. If the unit is paired to a Cell Phone and a call is incoming during an active music session. Press the ON/OFF Button then speak to the microphone to answer the call. When your call is complete, press the ON/OFF Button to disconnect or end the call and resume to music playback. Or, press and hold the ON/OFF Button approximately 2 seconds to decline the phone.
6. To shut off the unit, press and hold the ON/OFF Button on the unit until hearing an audible prompt say "Power Off".

Notes:

- When the external BT Device searched the unit, our model number "MBH531" Will appear on the display of external BT Device.
- If while pairing you are asked for a code please try "0000" or "1234".

Normal operation after paired:

1. Power on the external BT Device and enter to BT mode.
2. Press and hold the ON/OFF Button on the unit approximately 2 seconds to power on the unit. You will hear an audible prompt say "Bluetooth Mode" and the Red & Blue LED Indicators on the unit will illuminate and blink.
3. Wait a few seconds until you are hear an audible prompt say "Connected" and the Blue LED Indicator is turn off.
4. Plays the music in the paired BT Device as usual. The Blue LED Indicator will start blinking.

Micro SD (TF) Card Playback Mode:

Listen music from Micro SD (TF) Card:

1. In power off mode, insert the Micro SD (TF) Card into the Micro SD Card Slot as the polarity marking beside the slot as illustrated below:



Note:

2. Press and hold the M Button on the unit approximately 2 seconds to power on the unit. You will hear an audible prompt say "TF Mode" and the Blue LED Indicators on the unit will illuminate and blink. The unit will automatically start to play the music on the card.
3. During playback:
 - Press the M Button to pause; press again to resume normal playback.
 - Press and hold the + or - Buttons to adjust volume level as desire.
 - Press and release the + or - Buttons repeatedly to skip tracks.
 - Press the M Button to switch to BT playback mode; press again resume to Micro USB (TF) Card playback mode.
4. To shut off the unit, press and hold the Button on the unit until hearing an audible prompt say "Power Off".

Notes:

- Up to 32 GB Micro SD (TF) Card the unit supports to play.
- Before replacing Micro SD (TF) Card, make sure the unit is in power off mode. Otherwise, the card and the unit may damage.
- When inserting the Micro SD (TF) Card,make sure the direction you selected is correct. Never insert violently to avoid damaging the Micro SD Card or the unit.
- If it doesn't work, please check if the direction is correct.
- You also need to download the desired music in MP3 format into the Micro SD (TF) Card before insert into the unit.

AUX (In) Mode:

Listen music through the Aux Out; Line Out or Phone Jack from external audio player:

1. In power off mode, connect one end of the supplied Audio Connection Cable to the AUX (In) Jack on the unit.
2. Connect the other end to the Aux Out; Line Out or Phone Jack on external audio player.
3. Play the music on the external audio player as usual.
4. Use the Volume controls on the external audio player to adjust volume level as desired.

Notes:

- If you are listening music from external Audio Player through AUX In Jack. You are no need to power on the unit.
- If the Audio Connection Cable is inserted into the AUX (In) Jack, BT/Micro SD (TF) Card playback mode will be automatically shut off. Unplug the cable from the jack before use BT/Micro SD (TF) Card Playback mode.

TROUBLESHOOTING

Check the following before requesting service:

SYMPTOM	POSSIBLE CAUSE	POSSIBLE SOLUTION
Can't power on	Built-in battery drained	Recharge the battery as page 3
No sound or sound weak	Volume of the unit was set to minimum position	Increase the volume by press and hold the + Button on the unit
	Volume level of paired/connected device is in low level	Rise the volume level of the paired/connected device
Sound distortion	Volume level too high	Reduce the volume level by press and hold the - Button on the unit
	Volume level of the paired/connected device too high	Reduce the volume level of the paired/Connected device
BT not functioning	The external BT Device had NOT paired to the unit	Pair the external BT Device to the unit as page 3-4
	The external BT device too far from the unit	Place the external BT device close to the unit
	Audio Connection Cable was inserted into the Aux/Line In Jack	Unplug the Audio Connection Cable from the AUX (In) Jack before use BT or Micro SD (TF) Card playback mode

GENERAL SPECIFICATIONS:

Power source:.....Built-in DC --- 3.7 V, 450 mAh (1,665 WH) rechargeable Li-ion Battery, Recharge by DC ---5 V through the Micro USB Port

Impedance of the Earbuds:.....15 mW, 32 ohms per Channel

Audio power:.....15 mW per Channel

BT Operation:.....32 Feet in open area

PACKAGE INCLUDES:

- 1 xOwner's Manual
- 1 xUSB Connection Cable (For Charging only)
- 1 xAudio Connection Cable with 3.5mm plugs

SPECIFICATIONS AND ACCESSORIES ARE SUBJECT TO CHANGE WITHOUT NOTICE

LIMITED WARRANTY

Craig Electronics Inc. warrants this product to be free from manufacturing defects in material and workmanship under normal use for a period of 180 days from date of purchase. If service is required, please return the product to the store where it was purchased for exchange; or, pack the unit in the original packing material with all accessories if applicable, a copy of your sales receipt and a Cashier's check or Money Order for \$3 (to cover shipping and handling costs) payable to Craig Electronics Inc. For consumers in Canada, please make sure that the cashier check or money order is redeemable through a U.S. bank. Ship your product freight pre-paid. Your unit will be repaired, replaced or if the unit can not be repaired or replaced, a refund will be forwarded to you within four weeks of receipt of your unit. Please ship your unit to:

RF warning for Portable device:
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

Craig Electronics Inc.
1160 NW 163 Drive
Miami, FL 33169

This warranty is void if the product has been: a) Used in a commercial application or rental. b) Damaged through misuse, negligence, or abuse. c) Modified or repaired by anyone other than an authorized Craig Electronics Inc. service center. d) Damaged because it is improperly connected to any other equipment.
Note: This warranty does not cover: a) Ordinary adjustments as outlined in the Owner's Manual which can be performed by the customer. b) Damage to equipment not properly connected to the product. c) Any cost incurred in shipping the product for repair. d) Damage to the product not used in the USA.

This warranty is not transferable and only applies to the original purchase. Any implied warranties, including the warranty of merchantability, are limited in duration to the period of this expressed warranty and no warranty whether expressed or implied shall apply to the product thereafter.

Under no circumstance shall Craig Electronics Inc. be liable for any loss or consequential damage arising out of the use of this product. This warranty gives specific legal rights. However, you may have other rights which may vary from state to state. Some states do not allow limitations on implied warranties or exclusion of consequential damage. Therefore, these restrictions may not apply to you.

This product has been manufactured by and is sold under the responsibility of Craig Electronics Inc., and Craig Electronics Inc. is the warrantor in relation to this product. MAGNAVOX and SMART. VERY SMART are registered trademarks of Koninklijke Philips N.V. and are used under license from Koninklijke Philips N.V.

To Obtain Service on your Product
email:service@craigelectronics.com