

 <a href="http://www.honwa.cn">www.honwa.cn</a>	<u>Products Description</u>	<u>Products Description</u>	<u>Products Spec</u>	<u>Warning</u>
	Model NO.: BT Sports Music earbuds	Power Indicator: Blue/Red	BT Version:V4.1+EDR compatible with V1.1	Keep away from high Temp situation
	Style: Sports with ear-hook	Charge Volt: 5V/100MA-300mA	V1.0 V1.2 V2.0 V3.0	Keep away from fire
	Material: ABS	Battery Capacity: 70mAh Lithium-	BT Mode:A2DP/AVRCP/Hands free/Headset	Do not immerse into the water
	Device: Cell phone/Tablet/laptop with BT function	Polymer battery	Wireless Frequency: 2402MHz-2480MHz	Using the subsidiary USB cable for charging.
	Caller-ID Audio reminder	Battery Spec: 3.7*10*30mm	Sensitivity: -86dBm	Do not over charge continuously, batter using life will shorten.
	Unit ON/OFF Audio reminder	Working Volt: 3.6V-4.2V	Frequency: 20Hz-20kHz	Loading with Lithium-Polymer battery, Do not disassemble the BT unit, battery might broken or causing other danger consequence
	Dual devices pairing simultaneously	Charge Connector: Micro 5-pin USB	Receipt Distance: 10M	
BT-unit power display for IOS system device.	Call Time: 5H	Working TEMP Range: -20℃--40℃		
4 languages voice prompt	Music Time: 6H			
Power voice prompt	Standby Time: 220H			
	ISSC low-consume IC			

<u>Instruction</u>	<u>Instruction</u>	<u>Batter Charge</u>	<u>FCC Statement:</u>	
Turn On: Press/hold 3 secs until blue indicator is on	Answer/End Call: Press function button once	Loading with chargeable battery, the BT Unit need full charged at the first time using.	This equipment has been tested and found to comply with the limits for Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:	<ul style="list-style-type: none"> <li>• Reorient or relocate the receiving antenna.</li> <li>• Increase the separation between the equipment and receiver.</li> <li>• Connect the equipment to an outlet on a circuit different from that to which the receiver is connected. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</li> </ul> Note: Modifications to this product will void the user's authority to operate this equipment.
Turn Off: Press/hold 5 secs until red indicator is on	Reject Call: Press/hold function button 2 Secs	Connecting the USB cable to the charge socket.		
Pairing condition( Press/hold until blue and red indicator is blinking.	Voice Dial: Press/hold function button 2 Secs	Red indicator is on when charging		
Under the condition of Unit off, press/hold the funtion button, firstly the blue light is blinking until blue/red indicator is blinking alternately, then enter the searching mode.	Last Call Record Dial: Press function button twice	2.5 hours to full charge		
Turn on the BT of device and searching until finding a BT signal, a model NO. displays.	Music: Press function button	The red indicator is off when full charged and blue indicator is on		
Lastly press the model NO. to connect them. After pairing the BT Unit blue	Last Song: Press/hold "-" button 2 Secs			
Press the button once connecting again the device or unit.	Next Song: Press/hold "+" button 2 Secs			
Press/hold 2 secs "+" and function button, choose languages voice prompt	VOL Up: Press "+" button			
	VOL Down: Press "-" button			
	Stop Music: Press funtion button			
	Press/hold "+" and "-" button 2 Secs, power voice prompt	The red indicator is on when low power ( twice every 20 secs)		