


骑马订
尺寸：120*160mm
红框表示尺寸大小，不印刷
内页128太阳哑粉纸，封面200太阳哑粉纸



CONTENT INDEX

- 1. INTRODUCTION 1
- 2. WHAT'S IN THE BOX 1
- 3. CONNECT SOUNDBAR, SUBWOOFER AND SURROUND SOUND BOX 2
- 4. HOW TO CONNECT SOUNDBAR TO YOUR DEVICES 3
 - 4a. Connecting the Soundbar to your TV 3
 - 4b. Connect to Other Devices through Optical Cable 4
 - 4c. How to Use Bluetooth 5
- 5. USE YOUR SOUNDBAR SYSTEM 6
 - 5a. Soundbar Top Panel & Remote Control 6
 - 5b. LED Display 7
 - 5c. Soundbar Back Panel 8
 - 5d. Subwoofer Back Panel Area and Indicator Light 9
- 6. PRODUCT SPECIFICATIONS 10
- 7. PRODUCT SPECIFICATIONS 10
- 8. CUSTOMER SUPPORT 10
- FCC STATEMENT 11

1. INTRODUCTION

Thank you for purchasing the iDeaPLAY Soundbar Live2 system. We urge you to take a few minutes to read through this manual, which describes the product and includes step-by-step instructions to help you set up and get started.

CONTACT US:
If you have any questions about iDeaPLAY Soundbar Live2 system, its installation or its operation, please contact your retailer or custom installer, or send us a Email: support@ideausa.com
Toll-Free NO: 1-866-886-6878

2. WHAT'S IN THE BOX

3. CONNECT SOUNDBAR AND SUBWOOFER

Placing the Soundbar

To ensure the best audio experience, put the soundbar under the centre position under your TV.

Placing the Subwoofer

Put the subwoofer less than 30ft (10m) from the soundbar.

PLEASE NOTE:
It is recommended to use cable connection between the soundbar host and the TV. (Using Bluetooth connection for TV may cause sound quality pressure loss) The soundbar host must be used together with subwoofer and surround sound box.

4. HOW TO CONNECT SOUNDBAR TO YOUR DEVICES

4a. Connecting the Soundbar to Your TV
Connect your soundbar to a TV. You can listen to audio from TV programs through your soundbar.

4b. Connect to Other Devices Through Optical Cable
Using an optical cable, connect the optical port on your soundbar to the optical connectors on your devices.

4c. How to Use Bluetooth

Step1:
Enter pairing mode: Turn on the Soundbar. Press Bluetooth (BT) button on your remote control to start Bluetooth pairing. The "BT" icon will flash slowly on the screen indicating the Live2 has entered pairing mode.

Step2:
Search for "iDeaPLAY LIVE2" on your devices and then pair. Live2 will make an audible beep and the BT icon illuminate, indicates the connection is complete.

PLEASE NOTE:
Press "BT" button for three seconds to disconnect the Bluetooth device connected to the audio and enter the reconnection status.

Bluetooth Troubleshoots

- If you cannot find or pair to the Live2 via BT, unplug the Live2 from the power outlet, then 5 seconds later plug it again and connect by following the instructions above.
- A previously paired device will automatically reconnect if it hasn't been unpaired. Need to search and pair manually for the first time use or reconnect after unpaired.
- The Live2 can only pair to one device one time. If you cannot pair your device, please check that no other device is already paired with the Live2.
- BT connection range: Surrounding objects can block BT signals; maintain a clear line of sight between the soundbar and the paired device, household appliances, such as smart air cleaners, WiFi routers, induction cookers, and microwave ovens can also cause radio interference that reduces or prevent pairing.

5. USE YOUR SOUNDBAR SYSTEM

5a. Soundbar Top Panel & Remote Control

- Volume Adjustment
- Power Button (It takes 3 seconds to turn on / off the Soundbar)
- Sound Source Selection (Touch the icon, the corresponding icon "BT, AUX, OPT, COX, USB" in the front display area will light up accordingly, indicating that the corresponding input sound source on the backplane has entered the working status.)
- Sound Mode Adjustment
- Previous / Next
- Pause / Play / Mute Button
- Installing Remote Batteries (Insert the provided AAA batteries.)

5b. LED Display

- Temporary Display of Volume and Sound Source:**
 - The maximum volume is 30, and 18-20 is suitable for normal use.
 - Temporary display of sound source: select sound source through touch screen or remote control. The corresponding source is shown here for 3 seconds and then returns to the volume number.
- Sound Effect Display:**
Press the "EQ" button on the remote control to change the sound mode.
MUS: Music mode
NEWS: News mode
MOV: Movie mode
- Sound Source Display:**
Select on touch screen or by remote control, the mode will light up according on the screen.
BT: Corresponding to Bluetooth.
AUX: Corresponding to aux input on the backplane.
OPT: Corresponding to optical fiber input on backplane.
COX: Corresponding to coaxial input on backplane.
USB: When the USB key is pressed on the remote control or the touch screen is switched to USB mode, USB will be displayed in the volume area.

5c. Soundbar Back Panel

- USB Input Port:**
Automatically recognize and play from the first song after inserting USB flash disk. (Cannot select folder to play).
- AUX Input Port:**
Connect with 1-2 audio cable and connected with red / white output port of sound source device.
- Coaxial Port:**
Connect with coaxial line and connected with coaxial output port of sound source device.
- Optical Fiber Port:**
Connect with optical fiber cable and connected with optical fiber output port of sound source device.
- Power Port:**
Connect to household power supply.

5d. Subwoofer Back Panel Area and Indicator Light

- Bass Intensity Adjustment:** 70% intensity is appropriate for normal use.
- Subwoofer In(Extension Input):** It can be connected with other devices with bass audio output.
- Power Switch:** Press after the subwoofer is connected to the power, the indicator light on the upper-left corner of subwoofer front is on.
- Subwoofer Indicator Light:** Red: Power is on; Blue: Successfully connected to the soundbar (The subwoofer and the soundbar will be connected automatically but need to make sure the soundbar is powered on first)

6. STANDBY MODE

- Automatic standby: When the device has no signal input for 15 minutes (such as TV shutdown, movie pause, music pause, etc.), Live2 will automatically stand by. Then you will need to switch on the soundbar manually or by remote control.
- In automatic standby mode, the customer can also remotely control by the remote control and Live2 panel buttons.
- The auto standby function is the default and cannot be turned off.

7. PRODUCT SPECIFICATIONS

Model	Live2	Ports	Bluetooth, Coaxial, Optical Fiber, 3.5mm, USB Input
Size	Soundbar: 35x3.8x2.4 inch (894x98x61mm) Subwoofer: 9.2x9.2x15.3 inch (236x236x39mm)	Input Power Supply	AC 120V/60Hz
Speaker Unit	Soundbar: 0.75 inch x 4 Tweeter 3 inch x 4 Full Range Subwoofer: 6.5 inch x 1 Bass	Net Weight:	Soundbar: 6.77lbs(3.075kg) Subwoofer: 11.1lbs(5.05kg)
Total RMS	120W		

8. CUSTOMER SUPPORT

For any support or comments concerning our products, please send an email to: support@ideausa.com
Toll-Free NO: 1-866-886-6878
Address: 13620 Benson Ave, Suite B, Chino, CA 91710
Website: www.ideausa.com

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

***RF warning for Mobile device:**
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

