

MANUAL

Operation manual: For the first time to use (Or Replace the battery)Need to frequency bind

- Take out the remote control, install the battery
- Long press on the frequency key 2-4 seconds, Indicator light will flash
- Turn on the power of the car, Indicator light flashes to long lighting, then frequency bind succeed
- If the frequency bind failed (Indicator light flashes) , remove the battery and repeat steps 1~3
- remote control without operation after 10 seconds, Indicator light will off into power saving mode
- Button Description: \triangle forward ∇ backward \triangleleft turn left \triangleright turn right
S: Speed P: Open door / Close door

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.