

Photographs of EUT Setup



Fig-4.1 Open the Front antenna lengthwise of EUT with 0 cm Gap (Body Mode)



Fig-4.2 Open the Rear Face antenna lengthwise of EUT with 0 cm Gap (Body Mode)



Fig-4.3 Open the Top Side antenna lengthwise of EUT with 0 cm Gap (Body Mode)



Fig-4.4 Open the Right Side antenna lengthwise of EUT with 0 cm Gap (Body Mode)



Fig-4.5 Open the Front antenna lateral of EUT with 0 cm Gap (Body Mode)



Fig-4.6 Open the Rear Face antenna lateral of EUT with 0 cm Gap (Body Mode)



Fig-4.7 Open the Top antenna lateral of EUT with 0 cm Gap (Body Mode)



Fig-4.8 Close the Front antenna of EUT with 0 cm Gap (Body Mode)



Fig-4.9 Close the Rear Face antenna of EUT with 0 cm Gap (Body Mode)



Fig-4.10 Close the top antenna of EUT with 0 cm Gap (Body Mode)

Photographs of EUT



