



## S17说明书折页

成品尺寸: 55\*80 mm

材质: 封面封底157g铜版纸, 折页

料号: 11401-01342

<h3>S17</h3>  <p>多功能键 EQ调节</p>	<h4>功能概述</h4> <h5>给耳机充电:</h5> <ol style="list-style-type: none"><li>1. 请使用随配的充电线给耳机充电, 否则可能会损坏您的耳机;</li><li>2. 耳机电池是不可拆卸的可充电电池。为了保护您的耳机, 请勿不要拆卸电池;</li><li>3. 充电之前请给耳机关机;</li><li>4. 把充电线插入耳机的充电接口中, 充电时耳机的红灯常亮;</li><li>5. 耳机充满需要 1.5 ~ 2小时, 当充满电时耳机的指示灯蓝色常亮。单次使用时间的16小时。</li></ol> <h4>按键示意图</h4> 		<h4>开机配对:</h4> <p>长按多功能按键3秒, 直到红灯交替快闪, 进入配对模式。</p> <h4>关机:</h4> <p>长按多功能按键3秒, 红灯亮1秒后关机。</p> <h4>与手机配对:</h4>  <p>长按耳机多功能按键直到指示灯交替快闪, 打开手机蓝牙, 在可用设备中搜索"Padmate S17"并点击连接完成配对。</p>	<h4>同时连接两台设备 (多点连接):</h4> <ol style="list-style-type: none"><li>1. 首先, 按照配对说明与设备1配对连接。</li><li>2. 配对成功后, 关闭设备1的蓝牙功能。</li><li>3. 按照配对说明与设备2配对连接 (设备1的蓝牙功能已关闭)。</li><li>4. 与设备2连接成功后, 打开设备1的蓝牙功能, 耳机将于设备1自动连接, 如果没有连接成功, 请在设备1中点击"Padmate S17"完成连接。</li><li>5. 以上操作完成后, 您可以使用耳机从两个配对设备中的任何一个拨打接听电话。</li></ol>	<h4>音频产品警告!</h4> <p>长期暴露于高音量声音可能导致永久性听力损失。请降低音量, 避免过长时间的聆听。在聆听音乐、查看视频或玩游戏时, 请保持安全音量。</p> <p>如果您正在使用本产品, 请将音量限制器设置为低水平。</p> <p>如果您在长时间使用本产品后感到头晕或恶心, 请立即停止使用本产品。</p> <p>本产品可能会导致听力损失, 请务必在安全音量下使用本产品。</p> <p>本产品可能会导致听力损失, 请务必在安全音量下使用本产品。</p> <p>本产品可能会导致听力损失, 请务必在安全音量下使用本产品。</p>	<h4>电池警告!</h4> <p>"小心"标志表示不当。本产品中使用的电池可能存放在火灾或化学危险区域。如果发生此类情况, 请立即通知消防队。</p> <p>本产品使用不可拆卸的锂离子电池。请勿将本产品放入水中, 因为可能会导致短路。</p> <p>请勿将本产品放入水中, 因为可能会导致短路。</p> <p>请勿将本产品放入水中, 因为可能会导致短路。</p>	<h4>充电器警告!</h4> <p>请勿使用输出电流大于0.2A的充电器给本产品充电。</p> <p>请勿将本产品放入水中, 因为可能会导致短路。</p> <p>请勿将本产品放入水中, 因为可能会导致短路。</p>
--	---	---	--	---	--	--	--

<h3>Overview of earbuds</h3> <h4>Charger and battery:</h4> <ol style="list-style-type: none"><li>1. Please use the original cable to charge the Bluetooth earbuds, otherwise it may damage the earbuds.</li><li>2. The earbuds uses a non-detachable built-in rechargeable battery, in order to protect your earbuds, please do not remove the battery.</li><li>3. Before charging, make sure the earbuds has been power off.</li><li>4. Plug USB cable into the charging port of earbuds, the red light remains bright when charging.</li><li>5. Charging time of earbuds takes approximately up to 1.5-2 hours, the red light will turn blue when fully charged, life time is about 16 hours.</li></ol> <h4>Key diagram</h4> 	<h4>Power on and Pairing the earbuds:</h4> <p>Press and hold the MF button for 3 seconds until the red and blue lights flash alternately, then earbuds enter pairing mode.</p> <h4>Power off:</h4> <p>Keep pressing the MF button 25, red light will go for 10, then go out.</p> <h4>Pair the earbuds:</h4>  <p>Keep press the MF button until the alternative red and blue light quickly blinks, turn on your phone's Bluetooth, search for "Padmate S17" in the available devices list and click it to complete the pairing of the earbuds.</p>	<h4>Simultaneously Pairing with Two Devices (Dual Pairing Mode):</h4> <ol style="list-style-type: none"><li>1. First, follow the instructions in the "Pairing" section to pair the earbuds with Device 1.</li><li>2. Once paired, disable pairing function on Device 1.</li><li>3. Next, follow the instructions in the "Pairing" section to pair with the Device 2 (Device 1 Pairing function off).</li><li>4. Once paired with Device 2, turn on Pairing function on Device 1, and the earbuds will automatically reconnect if it not reconnect success, please click "Padmate S17" in Device 1 to connect.</li><li>5. You can now make and receive calls from either of the two paired devices.</li></ol>	<h4>AUDIO PRODUCT WARNING!</h4> <p>PERMANENT HEARING LOSS MAY RESULT FROM LONG-TERM EXPOSURE TO SOUNDS AT HIGH VOLUMES. USE AS LOW A VOLUME AS POSSIBLE.</p> <p>Don't prolonged use of headsets at excessive sound pressure level.</p> <p>Please read the Safety Guidelines below prior to using this product.</p> <h4>You can reduce the risk of hearing damage by following these safety guidelines:</h4> <ol style="list-style-type: none"><li>1. Prior to using this product follow these steps:<ul style="list-style-type: none"><li>- Before using the product, turn the volume control to its lowest level.</li><li>- If you experience discomfort or ringing in your ears, immediately discontinue using the product.</li></ul></li><li>2. With continued use at high volume, your ears may become accustomed to the sound level, which may result in permanent damage to your hearing without any noticeable discomfort.</li></ol> <h4>GENERAL SAFETY INFORMATION:</h4> <p>If you have a pacemaker or other electrical medical devices, consult your physician before using this product.</p>	<p>This package contains small parts that may be hazardous to children. Always store the product out of reach from children. The bags themselves or the many small parts they contain may cause choking if ingested.</p> <p>Don't disassemble the product yourself or insert any type of object into it, as this may cause a circuit failure that can lead to a fire.</p> <p>None of the components can be repaired or replaced by users. Only authorized dealers or service centers may open the product. If any parts of your product require replacement for any reason, including normal wear and tear or breakage, contact your dealer or service center.</p> <p>Avoid exposing your product to rain or other liquids.</p> <p>Keep all products, cords, and cables away from operating machinery.</p> <p>Observe all signs and instructions that require an electrical device or RF radio product to be switched off in designated areas such as hospitals or aircrafts.</p> <p>If the product overheats, has been dropped or damaged or has been dropped in a liquid, discontinue use.</p> <p>Remember: Always drive safely, avoid distractions and follow local laws!</p> <p>The use of a speaker while operating a motor vehicle may be regulated by local laws. Using a headset while operating a motor vehicle, motorcycle, watercraft or bicycle may be dangerous, and is illegal in some jurisdictions, just as use of this headset with both ears covered while driving is not permitted in certain jurisdictions. Check with your local authorities.</p> <h4>BUILT-IN BATTERY CARE:</h4> <p>Please observe the following if the product contains a battery:</p>	<p>Your product is powered by a rechargeable battery. The full performance of a new battery is achieved only after two or three complete charge and discharge cycles.</p> <p>The battery can be charged and discharged hundreds of times, but will eventually wear out. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime.</p> <p>The battery will be charged if you do not charge over 48 hours. If the battery has been charged for a long time, we recommend you to charge it at least once every three months.</p> <p>Leaving the product in hot or cold places will reduce the capacity and lifetime of the battery. Always try to keep the battery between 0°C and 40°C (32°F and 104°F). A product with a hot or cold battery may not work temporarily, even when the battery is fully charged.</p> <h4>Battery warning</h4> <p>"Caution" label: the battery used in this product may present a risk of fire or chemical burn if misused. Batteries may explode if damaged or used for this product.</p> <p>Only recharge your battery with the provided approved charger designed for this product.</p> <p>Dispose of batteries according to local regulations. Please recycle when possible. Do not dispose as household waste or in a fire as they may explode.</p> <p>Unless otherwise specified in the user manual, do not short-circuit the battery in your product, do not remove or replace by the user. Any attempt to do so is risky and may result in damage to the product.</p> <p>Important: Please refer to the user manual for a description of the charging status indicator lights. Some products cannot be used while charging.</p>	<h4>Charger warning!</h4> <p>Do not use a wall-charger with more than 5V and 2A output.</p> <p>When you disconnect the power cord or any attachment, grasp and pull the plug, not the cord. Never use a charger that is damaged.</p> <p>Do not attempt to disassemble the charger as it may expose you to dangerous electric shock.</p> <h4>MAINTENANCE</h4> <p>Use the product or charger before cleaning.</p> <p>Clean the product by wiping with a dry or slightly damp cloth. The cord and charger may only be hand-washed.</p>	<h4>FCC Warning</h4> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.</p> <p>Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.</p> <p>If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"><li>— Reorient or relocate the receiving antenna.</li><li>— Increase the separation between the equipment and receiver.</li><li>— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</li><li>— Consult the dealer or an authorized radio/TV technician for help.</li></ul> <p>The device has been evaluated to meet general RF exposure requirements. The device can be used in a portable exposure condition without restriction.</p> <p>FCC ID: 2AUEJ-S17</p>
---	---	--	--	---	---	---	---