

JJ AUDIO 万音
Bluetooth Soundbar



<http://www.jyav.cn/>

Content:

Introduction	2
Package contents	2
Features & Specifications	2-3
Overview of soundbar and remote controller	4-5
Connect to your audio devices:	5-8
Warnings and Precautions	8
Trouble shooting	9
Safety Information	10-12

Introduction

Thanks for choosing Axess products. Please read this user's guide before using your new soundbar

Package Contents

Soundbar DC Adapter Warranty Card
Remote Controller AAA batteries*2
User's Guide RCA cable



Features

1. Bluetooth Ultra-thin Soundbar (wall-mountable);
2. Built-in 3D surround technology;
3. Deep bass speaker, high, middle and low three rate technology;
4. Bluetooth/USB//AUX in/Line in;
- 5 CE/FCC approval
6. Full function remote control operation;
7. UL approval adapter
8. Ideal partner for LED/LCD TVs;
9. Left/Right separately cavity, 2.0 stereo sound;

Specifications

Power Input: DC 12V 2A
Output: 60W
Frequency Response: 80-16k(Hz)
Speaker Units: 4"Full Range Speaker x 2
Interface: Audio Input/Aux in/Line in/USB/Bluetooth
Distortion Degree \leq 1% (1KHz 1W 4 Ω)
S/N Ratio \geq 80db
Standby Power \leq 0.5W
Isolation Level \geq 70db
Input Sensitivity650Mv, Max:2000mV
Speaker: 4 inch per unit*2 pcs, 3 inch diaphragm*2 pcs

Overview of soundbar and remote controller Buttons:




Connections:

Important tips for system connection

When you want to connect soundbar to your TV or other devices, Please choose output port of your devices. Please check the connection carefully before you use our products.


TV Connection

If your TV has 3.5mm output port(headphone audio output port), you can use 3.5mm audio cable to connect soundbar to your TV.




DVD connection

If your DVD player has the red and white audio output port .please use the attached red and white RCA cable to connect our product and the DVD player.



Bluetooth Connection

Press "Mode" button to enter Bluetooth Mode. Then turn on your cellphone's Bluetooth function, search for SBBT1205 and connect it.



Warnings and Precautions

- ★ To reduce the risk of electric shock, do not remove cover (or back).
- ★ Do not expose the soundbar to dripping or splashing liquids. Do not place objects filled with liquids (such as vases) on the soundbar.
- ★ Using the soundbar near fluorescent lighting may cause interference with the remote. If the soundbar is behaving erratically, move away from any fluorescent lighting.
- ★ The power source must supply 12V 2A DC. Using a non-original adapter could damage the soundbar or adapter.

Trouble Shooting

PROBLEM	SOLUCION
No sound	Make sure the AC adapter is plugged into a working outlet and firmly connected to the soundbar. Check the connection of your device to the soundbar.
Distorted sound	Check your source device to see if it is causing the distortion. Set the device and soundbar volume to a low level.
Unbalanced sound	If the volume remains low even when the soundbar's volume is turned all the way up, check the source device to make sure it is connected via a variable output. Make sure the output is not turned down too low.

Safety Information

WARNING

Please read these safety warnings and cautions carefully to ensure your personal safety and prevent property damage.

Fire and Electric Shock Hazard

- Do not expose your speaker to liquid, moisture, humidity, or rain. Do not use the speaker near a bathtub, sink, sauna, pool, or steam room. Exposure of the speaker to moisture could result in electric shock.
- Do not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint, or insert foreign objects in to the speaker.

Such actions could result in electric shock.

- Clean the speaker only with a dry cloth.
- Do not expose your speaker to extremely high or low temperatures.
- Do not leave your speaker in direct sunlight for extended periods of time.
- Do not leave your speaker near open flames such as cooking burners, candles, or fireplaces.

- Do not block ventilation openings

Battery/Charging Hazard

- Do not dispose your speaker in a fire. The battery could explode causing injury or death.
- Only charge the speaker in accordance with this User Manual. .

- Do not charge the speaker in damp areas or in extremely high or low temperatures because this could result in electric shock.
- Do not clean the speaker when it is being charged. Always unplug the charger first before cleaning the speaker.

Automobile Accident Hazard

- Do not leave or store the speaker or any of its accessories near or over your automobile's air bag because serious injury may result when an air bag deploys.

Fall Hazard

- Do not place the speaker on high surfaces such as shelves. During music playback the speaker may move which could cause the speaker to shift and fall off the edge.

CAUTION

- Do not use abrasive cleaners to clean your speaker because this could cause scratches or damage.
- Do not bring your speaker in to contact with any sharp objects because this could cause scratches and damage.
- Do not insert anything into your speaker unless otherwise specified in this User Manual. This may damage the internal components.
- Do not attempt to repair, modify, or disassemble your speaker yourself.
- Do not attempt to replace the battery of the speaker. It is built-in, and not changeable by users.
- Use only the USB charging cable supplied in the accessories package to charge the speaker, from the USB port of computer. Or charge the speaker with a wall main

charger supplied from the same store where you purchase this speaker.

Other chargers may look similar, but using them could result in electric shock and could damage the speaker.

- Observe all signs and displays that require an electrical device or RF radio products to be switched off in designated areas.

FCC

FCC NOTICE

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions;

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

FCC CAUTION

- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

To locate the FCC and IC identification numbers, please look on the underside of the speaker.

CE STATEMENT

This product is compliant with the CE directive. All returns must be made to the original place of purchase.



Tel : +86 755-33139905

Email: jyaudio@joyspeaker.com

Add.: 3/F, Bldg C, No. 99, the 2nd Industrial Park, Nanchang Community,
Xixiang Town, Baoan District, Shenzhen, China 518126.