

标准书名	印刷部品规格书				版本	公差等级				
						基本尺寸				
						A级	B级	C级		
						5<L<10	±0.08	±0.10	±0.15	
注意事项	<ul style="list-style-type: none"> <li>● 图中 * 记号表示该尺寸为重点管控尺寸。</li> <li>● 量产前样品请先取得研发担当者之确认。</li> <li>● 使用模具在二具以上时各模具之检定品。</li> <li>● 交货者希望变更时，须事先取得研发担当者之承认。</li> <li>▲ 图中所用物料必须符合欧盟RoHS环保要求，送样时请附上检测报告。</li> </ul>				10<L<20			±0.10	±0.15	±0.20
					20<L<40			±0.15	±0.20	±0.25

100mm

100mm

**iwALK**

Welcome Guide  
Crazy Keyboard

User's Manual

**Product Structure**

- ① USB-C Charging Port
- ② Power Button
- ③ Function Keys
- ④ Bluetooth Pairing Indicator Light
- ⑤ Case lock Indicator Light
- ⑥ Power/Low Battery/Charging Indicator Light

**Usage Method**

1. Take out the iPad case from the Cover Case and install the iPad.
2. Turn the upper half of the cover back to form a bracket.

**Bluetooth Connection**

1. Turn the power button to "ON" position, the blue power indicator will light for 1 second.
2. Press Fn+Connect to enter the pairing mode, the blue Bluetooth pairing indicator will flash. The keyboard will stay on searching state within 3 minutes.
3. Turn on the Bluetooth menu on your iPad. Search for Bluetooth devices. Choose the name "Crazy Keyboard" and click on it. After the connection is successful, the pairing indicator is off.

After your successful first-time pairing, your iPad will automatically remember the keyboard. To connect again, please turn on Bluetooth on your iPad and the keyboard. The device should automatically connect. If it does not connect, please tap it in the My Devices list to connect.

**Charging**

When battery is low, the red power indicator will flash every two minutes, means need to charge the keyboard.

1. Connect the adapter and the keyboard through the USB-C to USB-C charging cable.
2. When charging, the power indicator light is steady red, after full light is steady blue.

Note: When not use for long time, suggest to close keyboard, in order to prolong battery life.

**Focus On True Value™**

www.iwalk.com/Service

TEL: +86-400-0888-2827 (weekdays)  
TEL: +86-20-3853-2821 (24hr service)  
TEL: +86-20-3853-2822 (24hr service)  
HEAD OFFICE: 80-082-0820-371700 (Main-Line 08:00-17:00)  
@iwalkchina

**iwALK Face**  
iwALK X-COMM  
iwALK X-ORBIT

**U20 GLOBAL CO.,LTD.**  
Head Office: Shenzhen U20 Building, Huaren Road 385, Jinhua, Xiamen, Fujian, China

UK Authorized Representative:  
iwalk (UK) Ltd.  
15 Great Portland Street, London, W1W 7LT  
Tel: +44 (0)20 7323 8200 | support@iwalk.com

EU Authorized Representative:  
iwalk (EU) Ltd.  
Avenue de la Woluwe 62, 1200 Brussels, Belgium  
Tel: +32 (0)25 467 2237

UK CE FCC RoHS REACH  
PA1171V2.0  
Made in China

The following function keys need to be combined with the FN key.

Input Switch: [Fn] [Enter] [Tab] [Caps Lock] [F1-F12]

**Specifications**

Product Name: Crazy Keyboard  
Model No.: BCI003 (2.9" / BCI04 (1.1")  
Operating Distance: Inductive, 70 meters  
Capacity: 500mAh (2.7V / 850mAh)  
Input: USB-C / 2.4GHz (BCI003)  
Weight: 100g (BCI003) / 75g (BCI04)

Charging time: 3-4 hours  
Working time: >45 hours  
Standby time: >30 days  
Product size: 290x120x10mm (BCI003)  
256x105x24mm (BCI04)

**Safety Precautions**

1. To preserve battery lifespan, use and recharge at least once every 4 months.
2. Use original or certified cables.
3. Do not expose to liquids.
4. Do not disassemble.
5. Avoid overcharging.
6. Avoid extreme temperatures.
7. Do not leave for a long time during charging.

**Touchpad Gestures**

Left mouse button (Click)

Click the cursor (One-finger movement)

Drag (Click and move with one finger)

Double click (Double click with one finger)

Swipe left to switch apps (Swipe left from the right edge with one finger)

Swipe right to switch apps (Swipe right from the left edge with one finger)

Open the app switcher (Click "Recent" from the top edge with one finger)

Right mouse button (Click)

Swipe left and right (Two-finger move horizontally)

Swipe up and down (Two-finger move vertically)

Zoom in (Apply to the browser (Two-finger spread out))

Zoom out (Apply to the browser (Two-finger pinch))

Swipe left to switch apps (Swipe left with three fingers)

Swipe right to switch apps (Swipe right with three fingers)

Back to home screen (Swipe up with three fingers)

Open Home Indicator (Two-finger click)

**Warranty card**

Please refer to the warranty card for details. Our products warranty period is 12 months starting from the date of purchase. After the warranty period, we will be available to the consumer. If the product has any quality problem, we will provide free repair or replacement service (subject to availability).

Please read the following information carefully before using the product. The manufacturer is not responsible for any damage caused by the user's misuse of the product. The manufacturer is not responsible for any damage caused by the user's misuse of the product. The manufacturer is not responsible for any damage caused by the user's misuse of the product.

**Product Information**

Product Name: Crazy Keyboard  
Model No.: BCI003 / BCI04  
Version: 1.0

**Customer Information**

Name: \_\_\_\_\_  
Phone No.: \_\_\_\_\_  
Address: \_\_\_\_\_

**Notes**

1. Please read the user manual carefully before using the product.  
2. The product is not waterproof.  
3. The product is not for use in a humid environment.  
4. The product is not for use in a high-temperature environment.  
5. The product is not for use in a low-temperature environment.  
6. The product is not for use in a high-voltage environment.  
7. The product is not for use in a low-voltage environment.

英文说明书	PA1171V2.0	BCI003/BCI004	2021.12.06	赖韵齐					
部品名	部品番号	使用機種	日期	制图	确认	承认	产品颜色		
经营策略部	制造部	采购部	品牌策略部	物控部	营销部	品管部	原件保存		
							研发部		
<b>厦门广开电子有限公司</b> <b>U20 GLOBAL CO.,LTD.</b>				页码	图纸规格	视图类型	公差等级	单位	比例
				1/1	A4		A	mm	1:1