




# Anaklia

User Manual



# Anaklia


Thank for purchasing TIC Anaklia Bluetooth Speaker.  
Please follow this manual to achieve the best sound effect.





## Accessories


---



A



B



C




D




## Power On/ Off

---



Slide up / down to turn on






Long press to turn off

---



## Bluetooth Connection

---







## NFC Connection

---


Easy pairing only works with devices with NFC capability





## Audio AUX connection

---







## Power Adapter Guide

---



LED



LED









## Volume Adjustment

---





---

This product is covered under warranty of 1 year starting from the date of purchase. Within the warranty period, repair service or components replacement will be provided for free under normal use or maintenance of components, materials, and functions.

Warranty does not apply to the following circumstances:

- 1.Product is not purchased from legal channel that is authorized by the company.
- 2.Failure to provide regular and proper maintenance to this product.
- 3.Product failure due to improper usage, misuse, abuse, alteration, faulty installation, power line surge or modification.
- 4.Product failure due to acts of nature such as natural disaster, fire, flood, or casualty.
- 5.Warranty cannot be provided if the Barcode is destroyed.



- 
- 1.Avoid this device from accidental drops, physical shocks, and any long exposure to the sun or rain.
  - 2.Keep this device in a clean/dry environment of 0°C –40°C in temperature. The ambient humidity of the device should not exceed 75% so as to avoid corrosion damage. Do not approach the device to a heat source such as fire.
  - 3.Never dispose of any electrical or electronic waste in general circulation. Collect and dispose of such waste safely and separately.

Failure to follow these safety instructions may result in unexpected damage of this device. The company is not responsible to any result caused by violation of safety instructions above.



---

Model:----- Anaklia/BB1  
Product:-----Bluetooth Speaker  
Battery Capacity:----- 2000mAh  
Power Input:----- 5V  $\Rightarrow$  1A  
Connection Mode:----- NFC/Bluetooth/AUX  
Framework Material:-- Aluminum/ Wood Grain

Power:----- 5W\*2RMS1%THD  
Frequency:----- 80Hz-18KHz  
Audio Channels:-----2.0 Stereo  
Control:----- Touch and slide  
SNR:-----  $\geq$  75dB  
Dimension:----- -7.9"x8.7"x4.5"

---

## **IMPORTANT SAFETY INSTRUCTIONS:**

- 1) Read these instructions.
- 2) Keep and follow all instructions.
- 3) Heed all warnings.
- 4) For indoor products, do not use this apparatus near water. For outdoor products, please do not expose apparatus to water longer than its intended time and level.
- 5) Clean only with a dry cloth.
- 6) Do not install this apparatus near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
- 7) Do not block any ventilation openings. Install this apparatus in accordance with the manufacturer's instructions.
- 8) Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A ground-type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 9) Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles and the point where they exit from the apparatus.
- 10) Use only attachments and accessories specified by the manufacturer.
- 11) Unplug this apparatus during lightning storms or when unused for long periods of time.
- 12) Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as when the power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, or the apparatus had been exposed to rain or moisture, does not operate normally or has been dropped.
- 13) Do not expose this apparatus to dripping or splashing, and ensure that no objects filled with liquids, such as vases, are placed on the apparatus.
- 14) To disconnect this apparatus from the AC mains completely, disconnect the power supply cord plug from the AC receptacle.
- 15) The mains plug of the power supply cord shall remain readily operable.
- 16) Do not expose batteries to excessive heat such as sunshine, fire, or the like.
- 17) This is not a children's product and is not intended for use by children under 14 years old.

## **CAUTION:**

Risk of Electric Shock. Do Not Open.



The lightning flash with an arrowhead symbol, within an equilateral triangle, is intended to

alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

Warning: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

#### **BATTERY WARNING:**

Your device may contain an internal, rechargeable battery that is not replaceable. Improperly replaced batteries may present a risk of leak or explosion and personal injury. Mistreated rechargeable batteries may present a risk of fire or chemical burn. Do not disassemble or expose to conducting materials, moisture, liquid, or heat above 54°C (130°F). Do not use or charge battery if it appears to be leaking, discolored, deformed, or in any way abnormal. Do not leave battery discharged or unused for extended periods. Do not short circuit. Battery life varies with usage. Non-operational batteries should be discarded according to local laws. If no laws or regulations govern, dispose of your device in a waste bin for electronics. Keep batteries away from children.

#### **SOUND WARNING:**

Avoid hearing damage by establishing safe listening volumes. Listening to this product at high volumes or for extended time periods may cause permanent hearing loss. Protect your hearing by establishing safe volumes. Start with the volume setting control at its lowest setting. Slowly increase the volume until you can hear it comfortably and clearly without distortion. Reduce the volume or stop listening if you experience ringing in your ears or any discomfort. Consult with a physician if needed.

#### **FCC Warning**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note 2: 1.Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

TIC Audio Inc. All rights reserved. The TIC logo is a trademark of TIC Audio Inc, registered in the United States. Features, specifications, and appearance are subject to change without notice.

For more information, please visit our website: [www.ticcorp.com](http://www.ticcorp.com).