



HELMET INSTRUCTIONS

Thank you for your purchase! At Vigor Audio Helmets we believe that music makes a good bike ride great. We hope this Vigor Audio helmet keeps you safe and sound mile after mile.

WARNING: CYCLING CAN BE DANGEROUS. BICYCLE PRODUCTS SHOULD BE INSTALLED AND SERVICED BY A PROFESSIONAL MECHANIC. NEVER MODIFY YOUR BICYCLE OR ACCESSORIES. READ AND FOLLOW ALL PRODUCT INSTRUCTIONS AND WARNINGS INCLUDING INFORMATION ON THE MANUFACTURER'S WEBSITE. INSPECT YOUR BICYCLE BEFORE EVERY RIDE. ALWAYS WEAR A HELMET.

COMPATIBILITY & INTENDED USE
This helmet is intended only for bike, skateboarding, inline skates, push scooters. It is not designed for motor vehicle use or any other sports or activities. This helmet is not intended for extreme mountain bike riding, downhill or BMX Racing.

WARNING: Limited Impact Protection
Helmets cannot always protect against injury. Even low-speed accidents can result in serious injury or death. Helmets subjected to an impact should be returned to the manufacturer, destroyed, and replaced, even if damage is not outwardly visible. Helmets can be penetrated by sharp objects.

WARNING: Helmets Won't Prevent All Head Injuries
Some head injuries are not caused by impacts. Helmets cannot prevent injuries caused by non-impact forces.

WARNING: Helmets Only Protect What They Cover
This helmet will not protect the neck or any area of the head that it does not cover. This helmet will not guard against spinal or other bodily injuries that may result from an accident.

NOTE: This helmet has a limited life span and should be replaced when it shows obvious signs of wear.
• Do not modify or remove any component parts of the helmet
• Exercise caution when you ride. Comply with all traffic regulations and avoid accidents
• Watch for traffic pulling out of driveways or parking spots, and for people getting into or out of vehicles
• Don't ride at night without proper lighting and reflectors. Watch for parked cars. Doors often open without warning


HelmetSafety_Manual_Vigor.indd 1

HOW TO MAKE YOUR HELMET FIT LIKE A PRO

Vigor Audio Helmets come in a couple of sizes, so in all probability there is a perfect size to fit your needs. If the helmet you now own does not fit properly (there should be very little space between your head and the sweat-absorbent headband or pad) exchange it for one that does.

Once you've got a helmet that's the right size, you can customize the fit with the velcro-backed sizing pads. Stick them to the helmet shell so that it feels snug but not too tight when you put the helmet on.


1. Wear Your Helmet in Its Proper Position
Always wear the helmet low in the front to protect the forehead. Never wear the helmet tipped back to expose your forehead



NOTE: All fitting adjustments MUST be made with the helmet in the proper position. Failure to do so will result in a poor fit. Poor fit will allow the helmet to move out of position or come off in an accident.

2. Adjust The Straps

A. Put the helmet on and slide the straps through the adjustors until they are located in the correct position below and slightly in front of the ears



B. Make sure there is no slack in any of the straps when the adjustors are positioned correctly.

4. Adjust the Chin Strap

A. Always wear the helmet with the chin strap buckle fastened and the strap pulled tight.

B. Make sure the strap sits under the jaw, NOT on the point of the chin. Straps worn on the chin increase the chance of the helmet coming off in an accident.

5. Getting the Correct Fit

The helmet fits correctly when it is held firmly but comfortably in place by the interior fit pads and the retention system.

6. Checking the Fit and Adjustments

Before using the helmet, make sure it fits correctly, the straps are correctly adjusted, and the chin strap is tight enough. Put the helmet on in the correct position. Fasten the chin strap and pull it tight. Stand in front of the mirror.

A. Check the fit. Grab the helmet with both hands and twist it to the left and to the right. If the helmet fits right, the skin on the forehead will move as the helmet moves. If it does not, the helmet is too loose.

B. Check the straps. Grab the helmet with both hands and try to remove it by rolling the helmet forward and backward as far as you can. Make a serious effort.

NOTE: If you can roll the helmet off your head completely in either direction, by rolling it forward so far that it blocks your vision, or backward far enough to expose the forehead, it doesn't fit correctly.

WARNING: If you cannot adjust the helmet to fit properly according to Step 5 and 6, **DO NOT USE THIS HELMET**. Replace it with a different size or model. Return it to your dealer or contact Vigor Audio Helmets for assistance. Once you are satisfied that the helmet fits correctly and that all straps are properly adjusted and tightened, take a short test ride. Pay attention to overall comfort and helmet stability while riding. Make any minor adjustments to the fit pads and straps to improve comfort or stability.

ONGOING MAINTENANCE

Washing

WARNING: Do not use solvents or aggressive cleaning solutions to clean your helmet.

Helmets can be damaged by many commercially available petroleum-based cleaners. Use warm soapy water and a soft cloth or sponge to spot clean the helmet as needed.

Storage

WARNING: Excessive heat can damage this helmet. Never store your helmet in a car or in direct sunlight. Store in a cool, dry place.

HOW TO USE YOUR VIGOR AUDIO HELMET

CHARGING

Connect the helmet to wall charger/computer/laptop using the included micro USB cable. The LED light will turn Red while charging and will turn OFF once the helmet is fully charged.

TURNING ON/OFF

ON: Press the "II" (Play/Pause) button located in the center, for approximately 3 seconds to turn the helmet ON. Once it's on, a Blue LED light will start flashing.

OFF: Press the "II" (Play/Pause) button located in the center, for approximately 3 seconds to turn the helmet OFF. Once it's off, the LED light will turn off too.

PAIRING THE HELMET

1. With the unit powered off, press and hold the "II" (Play/Pause) button located in the center, for approximately 5 seconds until the LED light starts flashing red & blue alternately and you will hear a beep. Now the helmet is ready to pair to your device.

2. Turn the Bluetooth on your phone/device, to ON and search for "VIGOR BTB" select connect/pair.

NOTE: If you do not see the helmet you may need to refresh the Bluetooth list on your device.

3. Once the helmet is connected, only the Blue LED will flash.

NOTE: The pairing process is required only for pairing the helmet with the device for the first time. Once paired it will connect to the device automatically next time, by following the "TURNING ON/OFF" Instructions above.

AUDIO FUNCTIONS

PLAY / PAUSE: Press the "II" (Center) button to play or pause the music.

SKIP TRACKS: Quickly press the "<" (Left) button to skip to the previous song. Quickly press the ">" (right) button to skip to the next song.

VOLUME CONTROL

VOLUME UP: Long press the ">" (right) button to increase the volume. You will hear a short beep for every level and a brief ring to indicate that the helmet has reached the max volume levels.

VOLUME DOWN: Long press the "<" (left) button to decrease the volume. You will hear a short beep for every level and a brief ring to indicate that the helmet has reached the max volume levels.

12/2/13 3:32 PM

LIMITED WARRANTY

VSI warrants this new VIGOR AUDIO HELMETS product against defects in materials and workmanship for one (1) year from the original date of retail purchase by the consumer. This limited warranty is expressly limited to the replacement of the original product, at the option of VSI, and is the sole remedy of the warranty. This limited warranty applies only to the original purchaser of the VIGOR AUDIO HELMETS product and is not transferable.

In no event shall VSI be liable for any loss, inconvenience or damage, whether direct, incidental or consequential or otherwise resulting from breach of any express or implied warranty or condition of merchantability, fitness for a particular purpose, or otherwise with respect to this product except as set forth herein. This warranty gives the consumer specific legal rights, and those rights and other rights may vary from state to state.

This warranty does not cover the following:

- Damage due to improper assembly or follow-up maintenance or lack of skill, competence or experience of the end user
- Products that have been modified, neglected, used in competition or for commercial purposes, misused or abused, involved in accidents or anything other than normal use
- Damage or deterioration to the surface finish, aesthetics or appearance of the VIGOR AUDIO HELMETS product
- Normal wear and tear
- Installation of components, parts, or accessories not originally intended use with or compatible with VIGOR AUDIO HELMETS products

TO THE EXTENT NOT PROHIBITED BY LAW, THESE WARRANTIES ARE EXCLUSIVE AND THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES OR CONDITIONS INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

WARRANTY PROCESS

We will happily back up our products. If you and your shop think your VIGOR AUDIO HELMETS product is worthy of a warranty inspection, please visit www.vigorhelmets.com/pages/warranty to start your RMA process.

CRASH REPLACEMENT PROGRAM

If you are involved in an accident, or your helmet experiences any significant impact, please visit www.vigorhelmets.com/pages/warranty to start your Crash Replacement process, and we'll extend a Crash Replacement Discount on the purchase of a new helmet. (Only valid on www.vigorhelmets.com)

WARRANTY INFORMATION

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation



VIGOR SPORTS INC.
17605 FABRICA WAY STE I
CERRITOS, CA 90703

(714)880-6105

WWW.VIGORHELMETS.COM



OWNERS MANUAL

正面

反面