

Quick Start Guide Nokia xx

N150DL



Make and Receive Calls:

1. Tap
2. Tap and type in a number, or tap and select a contact you want to call.
3. Tap

Answer a call

To answer a call when your screen is unlocked, tap **ANSWER**. To answer a call when your screen is locked, swipe up.

Add a contact

1. Tap **Contacts** >
2. Fill out the information.
3. Tap **Save**.

Voicemail Setup:

For instructions on how to set up voicemail, contact your service provider. When you have new voice mail appears in the status bar. Swipe down and tap the notification to listen to the voicemail.

Included in this package:

- Activation card
- Quick Start Guide
- About Your Phone booklet
- Phone
- Charger
- USB-C Cable

Initial Phone Setup:

Your phone already has a SIM card installed.

Your phone's battery may not be fully charged. Use the USB-C Cable and charger included in your package to charge your phone fully before the first use.

To turn your phone ON, press and hold the Power/Lock button. To turn your phone OFF, press the Power/Lock button and the volume up button at the same time.

Text and Picture Messaging:

1. Tap on the Messages icon .
2. Tap **Start chat**.
3. To add a recipient, tap , type in their number, and tap . To add a recipient from your existing contacts, start typing their name, once the contact list appears tap on the desired contact name.
4. To add more recipients, tap . After choosing all the recipients, tap **Next**.
5. Write your message in the text box.
6. To add a photo, tap and tap to take a new photo, or tap **Gallery** and select an existing photo.
7. Tap .

Notifications and Quick Settings:

When you receive new notifications, such as messages or missed calls, icons appear at the top of the screen. To access your notifications, swipe down from the top of the screen. To close the view, swipe up on the screen.

To activate a feature, swipe down from the top of the screen and choose the quick setting. To see more icons, drag the quick settings menu down.

Set up your Google™ Account:

During your initial phone setup you will be prompted to log into your Google account. You may skip this step and return to it using the steps below.

1. Tap **Settings** > **Passwords & accounts** > **Add account** > **Google**.
2. Type in your Google account credentials and tap **Next**, or, to create a new account, tap **Create account**.
3. Follow the instructions on your phone.

Turn on Wi-Fi:

1. Tap **Settings** > **Network & internet** > **Wi-Fi**.
2. Switch **Use Wi-Fi** ON.
3. Select the connection you want to use.

Using your Mobile Internet:

1. Tap on the Chrome icon .
2. Write a search word or a web address in the search field.
3. Tap , or select from the proposed matches.

Security Settings:

Set a screen lock

During your initial phone setup you will be prompted choose a screen lock option. You may skip this step and return to it using the steps below.

1. Tap **Settings** > **Security** > **Screen lock**.
2. Choose the type of lock and follow the instructions on your phone.

Bluetooth® Connectivity:

1. Tap **Settings** > **Connected devices** > **Connection preferences** > **Bluetooth**.
2. Switch **Use Bluetooth** to **ON**.
3. Make sure the device you are pairing to is turned on. You may need to start the pairing process from the other device.

For details, refer to the user guide for the other device.
4. Tap **Pair new device** and tap the device you want to pair with from the list of discovered Bluetooth devices.
5. You may need to type in a passcode. For details, refer to the user guide for the other device.

Unlock your phone:

Press the Power/Lock button and enter your screen lock.

Set up fingerprint authentication

1. Tap **Settings** > **Security** > **Fingerprint**.
2. Select your backup screen lock method and follow the instructions on your phone.

Unlock your phone with your fingerprint

To unlock your phone, place your registered finger on the Power/Lock button.

Notification and Status Icons:

	Bluetooth connection is on
	Wi-Fi is on
	Airplane mode is on
	Battery status

Regulatory Agency Information	
FCC ID	2AJOTTA-1500
Max. SAR (W/kg) - Head	1.16 W/kg
Max. SAR (W/kg) - Body	1.31 W/kg
HAC (Hearing Aid Compatible) & Rating	M4/T3

HMD Global Oy is the exclusive licensee of the Nokia brand for phones & tablets. Nokia is a registered trademark of Nokia Corporation. Google and other related marks and logos are trademarks of Google LLC. The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by HMD Global is under license.