

dodocool

# Instruction Manual

DA110

## Overview

### EN

- ① Volume down button
- ② Multifunction button
- ③ Volume up button

### DE

- ① Lautstärke- Taste
- ② Multifunktionstaste
- ③ Lautstärke+ Taste

### IT

- ① Pulsante volume giù
- ② Pulsante multifunzione
- ③ Pulsante volume su

### CN

- ① 音量减键
- ② 多功能键
- ③ 音量加键

### FR


- ① Bouton de volume -
- ② Bouton de multifonction
- ③ Bouton de volume +

### ES

- ① Botón volumen -
- ② Botón multifunción
- ③ Botón volumen +

### JP

- ① 音量ダウンボタン
- ② 多機能ボタン
- ③ 音量アップボタン



## EN How to use

Button	Function	Operation
Multifunction button	Power on	When the power is off, press and hold the multifunction button for about 2 seconds.
	Pair	When the power is off, press and hold the multifunction button for about 6 seconds.
	Power off	When the power is on, press and hold the multifunction button for about 5 seconds.
	Answer a call	When there is an incoming call, press the multifunction button once.
	End a call	During a call, press the multifunction button once.
	Reject a call	When there is an incoming call, press and hold the multifunction button for about 1 second.
	Activate voice control function	Press and hold the multifunction button for about 1 second.

## **Federal Communications Commission (FCC) Statement**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Warning:** Changes or modifications made to this device not expressly approved by Shenzhen TOMTOP Technology Co., Ltd. may void the FCC authorization to operate this device.

**Note:** The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.