

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 (1) This device may not cause harmful interference, and
 (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CONTENTS AND SPECIFICATIONS MAY VARY FROM THOSE ILLUSTRATED.
 Manufactured by **33298**
 TANG RONG ROAD,
 CHANGPING, DONGGUAN, CHINA
 All Rights Reserved.
 MADE IN CHINA

VR ENTERTAINMENT LTD.

HOW TO WIN

1 AIM **2 FIRE** **3 HIT**

Press FIRE button to shoot

When hit, the Laser Battle Hunter will make an explosion sound and shake. Number of hit is indicated by how many alert sound that the vehicle made.

3 HITS TO WIN!

To reset and play again: Press and hold the Slide Left Button, Slide Right Button and Fire Button for 3 seconds until a power-up sound is heard.

AUTONOMOUS MODE

Autonomous Mode Makes 1 Laser Battle Hunter a Moving Target for 1 minute

- Take one controller and one Laser Battle Hunter, then set them in ON mode first (refer to page 2).
- Take another set.
 - Slide Laser Battle Hunter's "INDOOR / OFF / OUTDOOR" switch to either INDOOR or OUTDOOR (refer to page 2).
- Wait for the LED Light to stop flashing. Hear Beep sound. The vehicle is in Small Patrol range as the default.
- PATROL RANGES**

 - Small patrol range (default) Hear 1 Beep.
 - Medium patrol range Hear 2 Beeps.
 - Large patrol range Hear 3 Beeps.

There are 3 Auto Patrol Ranges.

 - Small range: around 3ft (around 0.9m)
 - Medium range: around 9ft (around 2.73m)
 - Large range: around 15ft (around 4.6m) (Vary on different surfaces)
- Press the Slide Right Button once to step up to Medium Patrol range (Hear 2 Beeps). Then, press the Slide Right Button one more time to step up to Large Patrol range (Hear 3 Beeps). Press the Slide Left Button once to step down from Large Patrol range to Medium Patrol range (Hear 2 Beeps). Press the Slide Left Button one more time to step down from Medium Patrol range to Small Patrol range (Hear 1 Beep).

After selecting one of the Patrol range, then TO START (OR STOP) AUTO MODE. Press the Fire button of the Auto mode controller to start (or stop) the autonomous action. The Autonomous Laser Battle Hunter will run for 1 minute. Use your ON mode Laser Battle Hunter to shoot the Autonomous Laser Battle Hunter as many times as possible as it moves around and fires at you autonomously.

SCORING

The Autonomous Laser Battle Hunter stops after 1 minute, it will play a series of "beeps"= the number of times the Autonomous Laser Battle Hunter was hit. To play again: Hit the FIRE button of the controller of the Autonomous Laser Battle Hunter and repeat the process.

DECORATION

Use all "S" numbers for Shadow and use all "R" numbers for Reaper. Match the shape and number to the correct location.

Slots: S1-S11, R1-R11

Slots: S1-S11, R1-R11

TROUBLE SHOOTING / HINT

Problem / Question	Solution / Hint
Could not turn the controller on or it is not working properly	Most likely the batteries are too low to be usable. Insert 2 new AA Alkaline batteries. Make sure you move the ON/OFF/AUTO to either ON or AUTO position.
Could not turn the Laser Battle Hunter on or it is not working properly	Most likely the batteries are too low to be usable. Insert 5 new AA Alkaline batteries. Make sure you move the INDOOR/OFF/OUTDOOR to either INDOOR or OUTDOOR. Batteries are installed with incorrect polarities. Check the + and - markings to make sure the batteries are properly aligned.
Could not pair the controller and the Laser Battle Hunter	Get them closer. Try to pair them away from other electronic devices or an internet router and retry again.
Laser Battle Hunter's LED keeps flashing slowly and it cannot be controlled	The Laser Battle Hunter was hit 3 times and lost the battle. Press and hold the Slide Left Button, Slide Right Button and Fire Button for 3 seconds until a power-up sound is heard (refer to page 7).
No drifting	Depending on the various surface of ground. Ease of drifting on slippery surface.

QUICK TIPS
 When your vehicle starts lose power, it may lose functions or performance. It's time for fresh batteries. If your vehicle gets too far away, it won't work properly. Don't drive your vehicle in sand or through water or snow or grass. Don't store your vehicle near heat or in direct sunlight. Always turn switches OFF and remove all batteries for storage.

Cleaning instruction:
 To clean, wipe excess dirt from toy. Remove batteries first. Wipe toy clean with wet cloth using plain water. Then Wipe dry. DO NOT IMMERSIVE IN WATER and DO NOT CLEAN VEHICLE WITH ANY CHEMICALS. Let the toy completely dry before putting Batteries back into clean, dry battery compartment.

5+

LASER BATTLE HUNTERS

RADIO CONTROL

WATCH INSTRUCTIONAL VIDEO
<https://vr-entertain.com>
 click SUPPORT

INSTRUCTION MANUAL

START HERE

Controller

- Turn "ON/OFF/AUTO" switch to the OFF position
- Open the battery compartment cover by loosening the screw counter-clockwise
- Insert 2x1.5V AA batteries (not included) following the correct polarity
- Replace the battery compartment cover by tightening the screw clockwise

Laser Battle Hunter

- Slide the "INDOOR / OFF / OUTDOOR" switch to the OFF position
- Open the battery compartment cover by loosening the screw (turn counter-clockwise) and insert 5x1.5V AA batteries (not included) following the correct polarity
- Replace the battery compartment cover and tighten the screw. (turn clockwise)

INDOOR / OFF / OUTDOOR

SYNC THE CONTROLLER

- Turn controller on: Slide the "ON/OFF/AUTO" switch to the ON position.
- Turn the Laser Battle Hunter on: Decide if the Laser Battle Hunter will be used indoors or outdoors. Slide the switch to either INDOOR or OUTDOOR.

NOTE: Attack range will be decreased in the INDOOR mode to minimize signal reflection

NOTE: Autonomous Drive Mode switch position See page 8 for instructions

Repeat to sync another controller with another Laser Battle Hunter (up to 8 Laser Battle Hunters)

BASIC DRIVE / BASIC SPIN

Forward

Reverse

Spin Left

Spin Right

BASIC SLIDE

PRESS LEFT OR RIGHT BUTTONS

Slide Left

Slide Right

ADVANCED MOVES

Forward Left Turn

Backwards Left Turn

Forward Right Turn

Backwards Right Turn

HOW TO ATTACK

Front + Sides are Safe Zones

Attack Zone
 Aim to the rear of opponent Laser Battle Hunter

Attack from behind
 Aim here at the rear of opponent Laser Battle Hunter

Defend with front & Sides
 Turn towards your opponent to defend your Laser Battle Hunter

Infrared shooting distances vary depending on the lighting conditions the vehicles are operating in. The stronger the light (such as direct sunlight indoor or outdoor), the less the shooting range distance will be. In strong light try to get closer to take a shot to get a more powerful shot at your opponent.