

FRONT

ijoy KARAOKE CLUB

SPEAKER AND MICROPHONE
FCC ID: 2AJ074JSP2388



for use with
Bluetooth
enabled devices

USER
MANUAL

•FCC ID STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

•BATTERY CAUTION

The battery used in this device may present a risk of fire, explosion or chemical burn if used incorrectly. Never use or charge the battery if it appears to be leaking, discolored, deformed or in any way abnormal. Never disassemble the unit or attempt to remove the battery as that could cause leakage of alkaline solution or other electrolytic substances. Never expose the battery to any liquid. Never expose the battery to excessive heat such as direct light or fire. Always keep the battery out of the reach of infants and small children.

•BATTERY DISPOSAL

Please do not attempt to change the battery yourself. If the battery has died, you should follow the disposal instructions listed here. Never dispose of used batteries/electronics with ordinary solid wastes. Always dispose of used batteries/electronics in accordance with the prevailing community regulations that apply to the disposal of batteries/electronics. If there are no local regulations concerning battery/electronics disposal, please dispose of the device in a waste bin for electronic devices. Many electronics retailers now recycle batteries and other electronic components at no charge.

•YOUR IJOY PRODUCT

Thank you for purchasing and using the "IJOY KARAOKE CLUB" wireless Bluetooth® speaker and microphone. This product can provide a high quality karaoke experience for your parties. Before using this product, carefully read this manual to correctly operate this device. Please ask your local dealer if you have any questions.

IJOY KARAOKE CLUB X 1
Wired Microphone x 1
Charging Cable X 1
User Manual X 1

•SPECS

Impedance: 3 Ohm
S/N: ≥80db
Separation: ≥45db
Bluetooth®: 5.0
Distortion: ≤1.0%
Frequency response: 150Hz-18KHz
Bluetooth® range: 32ft
USB & TF maximum memory supported: 32GB
FM radio: 87.5-108.0MHz
Battery capacity: Built-in 600mAh
Battery type: Li-ion
Play time based on 50% volume: 2.5 hours
Charging voltage: DC 5V

BACK


•DEVICE FUNCTIONS

FUNCTIONS

- **ON/OFF button:** To turn on or off.
- **Charging cable is Micro DC5V.**
- **Microphone jack.**
- **Play music from a USB stick by inserting a USB stick into the USB port.** Supports MP3 format.
- **Play music from a TF card by inserting a TF card into the TF card port.** Supports MP3 format.
- **MODE button:** Press to go to FM radio mode/Bluetooth mode.
- **Press the button:** For Bluetooth®/TF/USB modes: to play/ pause music.

For Bluetooth®/TF/USB modes: to play/ pause music.
For FM mode: to select radio station. Press and hold to scan and pre-record the radio stations. You may pick from pre-recorded radio stations afterwards. This will take a few minutes.

- **Press the /- button:** For Bluetooth®/TF/USB/FM modes: move to previous track/ channel. Press and hold to lower volume.
- **Press the /+ button:** For Bluetooth®/TF/USB/FM modes: move to next track/ channel. Press and hold to raise volume.



•OTHER IMPORTANT SAFETY INFORMATION

To avoid danger of choking, please keep cables away from babies and children. This product is not a toy. Do not treat this product as household waste. Dispose of this device properly by handing it over to local collection services for recycling of electronic equipment. By ensuring that this product is properly disposed of, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling. For more detailed information about this product, please contact your local household waste disposal service or the shop where you purchased this item.



•INSTRUCTIONS

PAIRING THE DEVICE

- The speaker will automatically enter pairing mode when turned on. Enable Bluetooth® on the device you want to connect the speaker to and connect your device to IJOY KARAOKE CLUB.

TRUE WIRELESS STEREO FUNCTION (requires 2 KARAOKE CLUBS)

- TWS allows you to sync 2 KARAOKE CLUBS. Make sure neither are connected to any device. Power on both and make sure they are in Bluetooth® mode. Press and hold the MODE button.

CHARGING

- Connect the charging cable with KARAOKE CLUB and an appropriate charging source. A red LED light will indicate that it is charging.

•ONE (1) YEAR LIMITED WARRANTY

Our product is warranted for a limited lifetime warranty from the date of purchase. The warranty is provided on all material defects and workmanship. Guarantee of 12 months does not apply to decrease in the effective capacity caused by its use or age. WE RESERVE THE RIGHT TO CHANGE TECHNICAL SPECIFICATIONS. For more information please visit, www.goijoy.com.

Distributed by
Quest USA Corp.
495 Flatbush Ave Brooklyn, NY 11225

© GOIJOY & IJOY are registered trademarks of Quest USA Corp. All other trademarks and trade names are property of their respective owners. Designed by GOIJOY & IJOY in New York. All rights reserved Quest USA Corp. One (1) year limited warranty. To activate your product warranty go to our website www.goijoy.com & register this product.

Made in China.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by QUEST USA CORP. is under license. Other trademarks and trade names are those of their respective owners.

PLEASE FOLD ON THE GREEN LINES AND PRINT DOUBLE SIDED. DO NOT PRINT GREEN LINES