



LOGO Premium Active Bluetooth Neck-Band Headphone Instruction

Welcome use

Welcomed select the IJOY LOGO premium active Bluetooth neck-bank headphone, the product can provide high quality listening enjoyment for your computer, mobile phone, and multimedia. Before using this product, carefully read this manual to correctly manipulate and play its best performance. If somewhere puzzled, please ask your local dealer or call us.

Notice

Do NOT expose product to extreme temperatures, moisture or electric shock.

Do NOT attempt to open the unit for any reason.

Do NOT attempt to manipulate any electrical components in the unit. Doing so will invalidate any implied or written warranty and will release us from any liability related to product.

Do NOT attempt to use if internal components have been exposed to liquid. This notice serves to release us from any liability for damages caused by use of product following exposure to liquid.

Keeping unit on when not in use will shorten the lifespan of the battery. Please use responsibly.

Package Contents

- 1- Bluetooth Headphone -----1pcs
- 2- Micro USB Charging Cable -----1pcs
- 3- Back-up ear pieces -----2sets
- 4- User Instruction -----1pcs

Specifications

Bluetooth: 4.1

Battery: 3.7V 120mAh


Standby/talk: 300 hrs/ 6hrs

Playback time: 6 hrs

Charge time: 1.5 hrs

Working Distance: 10M

Keys Description



1. Switch power button to the “on” direction to turn on the headphone; IJOY LOGO headphone vibrates, and you will hear a short prompt. Switch power button to the “off” direction to turn off the headphone. You will also hear a prompt with vibration.
2. When incoming phone calls, press IJOY LOGO headphone’s “Answer/ Redial” button to answer a call. Press same button to hang up a call. Press “Answer/ Redial” button for twice to redial last number.
3. Press “Volume +” button to increase volume.
4. Press “Volume –” button to decrease volume.
5. Press “Pause/ Play” button to pause a song during music play. And press it again to continue.
6. Press “Next Track” button for next song.
7. Press “Last Track” button for previous song.

Bluetooth Headphone Pairing

Turn on the IJOY LOGO headphone by switching the power button to “on” direction, headphone vibrates, and you will hear a short prompt. Turn Bluetooth on using your phone or audio device and search for “IJOY LOGO” in the Bluetooth device list, and pair it. There will be a short prompt played as soon as pairing is successful.

Bluetooth Headphone Charging

IJOY LOGO headphone is with built in battery, can portable use, when the headphone automatically shut down during playing music, means power is to run out, needs to be charged. Connect a micro USB cable to a 5V 1A power source to charge the unit. Red indicator will be on when charging, and changes to blue once completion of charging.

Troubleshooting

Failure to connect to a Bluetooth-enabled device can be caused by any of the following:

Other Bluetooth devices are in pairing or sync mode and are interfering with your connection. Please remove other devices from the vicinity or turn them off.

Static or muffled sound can be caused by any of the following:

There are major Bluetooth obstructions between your device and the headphone.

You have extended the headphone beyond the recommended distance between devices.

Product Warranty

This product comes with a limited one year warranty from date of purchase. This warranty covers any product failures and offers a replacement guarantee. We will replace this product if it fails within 1 year of purchase date. All warranties are handled by the Authorized Reseller. Please retain your receipt. Please contact your authorized reseller with the receipt to process a replacement.

This replacement guarantee does not imply any liability for any product-related damages. Please use responsibly.

See more online: www.goijoy.com

Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by QUEST USA CORP may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.