

BAZOOKA SPEAKER

BOOKLET SIZE:  
2in. x 2in.

FINISHES:  
Stock paper:110 gms glossy;  
Page Right-Angle Fold.



DIELINE

COMMENTS:

FRONT



BAZOOKA

WIRELESS BLUETOOTH®  
SPEAKER WITH LIGHTSHOW



for use with

 Bluetooth®

enabled devices

FCC ID: 2AJQ7BAZOOKA  
MODEL: IJSP210137

USER

MANUAL

Distributed by Quest USA Corp.  
495 Flatbush Ave Brooklyn, NY 11225

© GOIJOY & IJOY, are registered trademarks of Quest USA Corp. All other trademarks and trade names are property of their respective owners. Designed by GOIJOY & IJOY in New York. All rights reserved Quest USA Corp. One (1) year limited warranty. To activate your product warranty go to our website [www.goijoy.com](http://www.goijoy.com) & register this product.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by QUEST USA CORP. is under license. Other trademarks and trade names are those of their respective owners.

Made in China.

YOUR IJOY PRODUCT

Thank you for purchasing and using the “IJOY BAZOOKA” Wireless Bluetooth® Speaker With Lightshow. This product can provide a high-quality listening experience for your mobile phone, computer, and other media devices. Before using this product, carefully read this manual to operate this device correctly. Please ask your local dealer if you have any questions.

CONTENTS

- 1 True Wireless Speaker
- 1 Micro-USB Charging Cord
- 1 User Manual
- 1 Aux Cord

SPECIFICATIONS

- Bluetooth® version: 5.0
  - Operating distance: 33 ft.
  - Battery: 3.7V 1200mAh
  - Input: Micro-USB: 5V 1A
  - Output: USB-A: 5V 0.2A
  - Playtime: 5 hours by 50% volume
  - Charging Time: 8-10 hours
  - Power: 10W
  - Material: Plastic
- Inputs: Microphone port; AUX port; USB-A port; TF card port
  - Functions: Bluetooth®; FM Radio; LED light Lightshow

USE PRECAUTIONS

1. Avoid using harmful substances, like organic solvents or detergents containing these ingredients to clean the speaker.
2. To ensure a smooth connection, we recommend that your device and the speaker’s maximum distance is within a 10-meter (33 feet) radius. Use it according to our precautions, advice and product directions and pay attention to the influence of the environment while using the speaker.
4. If the Speaker is not connecting or the communication is not smooth, etc., please do not disassemble any part of this item or its accessories, so you don’t lose the warranty.
5. Please use the standard wall or car USB charger to recharge the speaker battery.
6. To ensure that you use the speaker at its best range, make sure that it is fully charged.

**Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**


BACK

MULTIUSE PANEL (PRODUCT INPUTS & CONTROLS)

The inputs allow you to maximize your connectivity options so you can stream your music from the source of your choice, ant the product controls are simple, the BAZOOKA SPEAKER contains 4 main buttons and a knob, so your interaction is direct and intuitive.

The list below will help you understand how to interact with IJOY’s BAZOOKA sound system:

1. TF Card Input Port\*
2. Micro-USB Charging Port (5V 1A)
3. Microphone Port (MIC. IN)
4. LED Display
5. USB-A Input Port\*
6. Auxiliary Port (AUX)
7. Volume Knob (On/Off)
8. Mode Button
9. Playback Button
10. Forward Button
11. Play / Pause Button



\*MP3 format supported

ON/OFF

To turn it ON you should rotate the Volume Knob (7) clockwise. To turn it off you should rotate the Volume Knob (7) counter clockwise.

BLUETOOTH® PAIRING

Turn ON the speaker and make sure it is in Bluetooth® mode, if needed, use the Mode Button (8) to navigate through the product input options. Find the corresponding name (IJOY BAZOOKA) from the Bluetooth® list on your device and click pairing. To change to another Bluetooth® able device, Please disable the Bluetooth® connection on your 1st device and repeat the process described above with the new device.

CHARGING

Connect the charging cable to the speaker’s Micro-USB charging port (2), insert the other end to a 5V adapter (not included).

MUSIC CONTROLS

When playing music through Bluetooth®, AUX-IN, TF Card Input, or USB-A Input: Press the Play/Pause Button (11) to pause the music, press it again to continue playing. To navigate through the product input options please press the Mode Button (7) every time you want to listen from a different source. Press the Playback Button (9) to play the previous song; press the Forward Button (10) to play the next. Rotate the Volume Knob (7) clockwise to increase volume. To Low Volume you should rotate the Volume Knob (7) counter clockwise. Pay attention and don’t rotate the knob to its minumum volume range to avoid turning it Off.

OTHER IMPORTANT SAFETY INFORMATION

To avoid danger of choking, please keep cables away from babies and children. This product is not a toy.

Do not treat this product as household waste. Dispose of this device properly by handing it over to local collection services for recycling of electronic equipment. By ensuring that this product is properly disposed of, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handing. For more detailed information about this product, please contact your local household waste disposal service or the shop where you purchased this item.



ONE (1) YEAR LIMITED WARRANTY

Our product is warranted for a One (1) year limited warranty from the date of purchase. The warranty is provided on all material defects and workmanship. Guarantee of 12 months does not apply to decrease in the accumulator’s effective capacity caused by its use or age. Effective capacity gradually decreases depending on the method of use of the accumulator. WE RESERVE THE RIGHT TO CHANGE TECHNICAL SPECIFICATIONS. For more information please visit, [www.goijoy.com](http://www.goijoy.com)

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
1 - This device may not cause harmful interference, and  
2 - this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.  
Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
Consult the dealer or an experienced radio/TV technician for help.  
RF warning statement:  
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.  
FCC ID: 2AJQ7BAZOOKA