


FRONT

ijoy 10W WIRELESS CHARGER
GEODE



WIRELESS CHARGER
USER MANUAL

© GOLJOY & IJOY are registered trademarks of Quest USA Corp. All other trademarks and trade names are property of their respective owners. Designed by GOLJOY & IJOY in New York. All rights reserved Quest USA Corp. One (1) year limited warranty. To activate your product warranty go to our website www.goljoy.com & register this product.

Distributed by Quest USA Corp.
495 Flatbush Ave, Brooklyn NY 11225

Made in China.

NOTE: Attachments on the back of your phone can impede the effectiveness of the wireless charger, and lead to overheating. Please remove attachments from the phone before charging on this device.

People who use a heart pacemaker should consult a doctor before using this product, and leave the charger at a distance of 22cm from the pacemaker. Electromagnetic waves can influence the effectiveness of the pacemaker.

USING YOUR PRODUCT

- Plug the other end into an available USB port on your computer or a suitable USB wall adapter.
- Place your Qi compatible smartphone on the charging surface of the wireless charger.
- For best results, make sure that your phone is as close to the center of the charging surface as possible.
- Remove your phone from the charging surface once charging is complete.

YOUR PRODUCT

Thank you for purchasing and using this wireless charger. This product can provide a high quality charging experience for your mobile phone. Before using this product, carefully read this manual to correctly operate this device. Please ask your local dealer if you have any questions.

1 wireless charger
1 user manual

PRODUCT SPECIFICATIONS

Inputs: DC 5V/2A, 9V/2A
Output: 10W (Max)
Charging Efficiency: >75%
Charging Distance: ±8mm
Frequency: 113~205KHz

Before attempting to use this, ensure that your mobile device is Qi compatible and supports wireless charging.

Compatible with: iPhone 8 and above
Samsung Galaxy Note 5, Samsung Galaxy S7 Edge, Samsung Galaxy S8, Samsung Galaxy S8+, Samsung Galaxy S6, Samsung Galaxy S6 Edge, Nokia 1520, Nexus 6LG

Devices needing reserved wireless charging interface (not included) next to battery to work with charger: Samsung Galaxy S3/S4/S5/Note2/Note3/Note4, etc.

All devices must conform to Qi standard.

BACK

INSTRUCTIONS

- Never expose your wireless charger to high temperatures, extreme cold, high humidity, or any moisture or water.
- Do not let dust or other materials accumulate on the product.
- Do not charge in places where the sun shines directly or in high temperature.
- Do not lay magnetic cards or magnetic devices on the charger.
- Power off before cleaning.
- In order to avoid the risk of electronic shock, never attempt to open your charger or repair it without the assistance of certified professionals.
- Your wireless charger is not recommended for use by children without adult supervision.
- When your smartphone is fully charged, remove it from the charger to avoid overcharging.
- Do not use your wireless charger at temperatures under 5°C or over 35°C.
- Do not drop your wireless charger, throw it, or subject it to strong physical impact. When charging, do not place your charger on flammable materials such as rugs, carpets, or bedding for safety.
- Only place Qi compatible phones on the surface of your charger. The use of incompatible phones can cause your charger to overheat and damage it.
- Your charger may cause interference to radio equipment and should not be installed near maritime safety communications equipment or other critical navigation or communication equipment operating between 0.45~30MHz.
- Please recycle or dispose of your wireless charger properly based on the laws and rules of your municipality.
- Make sure the charger is unplugged before cleaning it.

OTHER IMPORTANT SAFETY INFORMATION

To avoid danger of choking, please keep cables away from babies and children. This product is not a toy. Do not treat this product as household waste. Dispose of this device properly by handing it over to local collection services for recycling of electronic equipment. By ensuring that this product is properly disposed of, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling. For more detailed information about this product, please contact your local household waste disposal service or the shop where you purchased this item.

FCC STATEMENT FCC ID: 2A1Q7GE00E

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.

ONE (1) YEAR LIMITED WARRANTY

Our product is warranted for a one (1) year limited warranty from the date of purchase. The warranty is provided on all material defects and workmanship. Guarantee of 12 months does not apply to decrease in the accumulator's effective capacity caused by its use or age. Effective capacity gradually decreases depending on the method of use of the accumulator. WE RESERVE THE RIGHT TO CHANGE TECHNICAL SPECIFICATIONS. For more information please visit, www.goljoy.com

PLEASE FOLD ON THE GREEN LINES AND PRINT DOUBLE SIDED. DO NOT PRINT GREEN LINES