



# FRONT

# BACK

<p><b>ijoy MUSE</b> FOLDABLE WIRELESS HEADSET FCC ID: 2AJQ/MUSE</p>  <p>for use with Bluetooth enabled devices</p> <p><b>USER MANUAL</b></p>	<p><b>FCC STATEMENT:</b> This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p><b>NOTE:</b> This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following:</p> <ul style="list-style-type: none"><li>• Reorient or relocate the receiving antenna.</li><li>• Increase the separation between the equipment and receiver.</li><li>• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</li><li>• Consult the dealer or an experienced radio/TV technician for help.</li></ul> <p>Changes or modifications not expressly approved by iJOY could void the user's authority to operate this equipment.</p> <p><b>Warning statement:</b> The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restrictions.</p>
<p><b>•YOUR IJOY PRODUCT</b></p> <p>Thank you for purchasing and using the "iJOY MUSE" wireless Bluetooth® foldable headset. This product can provide a high quality listening experience for your mobile phone, computer and other media devices. Before using this product, carefully read this manual to correctly operate this device. Please ask your local dealer if you have any questions.</p> <p>Model No.: LHPMSE01/LHPMSE02/LHPMSE03</p> <p>MUSE Foldable Wireless Headset X1 Charging Cable X1 User Manual X1</p> <p><b>•SPECS</b></p> <p>Bluetooth® version: 5.0 Operating distance: 32 ft Playtime: Up to 5 hours Charging time: About 1 hour Frequency: 20Hz-20KHz Impedance: 32Ω Battery Capacity: 200mAh Input: 5V, 500mA</p>	<p><b>•BATTERY CAUTION</b></p> <p>The battery used in this device may present a risk of fire, explosion or chemical burn if used incorrectly. Never use or charge the battery if it appears to be leaking, discolored, deformed or in any way abnormal. Never disassemble the unit or attempt to remove the battery as that could cause leakage of alkaline solution or other electrolytic substances. Never expose the battery to any liquid. Never expose the battery to excessive heat such as direct light or fire. Always keep the battery out of the reach of infants and small children.</p> <p><b>•BATTERY DISPOSAL</b></p> <p>Please do not attempt to change the battery yourself. If the battery has died, you should follow the disposal instructions listed here. Never dispose of used batteries/electronics with ordinary solid wastes. Always dispose of used batteries/electronics in accordance with the prevailing community regulations that apply to the disposal of batteries/electronics. If there are no local regulations concerning battery/electronics disposal, please dispose of the device in a waste bin for electronic devices. Many electronics retailers now recycle batteries and other electronic components at no charge.</p>
<p><b>•DEVICE FUNCTIONS</b></p> <p><b>CALL FUNCTION</b></p> <ul style="list-style-type: none"><li>• Answering/Ending a call: Press <b>Ⓛ</b> once</li><li>• Rejecting a call: Press and hold <b>Ⓛ</b></li></ul> <p><b>ADJUSTING VOLUME AND CONTROLLING MUSIC PLAYBACK</b></p> <ul style="list-style-type: none"><li>• Press <b>Ⓛ</b> once: Bluetooth® or TF card: Play/Pause Music Radio: Search through radio stations</li><li>• Press <b>Ⓜ</b>/<b>V</b> once: Bluetooth® or TF card: Previous Song Radio: Previous Radio Station</li><li>• Press and hold <b>Ⓜ</b>/<b>V</b>: Decrease Volume</li><li>• Press <b>V</b>/<b>Ⓜ</b> once: Bluetooth® or TF card: Next Song Radio: Next Radio Station</li><li>• Press and hold <b>V</b>/<b>Ⓜ</b>: Increase Volume</li><li>• Press and hold <b>M/EQ</b>: Switch to radio, Bluetooth®, or TF card mode</li><li>• Press <b>M/EQ</b> once: Switch to sound effect in turn</li></ul>	<p><b>•OTHER IMPORTANT SAFETY INFORMATION</b></p> <p>To avoid danger of choking, please keep cables away from babies and children. This product is not a toy. Do not treat this product as household waste. Dispose of this device properly by handing it over to local collection services for recycling of electronic equipment. By ensuring that this product is properly disposed of, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling. For more detailed information about this product, please contact your local household waste disposal service or the shop where you purchased this item.</p> 
<p><b>•INSTRUCTIONS</b></p> <p><b>POWERING ON/OFF</b></p> <ul style="list-style-type: none"><li>• Press and hold <b>Ⓛ</b>/<b>M</b> for 3 seconds to turn on. It should automatically go to pairing mode. Lights should flash.</li><li>• Press and hold <b>Ⓛ</b>/<b>M</b> for 3 seconds to turn off. It will also turn off if Bluetooth® has been off for 5 minutes.</li></ul> <p><b>PAIRING YOUR PRODUCT.</b></p> <ul style="list-style-type: none"><li>• Place the headset within 32 ft of a Bluetooth® enabled device. Enable Bluetooth® on the device you want to connect the headset to and search for "iJOY MUSE". Select "iJOY MUSE" to connect. The headset will automatically connect to this same device next time both items are turned on.</li></ul> <p><b>CHARGING</b></p> <ul style="list-style-type: none"><li>• Use the charging cable provided to charge the headset. Connect the cable to the port of the headset.</li></ul> <p><b>RESET</b></p> <ul style="list-style-type: none"><li>• If the headset suddenly doesn't work, press <b>Ⓛ</b>/<b>M</b> for 8 seconds.</li></ul> <p><b>YOU CAN USE THE HEADSET WITH A 3.5 MM AUDIO CABLE(not included).</b></p>	<p><b>•LIMITED LIFETIME WARRANTY</b></p> <p>Our product is warranted for a limited lifetime warranty from the date of purchase. The warranty is provided on all material defects and workmanship. Guarantee of 24 months does not apply to decreases in the effective capacity caused by its use or age. WE RESERVE THE RIGHT TO CHANGE TECHNICAL SPECIFICATIONS. For more information please visit, <a href="http://www.goljoy.com">www.goljoy.com</a>.</p> <p>Tip: Must choose the formal manufacturer certified charger, output voltage of 5V. If the product is not in use for a long time, please charge it.</p> <p>Quest USA CORP 495 Flatbush Ave. Brooklyn, NY 11225</p> <p>© Goljoy &amp; iJOY are registered trademarks of Quest USA Corp. All other trademarks and trade names are property of their respective owners. Designed by GOIJOY &amp; IJOY in New York. All rights reserved. Limited lifetime warranty. To activate your product warranty, go to our website <a href="http://www.goljoy.com">www.goljoy.com</a> &amp; register this product.</p> <p>Made in China.</p>

**PLEASE FOLD ON THE GREEN LINES AND PRINT DOUBLE SIDED.  
DO NOT PRINT GREEN LINES**