

PRINT ARTWORK ON DIRECTLY ON PAPER.
DO NOT PRINT RED FOLD AND CUT LINES. OPEN USER MANUAL DIMENSIONS: 6.46"W x 5.5" H




FOLD LINE



CUT LINE

ijoy

IJOY TEMPO WIRELESS SPEAKER



FCC ID: 2AJQ7TEMPO

for use with
 enabled devices

**USER
MANUAL**

•YOUR IJOY PRODUCT

Thank you for purchasing and using the "IJOY TEMPO" LED Wireless Speaker. This product can provide a high quality listening experience through phones, computers, and multimedia. Before using this product, carefully read this manual to in order to operate at maximum benefit. Please ask your local dealer or call us if you have any questions.

IJOY TEMPO x 1
Charging Cable x 1
User Manual x 1

•PRODUCT SPECIFICATIONS

- PLAYTIME: 100% VOLUME - 4 HRS; 50%- 8 HRS
- CHARGE TIME: 2-3HRS
- BATTERY CAPACITY: 3.7V/500MAH
- FEATURES: BT/TF/USB/LED/FM/TWS
- NUMBER OF LEDES: 5
- LED TYPE/MODES: 5 LED MODES
- NO MICROPHONE INCLUDED
- OUTPUT POWER: 3W
- INPUT: 5V
- MATERIAL: PP
- BLUETOOTH VERSION: 5.0
- BLUETOOTH RANGE: 10M

•FCC ID STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected,
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

•BATTERY CAUTION

The battery used in this device may present a risk of fire, explosion or chemical burn if used incorrectly. Never use or charge the battery if it appears to be leaking, discolored, deformed or in any way abnormal. Never disassemble the unit or attempt to remove the battery as that could cause leakage of alkaline solution or other electrolytic substances. Never expose the battery to any liquid. Never expose the battery to excessive heat such as direct light or fire. Always keep the battery out of the reach of infants and small children.

•BATTERY DISPOSAL

Please do not attempt to change the battery yourself. If the battery has died, you should follow the disposal instructions listed here. Never dispose of used batteries/electronics with ordinary solid wastes. Always dispose of used batteries/electronics in accordance with the prevailing community regulations that apply to the disposal of batteries/electronics. If there are no local regulations concerning battery/electronics disposal, please dispose of the device in a waste bin for electronic devices. Many electronics retailers now recycle batteries and other electronic components at no charge.

•FEATURES

- MULTI-LED LIGHTS
- UNIQUE DESIGN
- SUPER BASS
- TWS TECHNOLOGY

•PAIRING BLUETOOTH & PLAYING AUDIO

1. Power on the speaker, you will hear "beep" sound. The LED indicator will display blue quick flash and ready to pair. When pairing, remain within 3 feet of the unit.
2. Using the controls on your Bluetooth device, select IJOY TEMPO in the Bluetooth Settings to pair. A another "beep" sound will be heard when the device is connected successfully, and the LED indicator will display a solid blue light.
3. Use the controls on the connected Bluetooth device to select and begin playing audio. Use the controls on the device or the speaker to play, pause, skip tracks or adjust volume.

•OTHER IMPORTANT SAFETY INFORMATION

Disposal of old electronic & electronic equipment (Applicable in the European Union and other European Counties with separate collection systems) The trash can symbol (seen on the bottom) on the production indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for recycling of electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling. For more detailed information about this product, please contact your local household waste disposal service or the shop where you purchased this item.



TIP: Must use a formal manufactured certified charger. If the power bank has not been used for a significant amount of time, please make sure to charge before using the product.

•WARNING



At full volume, prolonged listening may lead to a ruptured eardrum (temporary or permanent deafness, hearing drone, tinnitus, hyperacusis). Please listen at a medium-low volume and no more than one hour a day

Please insert the proper battery needed correctly to prevent explosion.

•KEY FUNCTIONS

- 1-Press to switch between Bluetooth and FM. You can switch to TF or USB if connected.
- 2-Press to switch to the previous track. Press and hold to decrease the volume.
- 3-Press to play or pause the music. Double press to connect TWS function.
- 4-Press to switch to the next track. Press and hold to increase the volume.
- 5-Press to switch LED mode

- 6-USB charging port
- 7-Power button
- 8-TF input
- 9-USB input



•ONE (1) YEAR LIMITED WARRANTY

Our product is warranted for a One (1) year limited warranty from the date of purchase. The warranty is provided on all material defects and workmanship. Guarantee of 12 months does not apply to decrease in the accumulator's effective capacity caused by its use or age. Effective capacity gradually decreases depending on the method of use of the accumulator. **WE RESERVE THE RIGHT TO CHANGE TECHNICAL SPECIFICATIONS.** For more information please visit, www.gojoy.com

Distributed by
Quest USA Corp.
495 Flatbush Ave Brooklyn, NY 11225

© GOJOY & IJOY are registered trademarks of Quest USA Corp. All other trademarks and trade names are property of their respective owners. Designed by GOJOY & IJOY in New York. All rights reserved Quest USA Corp. One (1) year limited warranty. To activate your product warranty go to our website www.gojoy.com & register this product.

Made in China.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by QUEST USA CORP. is under license. Other trademarks and trade names are those of their respective owners.