


short manual

iRTT-RU

indurad RadioTransponderTag-RechargeUnit
Inductive recharge unit

email documentation@indurad.com **version** 2 **date** 26-Apr-22



Product description

The indurad RadioTransponderTag-RechargeUnit (iRTT-RU) is designed for inductive charging of the indurad RadioTransponderTag-ClientPersonnel (iRTT-CP) tags of the third generation. The charging trays are designed to fit into a CribMaster. 3 color LED is available for status and condition indication. Automatic status monitoring is available through CAN interface.

Installation and Operation Procedures

The iRTT-RU is part of a customer-specific system. A separate user manual is provided according to the customer project's requirements. Please refer to the project specific manual for instructions.

Regulatory Information

FCC ID: 2AJRSIRTRU

IC: 21407-IRTRU

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s) and complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation of the device.

Changes or modifications made to this equipment not expressly approved by indurad GmbH may void the FCC authorization to operate this equipment.

Radiofrequency radiation exposure Information:

This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. L'appareil ne doit pas produire de brouillage.
 2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
- The iRTT-RU is part of a customer-specific system. A separate user manual is provided according to the customer project's requirements. Please refer to the project specific manual for instructions.

Les changements ou modifications apportés à cet équipement non expressément approuvés par indurad GmbH peuvent annuler l'autorisation FCC d'utiliser cet équipement.

Cet équipement est conforme aux limites d'exposition aux radiations fixées par la FCC et l'IC pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.

Contact: **email** automation@indurad.com | **web** indurad.com