

BEFORE YOU START

Note:

- 1. Children under the age of 13 are not permitted to create a HiMirror account.
- 2. Make sure HiMirror Slide is placed on a flat and even surface.

HiMirror Slide must be installed within the range of a WiFi network

HiMirror Slide must be constantly connected to your WiFi network

GETTING STARTED

- 1. Connect HiMirror Slide to a power outlet using the power adapter.*
- 2. Push the power button to turn on HiMirror Slide.
- 3. Slide the panel to the right to open and use HiMirror Slide.
- 4. Follow the on-screen instructions to complete setup.

*Note: HiMirror Slide must be plugged into a power outlet at all times.

OPTIMAL ENVIRONMENT CONDITIONS

Light Source

For best results, make sure that the light sources around your HiMirror Slide are even and your face is not partially shadowed. Please refer to the following instructions when the light source is not adequate for HiMirror Slide.

- A. Strong backlight, such as a large window. Suggestion: Close the blinds or curtains.
- B. Uneven indoor lighting, such as a light source shining on one side of your face.
 Suggestion: Adjust the light's direction, or turn the light off.

C. Multiple light sources. Suggestion: Leave only the light source in front of you and turn the other lights off.

Temperature / Humidity

Power Adapter



Operation: 5°~35°C; 30%~80% RH Storage & Transportation: -20°C~60°C; 0~90% RH

Input AC: 100-240V~50/60Hz, 0.7A Output DC: 12V/2A, 24W

Address: 20191 Windrow Dr., Suite B Lake Forest, CA 92630, USA Toll-free Number: +1-855-999-3348









