




How to use Smart Cabinet Lock

1. Check the connection status with your SCL.




2. Touch the red circle on the screen once to open the door.



Other features



1. You can check the usage history by August app.



2. You can invite guest and manage the registered users.



3. Touch the green circle on the screen once to lock the door.






How to open an emergency



If the child is trapped in the drawer, the door opens when the luminescent emergency button is pressed.

How to delete SCL in August app



1. Click the Setting icon at the bottom and click the 'Lock Settings' section.
2. When you scroll down, there is a 'Factory Reset' menu.
3. Leave the SCL next to you and click the 'Reset Lock' button.
4. After removing the lock from the app, reset the SCL by unplugging the battery.

The world's favourite lock

ASSA ABLOY Opening Solutions Korea
08502
10F of JEI PLATZ Bldg., 186, Gasandigital 1-ro,
Geumcheon-gu, Seoul, Korea
Phone +82 2 1644 3526 (3525)
Fax +82 2 839 2297
e-mail: overseas.unlock@assaabloy.com
www.unilock.co.kr


Smart Cabinet Lock

Installation Instructions


The world's favourite lock



Smart Cabinet Lock Composition



Smart Cabinet Lock Assembly




Preparation before use

Download August App



* Supported Bluetooth Version - 4.0

A. How to insert the CR2 Battery into SCL Body



1. Open the cover by pressing the battery cover slightly.


2. Insert the CR2 battery.

* The battery can be used for about 1 year.

Battery life may vary depending on the amount of use and the environment.

How to register in August App

1. Run the app with the SCL ready to register.




2. Create your account and verify your phone and email.

4. Select the 'Set up a lock connected by August', then click 'Set up a Yale smart lock'. Skip the 'Install Smart Lock' section.

5. Click the 'Start' button. Make sure you're near your SCL and the battery is installed. Click the 'Start Setup' button.

6. Create a name for your SCL and select the house you want to add this lock to.



7. Your SCL has been registered.

FCC Compliance Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.