

LOCATE WITH SOUND. Ring the PowerPack from the app.

LAST PLACE SEEN.

The app always shows the last time and place it saw your PowerPack.

COMMUNITY FIND.

If your PowerPack is not where the app last saw it, Tile' s global network can update you with its latest location.



How to set up the Blutetooth tracking function (1) Download Tile App (2) Add the Tile option of the Nomad(3) Click the button to connect the App

> Original Keys, bags, bikes & more Slim Wallets, laptops & more Mate Keys, bags, bikes & mbre Romad

> > Buy Tile



after setup: (1)Ring lost items from your phone. If powerpack is within the 100-foot Bluetooth range, it will play a loud tune until you find it. (2)Double press the button to make your lost phone ring—even on silent.
(3)If your powerpack isn't where you last had it, select "Notify When Found" in the app and when any device in the Tile community simply passes by your missing item, you'll automatically be notified of its most recent location.

(4)Always keep the app running in the background, and Tile will automatically remember the last time and place you last had your item so you know where to start looking.



1x Type C input :5V/3A 1 x Type C output : 5V 3A, 9V/12V 2A, QC 2.0 1 x Type A output: 5V/2.4A

LEARN MORE tile explained.hellonomad.com

SUPPORT support@hellonomad.com

WARRANTY

Nomad is solely responsible for the warranty of PowerPack and the Tile Bluetooth module. The PowerPack is warrantied for 2 years .

LEGAL

Nomad and the Nomad logo are trademarks of Nomad Goods, Inc. 2016 Registered in the U.S. and other countries. Patents pending.


The Tile and Tile design are trademarks of Tile, Inc.

iPad, iPhone, iPod nano, and iPod touch are trademarks of Apple Inc., registered inthe U.S. and other countries. Lightning is a trademark of Apple Inc.

ΝΟΜΛΟ

Back





Front