

**Properly Dispose of Batteries**

This product contains a Lithium battery. To properly dispose of expired batteries, view your city/ state's website or newsletter to determine what disposal guidelines, if any, should be followed, and make note of designated hazardous waste collection days.

**Battery Warning**

Lithium batteries can expand, burst, or catch fire if used incorrectly, causing both property damage and or personal injury. It is essential that you follow all the included instructions and safety warnings in full. The manufacturer, distributors, and retailers will assume no liability for the failure to comply with these safety instructions and warnings.

**Technical Support**

**Email:** support+20weventspeaker@pctbrands.com

**Phone:** (248) 236-0061 9:30am-5:30pm EST, M-F.

**PCT BRANDS**

PCT Brands LLC, 3720 Lapeer Rd., Auburn Hills, MI 48326. Made in China.  
PCT Brands is a trademark or registered trademark of PCT Brands, LLC. © 2017 All designs are protected by copyright ©French Bull LLC. The French Bull logo, the French Bull dog and Live Vivid are registered trademarks of French Bull LLC. This product is produced under license. All rights reserved. Bluetooth is a registered trademark of Bluetooth SIG, Inc. All rights reserved. © 2017 PCT Brands, LLC

20WEventSpeaker\_MAN\_07/17

ounded by iconoclastic designer

and pop enthusiast Jackie Shapiro.

French Bull re-imagines the ordinary

with an unconventional twist.

A passion for pattern and a desire to create

home products inspired French Bull.

French Bull's boundaries have become

as limitless as its distinctive look.

**LIVEVIVID.**



use for which the product is not intended, is contrary to instructions provided in the user manual, as a result of the use of parts not manufactured or sold by PCT Brands, LLC, or due to any misuse, abuse, negligence, modification, or improper packing when returning product to PCT Brands, LLC. EXCEPT FOR THE WARRANTY SET FORTH HEREIN, PCT BRANDS, LLC DISCLAIMS ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED OR STATUTORY, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY APPLICABLE LAW ARE LIMITED TO THE TERM OF THIS WARRANTY. IN NO EVENT SHALL PCT BRANDS, LLC BE LIABLE FOR ANY INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO LOSS OF BUSINESS, PROFITS, DATA OR USE, WHETHER IN AN ACTION IN CONTRACT OR TORT OR BASED ON A WARRANTY, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT. YOU AGREE THAT REPAIR, AND (UPON AVAILABILITY) REPLACEMENT, AS APPLICABLE, UNDER THE WARRANTY SERVICES DESCRIBED HEREIN IS YOUR SOLE AND EXCLUSIVE REMEDY WITH RESPECT TO ANY BREACH OF THE PCT BRANDS, LLC LIMITED WARRANTY SET FORTH HEREIN. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

**How Do I Obtain Warranty Service?**

For warranty service, please email warranty+20weventspeaker@pctbrands.com or call (248) 236-0061 to report a claim, at which time PCT Brands, LLC technicians will attempt to solve any issues. If unable to resolve your issue, you will be issued an RMA to authorize the return of the item for repair/replacement. All charges incurred while returning product, including postage, duties, export taxes, and customs duties, are the responsibility of purchaser, and purchaser assumes all risk of loss during shipment. For more information visit [www.pctbrands.com](http://www.pctbrands.com)

**FCC Compliance**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Note 1:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: a) Reorient or relocate the receiving antenna b) Increase the separation between the equipment and receiver c) Connect the equipment into an outlet different from that to which the receiver is connected d) Consult the dealer or an experienced radio/TV technician for help.

**Note 2:** Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**RF warning statement:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**One (1) Year Limited Warranty**

PCT Brands, LLC warrants this product to be free from defects in materials and workmanship. This warranty covers the original purchaser only, and is not transferable to anyone who subsequently buys, leases, or otherwise obtains from you. Your One Year Limited Warranty begins on the date of purchase. Your original purchase invoice or sales receipt, showing date of purchase, is your proof of warranty period. The duration of this warranty does not extend beyond the initial period of coverage should any repairs or replacements be made or performed. This warranty does not extend to any product not purchased from PCT Brands, LLC, or an authorized PCT Brands, LLC reseller. This warranty does not extend to product that has been damaged or rendered defective as a result of

- Function Guide**
- Power Button:** Long press to turn unit on/off.
  - Play/Pause Button:** Short press to pause and resume play. Long press to disconnect Bluetooth from currently paired device. For incoming calls, short press to answer and long press to reject the call.
  - Volume Down Button:** Short press to lower the volume and long press to play previous track (Bluetooth mode only).
  - Volume Up Button:** Short press to raise volume (a tone will sound when you've reached maximum volume). Long press to advance to next track (Bluetooth mode only).
  - Microphone:** During incoming calls, you should be within 1½ feet of the microphone for optimal call performance.
  - Bluetooth Indicator:** Flashes when available to pair, remains lit when paired.
  - Charging Indicator:** Red when charging, off when fully charged.
  - Auxiliary-In Jack:** For use with included 3.5mm cable.
  - MicroUSB Charging Port:** Use to charge speaker.

features and functions.

Thank you for your purchase

of the 20W Event Speaker.

This versatile speaker combines remarkably

crystal-clear sound with go-everywhere portability

Please read this manual to take full advantage

of all of this innovative speaker's

**Specifications**

Output: 10W x 2

Input: 5V=1A

Battery: 4400mAh



MicroUSB Charging Cable 3.5mm Auxiliary Cable

**Troubleshooting**

**Unit won't pair:** Make sure that your device's Bluetooth option is turned on and that the unit is not paired with another device.

**Volume too low:** In addition to raising the speaker's volume via the Volume Up button, make sure the volume on your device is turned up.

**Unit doesn't turn on:** Charge the unit.

- Attention:**
- Donotexposethisitemtoextremetemperaturesorwetconditions.
  - Donotdisassemblethisunit—nouseserviceableparts.
  - Donotuseharshorabrasivecleanersonthisunit.

**Taking a Call (Bluetooth Mode Only)**

To take an incoming call, quickly press the Play/Pause Button to take the call. A long press of the Play/Pause Button will reject the call. You should remain within approximately 1½ feet of the microphone for optimal performance when on a call.

**Auxiliary Mode**

*Note: You will not be able to take hands-free calls or use the previous/next track function in Auxiliary Mode. Use your device to access these functions.*

- To Use Auxiliary Mode**
1. Plug one end of the included Auxiliary Cable (included) into your device and the other end into your speaker. You will automatically enter Auxiliary Mode.
  2. After unplugging the Auxiliary Cable to return to Bluetooth mode, you may need to re-pair the speaker with your device.

**Charging**

Although your speaker has a partial charge when purchased, we recommend that you fully charge the unit before first use.

**How to Charge**

Using the included charging cable, plug the MicroUSB end into the unit and the USB end into a wall adapter (not included) and plug into an available outlet. The Charging Indicator will illuminate red. When charging is complete, the charging light will turn off. Once fully charged, unplug the charging cable. *Note: A tone will indicate when your speaker has a remaining battery charge below 20%.*



**How to Turn the Unit On and Off**

**Turn On:** Press and hold the Power Button until the you hear a tone and the Bluetooth/Charging Indicator illuminates blue and flashes, indicating the speaker is ready to be paired with your device.

**Turn Off:** Press and hold the Power Button until you hear a tone and the Bluetooth/Charging Indicator goes off.

**Bluetooth Pairing Mode**

1. Press and hold the Power Button to turn the unit on.
2. Open the Bluetooth setting on your device and select "FB EVENT."
3. When successfully paired, the Bluetooth/Charging Indicator will stop flashing and remain on (this light will flash slowly when audio is playing and remain lit when connected but audio is paused).
4. To disconnect your Bluetooth connection, press and hold the Play/Pause Button.