


## USER MANUAL

Item no.SA211      Wireless Speaker



1 – LED indicator

2 – Mode(speaker)

3 – Charging Port

4 – Mode(torch)

### First Time Use:

(Fully charged before first time use)

1. Connect the provided charging cable to a power source and to the micro USB port on the headphones.
2. The LED indicator light shows red when charging and turns off when fully charged.

### ON/OFF(torch)

Power on – Press Mode key to turn on.

Strobe – Press again to strobe mode.

Power off – Press again to turn off.

### ON/OFF(speaker)

Power on – Press and hold Mode key until LED light will be blinking

Power off – Press and hold Mode key until LED light disappeared

### Wireless Set Up:

Press and hold Mode key until Blue & Red LED begins blinking (this is pairing Mode).

Using a Bluetooth enabled audio device, search the possible connections for "GC-01".

### Audio Functions:

#### 1. Play/Pause

Press Mode button to play.

Press again to pause

#### 2. Incoming Calls:

If receiving a call via Bluetooth connection, audio will automatically pause and begin to play again when call ends.

Under connected mode when phone call comes in:

Double press the Mode key to reject

Short press the Mode key to answer

Short press the Mode key to end the call

NOTE: This equipment has been tested and found to comply with the limits for a

Class B digital device, pursuant to part 15 of the FCC Rules. These limits are

designed to provide reasonable protection against harmful interference in a

residential installation. This equipment generates uses and can radiate radio

frequency energy and, if not installed and used in accordance with the instructions,

may cause harmful interference to radio communications. However, there is no

guarantee that interference will not occur in a particular installation. If this

equipment does cause harmful interference to radio or television reception, which

can be determined by turning the equipment off and on, the user is encouraged to

try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a

circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance

could void the user's authority to operate the equipment.

This device complies with Part

15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may

cause undesired operation.