

Hey there,

Congratulations on getting your very own FPods FS100 Truly Wireless Earpods with latest BT Version V5.3, Quad Mic ENC, 10mm deep bass drivers, 60ms low latency gaming mode, and IPX4 rating. You can now truly sink into your world of sound. Your musical vibe begins here.

Quick Start Guide

TRULY WIRELESS STEREO EARPODS WITH QUAD MIC ENVIRONMENTAL NOISE CANCELLATION

fastrack
FPods
FS100



Quick Start Guide



Eartips (S,M,L)

2x Truly Wireless Earpods



1x Portable Charging Case



1x Type C Charging Cable

Overview



LED Indicator






Touch Area
Charging Pins



USB-C Charging Port

Getting Started

- Place the earpods in the charging case and close the lid.
- Make sure to charge the earpods fully before starting the pairing process.
- Open the charging case lid and take out the buds.
- Turn ON your phone's Bluetooth settings, and search for "FPods FS100" and tap to pair and connect.
- Your earpods are now paired and ready for you to experience.
- The earpods will automatically re-connect to a previously paired device the next time you use it (Make sure the device's Bluetooth is ON).
- To charge the earpods, place them back into the case and close the lid. This will also power off the earpods.
- Use the right sized Eartips (S,M,L) for a better fit and experience.



- Take out the earpods from the Charging Case.
- Unpair the earpods from the previously connected device.
- Tap 5 times on L/R bud.
- Red LED on both L and R buds blinks 3 times and goes off.
- Your earpods are now reset and ready to pair again.

Reset

- Take out the earpods from the Charging Case.
- Unpair the earpods from the previously connected device.
- Tap 5 times on L/R bud.
- Red LED on both L and R buds blinks 3 times and goes off.
- Your earpods are now reset and ready to pair again.

Setup

- Power on: To turn on the earpods take them out of the case.
- Power off: Put the earpods in the case and close the lid to power off.
- To manually Power on the earpods, press and hold the buds for 2 seconds.
- To manually Power off the earpods, press and hold the buds for 4 seconds.
- To charge the earpods, place them in the charging case and close the lid.
- Please ensure to charge your earpods fully before using them.
- To charge the Charging Case, use the Type C charging cable provided in the box.
- Use a standard 5V / 1A adaptor for charging.

Call Controls

- Call Answer:** Double tap on L/R bud.
- Call Hangup:** Double tap on L/R bud during the call.
- Call Reject/Decline:** Press & hold on L/R bud for 2 seconds.

Music Controls

- Play/Pause:** Double tap on L/R bud.
- Increase Volume:** Single tap on R bud.
- Decrease Volume:** Single tap on L bud.
- Previous Track:** Press & hold L bud for 2 seconds.
- Next Track:** Press & hold R bud for 2 seconds.

Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



Quickstart Guide

fastrack
FPods
FS100

Monopod Mode


You can take out any bud out of the Charging Case and start using it as Monopod.

- 👉 Call Answer - Double tap on bud.
- 👉 Call Reject - Press & hold the bud for 2 seconds.
- 👉 Call Hangup - Double tap on bud.
- 👉 Music Play/ Pause - Double tap on bud.
- 👉 Music volume decrease - Single tap on bud.
- 👉 Music previous track - Press & hold the bud for 2 seconds.

- 👉 Call Answer - Double tap on bud.
- 👉 Call Reject - Press & hold the bud for 2 seconds.
- 👉 Call Hangup - Double tap on bud.
- 👉 Music Play/ Pause - Double tap on bud.
- 👉 Music volume increase - Single tap on bud.
- 👉 Music next track - Press & hold the bud for 2 seconds.

Features

Voice Assistant, Gaming Mode



- 👉 Tap 3 times on L/R bud to activate Voice Assistant.
- 👉 Tap 4 times on L/R bud to activate Gaming Mode.

Gaming Mode

Level up your gaming experience with the built-in low latency gaming mode.

Voice Assistant

Your voice assistant is just a few taps away.

Features

- 👂 Environmental Noise Cancellation (Quad Mic)
- ⚡ NitroFast Charge — 10 min charge gives 150 min Playtime*
- 🎮 40 Hours Playtime*
- 🎮 Gaming Mode (Low Latency of 60ms)
- 👉 Leather Finish
- 🍃 Lightweight Earpods
- 📶 10mm Driver
- 📶 Latest BT version 5.3

*As tested under optimal conditions at Titan Smart Labs.

LED Indications

Earpods

- Power ON: Blue LED blinks 3 times.
- Power OFF: Red LED blinks 3 times.
- Pairing Mode: Blue/Red LED blinks alternatively on 1 bud.
- Connected: LED off on both buds.
- While charging: Solid Red LED on buds during charging.
- Full charge: Buds LED goes off when fully charged.

Charging Case

- While charging: Red LED blinks continuously.
- Full charge: Solid red when fully charged.

Product Specifications

Product Specifications:

- BT Version: V5.3
- Driver Size: 10mm
- Frequency Response: 20Hz — 20KHz
- Water Resistance: IPX4
- Total Playtime with Charging Case: 40 Hours
- Buds Charging Time: 45 min
- Case Charging Time: 75 min
- Charging Voltage: DC 5V
- Transmission Distance: 10m
- Earpods Battery Capacity: 40mAh
- Charging Case Battery Capacity: 300mAh

Care & Warranty

The Don't's

- Do not expose the earpods to extreme temperature/ weather conditions.
- Don't use chemicals or detergent to clean your buds.
- Do not keep the case on charging for a longer time once it is fully charged.

Terms of Warranty

The product comes with a One year limited warranty against manufacturing defects. T&C apply. Any damage to the earpods that is not a malfunctioning issue will void the product's warranty. Please take care of your buds to ensure prolonged service life. If you have any queries or need to raise a complaint, please call us on 1800-266-0123 or visit the nearest Fastrack store.

Note - For more details on the product, please visit www.fastrack.in



FCC Compliance

FCC ID: 2AK9F-FT8

FCC Compliance

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions.

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Care & Warranty

🌐 www.fastrack.in 📱 @fastrack 📷 @fastrackworld

fastrack

